

Resolver Input Module

M/N 57C411

Instruction Manual J-3640-1

RELIANCE
ELECTRIC 

The information in this user's manual is subject to change without notice. Reliance Electric Industrial Company assumes no responsibility for errors that may appear in this user's manual.

WARNING

THIS UNIT AND ITS ASSOCIATED EQUIPMENT MUST BE INSTALLED, ADJUSTED, AND MAINTAINED BY QUALIFIED PERSONNEL WHO ARE FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF ALL EQUIPMENT IN THE SYSTEM AND THE POTENTIAL HAZARDS INVOLVED. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.

WARNING

INSERTING OR REMOVING THIS MODULE OR ITS CONNECTING CABLES MAY RESULT IN UNEXPECTED MACHINE MOVEMENT. TURN OFF POWER TO THE MACHINE BEFORE INSERTING OR REMOVING THE MODULE OR ITS CONNECTING CABLES. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.

CAUTION

THIS MODULE CONTAINS STATIC-SENSITIVE COMPONENTS. CARELESS HANDLING CAN CAUSE SEVERE DAMAGE.

DO NOT TOUCH THE CONNECTORS ON THE BACK OF THE MODULE. WHEN NOT IN USE, THE MODULE SHOULD BE STORED IN AN ANTI-STATIC BAG. THE PLASTIC COVER SHOULD NOT BE REMOVED. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN DAMAGE TO OR DESTRUCTION OF THE EQUIPMENT.

Table of Contents

1.0	Introduction	1-1
2.0	Mechanical/Electrical Description	2-1
2.1	Mechanical Description	2-1
2.2	Electrical Description	2-1
3.0	Installation	3-1
3.1	Wiring	3-1
3.2	Initial Installation	3-1
3.3	Module Replacement	3-5
4.0	Programming	4-1
4.1	Register Organization	4-1
4.2	Local I/O Definition	4-2
4.2.1	Single Register Reference	4-3
4.2.2	Bit Reference	4-3
4.2.3	Examples of Local I/O Definitions	4-4
4.3	Remote I/O Definition	4-4
4.3.1	Single Register Reference	4-4
4.3.2	Bit Reference	4-6
4.3.3	Examples of Remote I/O Definitions	4-6
4.4	Reading and Writing Data in Application Tasks	4-6
4.4.1	BASIC Task Example	4-7
4.4.2	Control Block Task Example	4-7
4.5	Using Interrupts in Application Tasks	4-8
4.5.1	BASIC Task Example	4-8
4.5.2	Control Block Task Example	4-9
4.6	Using the External Stroke Input	4-10
4.7	Restrictions	4-11
4.7.1	Writing Bits to Registers	4-11
4.7.2	Interrupts in Remote I/O Racks	4-11
4.7.3	Feedback Element in a Drive System	4-11
5.0	Diagnostics and Troubleshooting	5-1
5.1	Incorrect Data	5-1
5.2	Bus Error	5-3
5.3	Interrupt Problems	5-4
5.3.1	No Interrupts	5-6
5.3.2	Hardware Event Time-Out	5-6
5.3.3	Hardware Event Count Limit Exceeded	5-6
5.3.4	Illegal Interrupt Detected	5-6

Appendices

Appendix A	
Technical Specifications	A-1
Appendix B	
Module Block Diagram	B-1
Appendix C	
File Connections	C-1
Appendix D	
Related Components	D-1

List of Figures

Figure 2.1 - External Strobe Input Circuit	2-2
Figure 2.2 - Low Leakage Requirement for Devices Driving Strobe Input	2-2
Figure 2.3 - Module Feedback	2-3
Figure 3.1 - Rack Slot Numbers	3-1
Figure 3.2 - Typical M/N or C380 Reserver Field Connections	3-2
Figure 3.3 - Typical M/N or C381 Reserver Field Connections	3-3
Figure 3.4 - Changing the Direction of Rotation	3-4
Figure 4.1 - Reserver Data Registers	4-1
Figure 4.2 - Interrupt Control Registers	4-2
Figure 4.3 - Reserver Locking Register	4-2
Figure 4.4 - Module in a Local Rack	4-3
Figure 4.5 - Module in a Remote Rack	4-5

1.0 INTRODUCTION

The Resolver Input Module is used to input the angular position of a resolver to the DCS 5000 system. The module provides 12-bit resolution of one revolution and a 2-bit resolution counter. The resolver position may be sampled from 500 microseconds to 32.767 seconds. An external strobe input is provided to permit synchronization of the DCS 5000 system to an external event. The module can be programmed to interrupt on every sample.

Typically, this module is used to input rotary shaft position for the purpose of determining shaft position or velocity.

This manual describes the functions and specifications of the module. It also includes a detailed overview of installation and servicing procedures, as well as examples of programming methods.

Related publications that may be of interest:

- J-2671 DCS 5000 PRODUCT SUMMARY
- J-3600 DCS 5000 ENHANCED BASIC LANGUAGE INSTRUCTION MANUAL
- J-3601 DCS 5000 CONTROL BLOCK LANGUAGE INSTRUCTION MANUAL
- J-3602 DCS 5000 ADDRESS LOGIC LANGUAGE INSTRUCTION MANUAL
- J-3629 DCS 5000 HMDI-FO INSTRUCTION MANUAL
- J-3630 DCS 5000 PROGRAMMING TERMINAL INSTRUCTION MANUAL
- J-3635 DCS 5000 PROCESSOR MODULE INSTRUCTION MANUAL
- IEEE 516 GUIDE FOR THE INSTALLATION OF ELECTRICAL EQUIPMENT TO MINIMIZE ELECTRICAL NOISE INPUTS TO CONTROLLERS FROM EXTERNAL SOURCES

2.0 Mechanical/Electrical Description

The following is a description of the faceplate LEDs, field termination connectors, and electrical characteristics of the face connectors.

2.1 Mechanical Description

The input module is a printed circuit board assembly that plugs into the backplane of the DCS 5000 rack. It consists of the printed circuit board, a faceplate, and a protective enclosure. The faceplate contains tabs at the top and bottom to simplify removing the module from the rack. Module dimensions are listed in Appendix A.

The faceplate of the module contains a female connector socket and 5 LED indicators for module status, including one light that indicates when the board is operational, (on) or malfunctioning (off).

Input signals are brought into the module via a multiconductor cable (M/C 57C673; see Appendix D). One end of this cable attaches to the faceplate connector, while the other end of the cable has stake on connectors that attach to a terminal board for easy field wiring. The faceplate connector socket and cable plug are keyed to prevent the cable from being plugged into the wrong module.

On the back of the module are two edge connectors that attach to the system backplane.

2.2 Electrical Description

The input module contains a tracking resolver-to-digital converter that produces a 12 bit digital number proportional to one electrical revolution of a resolver. The digital position may be sampled in one of two ways. The most common method is to specify the sampling period. The period may range from a low of 600 microseconds to a high of 32.7675 seconds, in increments of 600 microseconds.

The second method is to sample the position when an external event occurs. This method is useful when it is necessary to synchronize the DCS 5000 with the occurrence of a particular event. Using an external strobe input is a simple method of synchronizing your application software to the exact position of an object when an external event occurs. See figure 2.1 for details about the electrical characteristics of the external strobe input circuit. Because of the high input impedance of the strobe input, the device driving the input must have low leakage. See figure 2.2.

The module can be programmed to generate an interrupt whenever it does a periodic sample. This mode allows you to synchronize task execution with the conversion of new data. The converted data will be latched when the interrupt is generated.

The module contains a 2 bit electronic counter that can count a total of 4 electrical resolver revolutions. This 2 bit counter is contained in the most significant two bits of resolver position, registers 0 and 1. This counter is reset whenever power is turned on to the system or a board reset command occurs.

The module produces a 26 volt rms 2301 Hertz sine wave reference output signal which is capable of driving a $400\ \Omega$ load. This reference signal is transformer-isolated and short-circuit protected through a current limiter. The module also receives 11.8 volt rms sine and cosine signals from the resolver, as well as the 26 volt rms reference.

There are 5 LEDs on the top plate of the module. The top LED, labeled DIR-CLOCK, indicates the direction of rotation of the resolver. When it is on, the resolver is rotating clockwise. The next LED, labeled +DRK OK, indicates that the resolver is connected to the module. The next LED, labeled CCLK OK, indicates that the common clock is on. The fourth LED, labeled IPS OK, indicates that the isolated power supply is working. Finally, the bottom LED, labeled OK, indicates whether the common clock is on and the isolated power supply is functional. See figure 2.3.




Figure 2.1 - External Strobe Input Circuit




Figure 2.2 - Low Leakage Requirement for Device Driving Strobe Input




Figure 2.3 - Module Faceplate

3.0 INSTALLATION

3.1 Wiring

The installation of wiring should conform to all applicable codes.

To insure the possibility of electrical noise interfering with the proper operation of the control system, exercise care when installing the wiring from the system to the external devices. For detailed recommendations, refer to IEEE 515.

You should use twisted pair (2 wires per inch) wiring to/from the resolver.

3.2 Initial Installation

Use the following procedure to install the module:

WARNING

INSERTING OR REMOVING THIS MODULE OR ITS CONNECTING CABLES MAY RESULT IN UNEXPECTED MACHINE MOTION. POWER TO THE MACHINE SHOULD BE TURNED OFF BEFORE INSERTING OR REMOVING THE MODULE OR ITS CONNECTING CABLES. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.

- Step 1 Remove power from the system. Power to the rack as well as all power to the wiring leading to the module should be off.
- Step 2 Take the module out of its shipping container. Take the module out of the anti-static bag. Be careful not to touch the connectors on the back of the module.
- Step 3 Insert the module into the desired slot in the rack. Refer to figure 3.1. Use a screwdriver to secure the module into the slot.




Figure 3.1 - Rack Slot Numbers

Step 4. Mount the terminal strip (from cable assembly MN 57C373) on a panel. The terminal strip should be mounted to a low easy access to the screw terminals. Be sure that the terminal strip is close enough to the rack so that the cable will reach between the terminal strip and the module. The cable assembly is approximately 60 inches long.

Step 5. Attach the resolver but leave the mechanical coupling between the resolver and the motor unconnected.

Fasten the field wires from the resolver to the terminal strip. Typical field connections are shown in figures 3.2 and 3.3.

Use twisted-pair wire, connected as shown, for the cabling between the resolver and the terminal strip in the control enclosure. Recommended twisted-pair wire is Baber™ B167 cable or equivalent. Maximum operating cable length is dependent upon the type of cable you use.

Make certain that all field wires are securely fastened.




Figure 3.2 - Typical MN 57C360 Resolver Field Connections




Figure 3.3: Typical M/N 57C361 Resolver Field Connections

- Step 6:** Insert the cable assembly's (M/N 57C373) field terminal connector into the mating half of the module. Use a screwdriver to secure the connector to the module.
- Note that both the module and the terminal slip connector are equipped with "keys". These keys should be used to prevent the wrong cable from being connected to the module in the event that the connector needs to be removed for any reason and then reattached later.
- At the time of installation, rotate the keys on the module and the connector so that they can be connected together securely. It is recommended that, for modules so equipped, the keys on each succeeding module in the rack be rotated one position to the right of the keys on the preceding module.
- If you use this method, the keys on a particular connector will be positioned in such a way as to fit together only with a specific module, and there will be little chance of the wrong connector being attached to a module.
- Step 7:** Check the wiring and be sure all connections are tight.
- Step 8:** With the resolver mechanically disconnected from the motor, turn on power to the rack. Use an oscilloscope to test the sine and the cosine signals from the resolver. These signals, measured at the terminal strip, should be a sine wave of approximately 33.4 V_{rms} (11.8 V_{rms} ± 1% RMS).
- Step 9:** Verify the installation by using the Programming Executive Software. Refer to the AutoMax Programming Executive Manual (J-3630 or J-3684) for more information.
- Use the I/O MONITOR function for local I/O or remote I/O, depending upon where the module is located. Set register 4 to a value of 1. Test register 2 and verify that bit 10 is set. If it is not, set register 3 to a value of 61.

Monitor register 0. Verify that it contains numbers proportional to the shaft's position of the resolver and that the numbers increase as the resolver is rotated clockwise. The direction of rotation can be reversed by switching the polarity of either the sine or the cosine wires. See Figure 3.4.




Figure 3.4 - Changing the Direction of Rotation

- Step 10. If the external strobe input is being used, the shaft should be turned to a fixed position and stopped. The external strobe input should now be closed. Verify that register 1 contains the same data as register 0.
- Step 11. Turn off power to the rack. Connect the mechanical coupling between the resolver and the motor. Turn on power to the system.

3.3 Module Replacement

WARNING

INSERTING OR REMOVING THIS MODULE OR ITS CONNECTING CABLES MAY RESULT IN UNEXPECTED MACHINE MOTION. POWER TO THE MACHINE SHOULD BE TURNED OFF BEFORE INSERTING OR REMOVING THE MODULE OR ITS CONNECTING CABLES. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.

Use the following procedure to replace a module:

- Step 1 Turn off power to the rack and all connections.
- Step 2 Use a screwdriver to loosen the screws holding the connector to the module. Remove the connector from the module.
- Step 3 Loosen the screws that hold the module in the rack. Remove the module from the slot in the rack.
- Step 4 Place the module in the anti-static bag, being careful not to touch the connectors on the back of the module. Place the module in the cardboard shipping container.
- Step 5 Take the new module out of the anti-static bag it came in, being careful not to touch the connectors on the back of the module.
- Step 6 Insert the module into the desired slot in the rack. Use a screwdriver to secure the module into the slot.
- Step 7 Attach the field terminal connector (M/N 67C373) to the mating half on the module. Make certain this is the connector is the proper one for this module (see step 6 in 3.2 initial installation). Use a screwdriver to secure the connector to the module.
- Step 8 Turn on power to the rack.

4.0 PROGRAMMING

This section describes how the data is organized in the module and provides examples of how the module is accessed by the application software. For more detailed information, refer to the DCS 5000 Enhanced BASIC Language Instruction Manual (J-3800).

4.1 Register Organization

The input module contains a total of five 16-bit registers. Registers 0 and 1 contain resolver position data. The resolver-to-digital converter provides 12 bits of resolution. Register 0 is updated with new position information at the rate specified in register 4. Register 1 is updated whenever the EXTERNAL STROBE goes from false to true. These registers are read only. Refer to figure 4.1.




Figure 4.1 Resolver Data Registers

Registers 2 and 3 are the interrupt status and control registers. Both registers contain the same information. Register 2 is read only. Register 3 is read/write. If the module is located in a remote rack, you must read the status from register 2. With the exception of bit 15 and bit 12, this register is controlled by the operating system and must not be manipulated by the user. Refer to figure 4.2.

For this module to operate properly, the common clock signal must be present on the backplane. The common clock signal is a 1 MHz clock that can be connected to all the I/O modules in the rack. It can be generated from a number of DCS 5000 I/O modules. If this module is to drive the common clock, bit 6 must be set.




Figure 4.2 - Interrupt Control registers

Register 4 contains the update period for reaching the receiver position. Each count in this register is equivalent to 500 microseconds. The update period may range from 600 microseconds to 32.7675 seconds. Refer to figure 4.3.




Figure 4.3 - Receiver Update Register

4.2 Local I/O Definition

Before any application program can be written, it is necessary to configure, or set, the definitions of system-wide variables, i.e. those that must be globally accessible to all tasks. This section describes how to configure the input module when it is located in the same rack as the processor module that is referencing it. Refer to figure 4.4.




Figure 4.1 - Module in a Local Rack

4.2.1 Single Register Reference

Use this method to reference a 16-bit register as a single input. Resolver input data, update period, and interrupt control registers are typically referenced using this method. The symbolic name of each register should be as meaningful as possible:

mmmm ICODE SYMBOLIC_NAME% [SLOT=*s*, REGISTER=*r*]

4.2.2 Bit Reference

Use this method to reference individual inputs on the module. Common clock status and control bits are typically referenced using this method. The symbolic name of each bit should be as meaningful as possible.

mmmm ICODE SYMBOLIC_NAME% [SLOT=*s*, REGISTER=*r*, BIT=*b*]

where:

mmmm - BASIC statement number. This number may range from 1-52767.

SYMBOLIC_NAME% - A symbolic name chosen by the user and ending with (%). This indicates an integer data type and all references will access register "r".

SYMBOLIC_NAME%b - A symbolic name chosen by the user and ending with %b. This indicates a boolean data type and all references will access bit number "b" in register "r".

SLOT - Slot number that the module is plugged into. This number may range from 0-15.

REGISTER - Specifies the register that is being referenced. This number may range from 0-3.

BIT - Used with boolean data types only. Specifies the bit in the register that is being referenced. This number may range from 0-15.

4.2.3 Examples of Local I/O Definitions

The following statement assigns the symbolic name POSITION% to register 0 of the input module located in slot 4:

```
1020 IODEF POSITION%[ SLOT=4, REGISTER=0]
```

The following statement assigns the symbolic name CCLK_ON% to bit 6 of register 3 of the input module located in slot 7:

```
3050 IODEF CCLK_ON%[ SLOT=7, REGISTER=3, BIT=6]
```

4.3 Remote I/O Definition

This section describes how to configure the module when it is located in a rack that is remote from the processor module referencing it. Refer to figure 4.5.




Figure 4.5- Modules in a Remote Rack

4.3.1 Single Register Reference

Use this method to reference a 16-bit register as a single input. Receiver input data and update period registers are typically referenced using this method. The symbolic name of each register should be as meaningful as possible.

```

### RCODEF SYMBOLIC NAME=(MASTER_SLOT=n,
    DROP=i, SLOT=j, REGISTER=k)

```

4.3.2 Bit Reference

Use this method to reference individual inputs on the module. Common clock status and control bits are typically referenced using this method. The symbolic name of each bit should be as meaningful as possible:

```
numm RIDDEF SYMBOLIC_NAME@ [ MASTER_SLOT=m,  
    DROP=d, SLOT=s, REGISTER=r, BIT=b]
```

where:

numm - BASIC statement number. This number may range from 1-32767.

SYMBOLIC_NAME% - A symbolic name chosen by the user and ending with (%). This indicates an integer data type and all references will access register "r".

SYMBOLIC_NAME@ - A symbolic name chosen by the user and ending with (@). This indicates a boolean data type and all references will access bit number "b" in register "r".

MASTER_SLOT - Slot number that the master remote I/O module is plugged into. This number may range from 0-15.

DROP - Drop number of the slave remote I/O module that is in the same rack as the input module. This number may range from 1-7.

SLOT - Slot number that the module is plugged into. This number may range from 0-15.

REGISTER - Specifies the register that is being referenced. This number may range from 0-4.

BIT - Used with boolean data types only. Specifies the bit in the register that is being referenced. This number may range from 0-15.

4.3.3 Examples of Remote I/O Definitions

The following statement assigns the symbolic name SHAFT% to register 0 on the input module located in slot 4 of remote I/O drop 3. This remote drop is connected to the remote I/O system whose master is located in slot 15 in the master rack:

```
1030 RIDDEF SHAFT.% [ MASTER_SLOT=15, DROP=3,  
    SLOT=4, REGISTER=0]
```

The following statement assigns the symbolic name CLOCK_EB@ to bit 6 of register 3 on the input module located in slot 7 of remote I/O drop 2. This remote drop is connected to the remote I/O system whose master is located in slot 8 in the master rack.

```
2050 RIDDEF CLOCK_EB@ [ MASTER_SLOT=8,  
    DROP=2, SLOT=7, REGISTER=3, BIT=6]
```

4.4 Reading and Writing Data in Application Tasks

In order for an input module to be referenced by application software, it is first necessary to assign symbolic names to the physical hardware. This is accomplished with either RIDDEF or RIDDEF statements in the configuration task.

Each application program, or task, that wishes to reference the symbolic names assigned to the input module may do so by declaring those names COMMON.

The frequency with which tasks read their inputs and write their outputs depends on the language being used. Control block tasks read inputs once at the beginning of each scan and write outputs once at the end of scan. BASIC tasks read an input and write an output for each reference throughout the scan.

The following is an example of a configuration task for the input module:

```

1010
1021  COMMON RESOLV
1030
1040  IODEF RESOLVER_NS(3,DT=4,REGISTER=0)
1050  IODEF RESOLVER_CN(1,X=4,DT=4,REGISTER=1)
1060
1070  COMMON CLOCK_CYCLE
1080
1090  IODEF CLK_CN(2)S(DT=4,REGISTER=3,DT=6)
1100
1110  AND _period=period
1120
1130  IODEF UPDATE_TIMES(SLOT=4,REGISTER=4)
1140
1150  Place any additional configuration statements here
1160
2010  END

```

4.4.1 BASIC Task Example

This example will read the resolver input once every second and store the value in the symbol "CURRENT_VALUE". The resolver position will be sampled every 100 mill seconds.

```

1010  COMMON RESOLVER_NS      ;Resolver description
1020  COMMON CLK_CN          ;Common clock cycle
1030  COMMON UPDATE_TIMES    ;Update period for resolver update
1040
1050  LOCAL CURRENT_VALUE     ;Current value of analog input
1060
2010  UPDATE_TIMES = 100     ;100 second conversion
3010  CLK_CN(1) = 1000       ;1000 millisecond cycle
4010
4020  Place any additional initialization software here
4030
5010  READ RESOLVER_NS(1)S(1)
5020  CURRENT_VALUE = RESOLVER_NS(1)
10010  END

```

The symbolic names defined as "COMMON" reference the inputs defined in the sample configuration task above. The symbolic name CURRENT_VALUE is local to the BASIC task and does not have (0) associated with it. Refer to the UGS 5000 Enhanced BASIC Language Instruction Manual (J-3602) for more information.

4.4.2 Control Block Task Example

The following example will read the resolver data every 400 mill seconds and store the inverted value in the symbol "READINGS". The resolvers shaft position will be sampled every 500 microseconds.

```

1010  COMMON RESOLVER_NS      ;Resolver description
1020  COMMON CLK_CN          ;Common clock cycle
1030  COMMON UPDATE_TIMES    ;Update period for resolver data
1040
1050  LOCAL READINGS         ;Current negative value of input
1060

```

```

9000  IDEF REGISTER=1          (COMMON) resolved conversion
9010  CODEL_EDGE=100         (COMMON) resolved
9020
9030  Place any additional initialization software here
9040
9050  Stop every 25 msec
9060
9070  CALL BCAN_LOAD_TASK=100
9080  GO_MATTER(STATE=BEFORE,_RESOLUTION_RESOLUTION)
9090  END

```

The symbolic names defined as *COMMON* reference the inputs defined in the sample configuration task above. The symbolic name *READINGS* is equal to the BASIC task and does not have a IC associated with it. Refer to the DCS 6000 Control Block Language Instruction Manual (J 3801) for more information.

4.5 Using Interrupts in Application Tasks

The input module supports an interrupt on the periodic resolution-to-digital conversion. Interrupts are used to synchronize software tasks with the resolution-to-digital conversion. Conversion rates may be specified from 500 microseconds up to a maximum of 52.7675 seconds in increments of 500 microseconds.

In order to use interrupts on the input module, it is necessary to assign symbolic names to the interrupt control register. This is accomplished with ICODEF statements in the configuration task. Note that interrupts cannot be used with modules located in remote racks.

Only one task may act as a receiver for a particular hardware interrupt. That task should declare the symbolic names assigned to the interrupt control register on the input module as COMMON. Once this has been done, any reference to those symbolic names within the task will reference the bus or register defined in the configuration task.

The following is an example of a configuration task for an input module using interrupts:

```

1000
1001  resolve
1002
1003  ICODEF RESOLVER_IN(SUCT=4, REGISTER=0)
1004  ICODEF RESOLVER_IN_RESOLUTION_RATE(REGISTER=1)
1005
1006  ICODEF REGISTER=0 (COMMON) resolved (task by the operating system)
1007
1008  ICODEF STROBE_STATUS(SUCT=4, REGISTER=0)EF=10
1009  ICODEF REGISTER_RESOLUTION_RATE(REGISTER=1)
1010  ICODEF STROBE_RESOLUTION_RATE(REGISTER=0)EF=10
1011
1012  GO_MATTER(STATE=BEFORE,_RESOLUTION_RESOLUTION)
1013
1014  Stop every 2500 msec
1015
1016  ICODEF REGISTER_RESOLUTION_RATE(REGISTER=1)EF=10
1017
1018  resolve
1019
1020  ICODEF REGISTER_RESOLUTION_RATE(REGISTER=1)EF=10
1021
1022  Place additional configuration statements here
1023
1024  END

```

This configuration defines all of the information most commonly used on the module. Unused definitions should be deleted by the user.

4.5.1 BASIC Task Example

The following is an example of a BASIC task that handles interrupts from the input module defined in section 4.4.

```
1000 COMMON /COMMON_VARS/ : (Reserved)
1001 COMMON /IOCR/ : (Reserved)
1010 COMMON /IOCR_LEN/ : (Reserved)
1020 COMMON /PRIVATE_VARS/ : (Reserved)
1030 COMMON /IOCR_LEN/ : (Reserved)
1040
1050
1060
1070
1080
1090
1100
1110
1120
1130
1140
1150
1160
1170
1180
1190
1200
1210
1220
1230
1240
1250
1260
1270
1280
1290
1300
1310
1320
1330
1340
1350
1360
1370
1380
1390
1400
1410
1420
1430
1440
1450
1460
1470
1480
1490
1500
1510
1520
1530
1540
1550
1560
1570
1580
1590
1600
1610
1620
1630
1640
1650
1660
1670
1680
1690
1700
1710
1720
1730
1740
1750
1760
1770
1780
1790
1800
1810
1820
1830
1840
1850
1860
1870
1880
1890
1900
1910
1920
1930
1940
1950
1960
1970
1980
1990
2000
END
```

4.5.2 Control Block Task Example

The following is an example of a control block task that handles interrupts from the input module defined in section 4.4.

```
1000 COMMON /RESOLVER_VARS/ : (Reserved)
1001 COMMON /IOCR/ : (Reserved)
1010 COMMON /IOCR_LEN/ : (Reserved)
1020 COMMON /PRIVATE_VARS/ : (Reserved)
1030 COMMON /IOCR_LEN/ : (Reserved)
1040
1050
1060
1070
1080
1090
1100
1110
1120
1130
1140
1150
1160
1170
1180
1190
1200
1210
1220
1230
1240
1250
1260
1270
1280
1290
1300
1310
1320
1330
1340
1350
1360
1370
1380
1390
1400
1410
1420
1430
1440
1450
1460
1470
1480
1490
1500
1510
1520
1530
1540
1550
1560
1570
1580
1590
1600
1610
1620
1630
1640
1650
1660
1670
1680
1690
1700
1710
1720
1730
1740
1750
1760
1770
1780
1790
1800
1810
1820
1830
1840
1850
1860
1870
1880
1890
1900
1910
1920
1930
1940
1950
1960
1970
1980
1990
2000
END
```

```

4000
4001     The following statement enables common clock from the module
4002     (this is true if the module is not back in the library, for example)
4003     The enable common clock should always be the lowest priority task
4004
4005
4006 GCLK_Eng = TRUE           ;Common clock enable
4007
4008
4009     Place additional initialization software here
4010
4011
4012     The next two statements are used to talk with the external
4013     event to the external. The event will be the sender
4014     and the event processor if the task is the highest
4015     priority task using a resolution of the module
4016     For example, the external event will be the
4017     highest priority task if it is a high speed task and
4018     the external event will be a resolution of the module
4019     if it is a low speed task
4020
4021 CALL_SCAN_LOOP(TICKS=0, EVENT=RESOLVER_EVENT)
4022
4023     The next statements perform the other operations of the
4024
4025
4026 CALL_PULSE_MULTINPUT=RESOLVER_NR, MULTIPLIER=1000, S
4027     (MULTIPLIER=1000, S)
4028
4029 END

```

4.6 Using the External Strobe Input

At the time of the external event, the reader position is transferred to register 1, where it will remain until the next event occurs. If your application software is reading the resolver position at a periodic rate (register 0), the difference between register 0 and register 1 represents the amount of travel from the time that the event occurred until the current scan of the application software. A typical application would be detecting the leading edge of an object moving on a conveyor.

The data captured by the strobe input will be as accurate as the external device driving the input. Note that when a strobe input has occurred, you must reset the input so that another one can occur. This is accomplished by writing a "1" to bit 12 of register 5.

The following is an example of a control block task that handles the strobe input from the input module defined in section 4.4.

```

8000 COMMON RESOLV=1, R4           ;Resolver rate
8001 COMMON RESOLVER_INTERRUPTS    ;Strobe reader data
8002 COMMON SCOR=0                 ;Scan position, 0 count of
8003 COMMON GCLK_Eng              ;Common clock enable
8004 COMMON INPUT_COUNTER=0       ;Input counter on time
8005 COMMON STROBE_STATUS=0       ;Strobe status
8006 COMMON STROBE_ACK=0         ;Strobe acknowledgment
8007 LOCAL RESOLVER_VALUES        ;Resolver value
8008 LOCAL STROBE_COUNTER=0       ;Strobe counter
8009 LOCAL INPUT_COUNTER=0        ;Input counter
8010 LOCAL EVENT_COUNTER=0        ;Event counter
8011 LOCAL EVENT_COUNTER=0        ;Event counter
8012
8013     Define the conversion parameters
8014
8015
8016 UPDATE_TICKS=100             ;Update tick count (100 counts)
8017 EVENT_NAME=RESOLVER_EVENT, INTERRUPT_STATUS=SCOR=0
8018     (MULTIPLIER=1000)
8019
8020 GCLK_Eng = TRUE           ;Common clock enable
8021
8022
8023 CALL_SCAN_LOOP(TICKS=0, EVENT=RESOLVER_EVENT)
8024
8025     The next statements build the conversion
8026     of the external event
8027
8028
8029 CALL_TRANSMISSION=RESOLV_COUNTER_INCREMENT, A
8030     (MULTIPLIER=1000, S)
8031
8032 STROBE_ACK=1, INPUT_COUNTER=0

```

```

7037
7038 The next statement calculates the current
7039 electrical time to occurrence of the distance
7040 error for all the gears.
7041
7042 G4  MATH_VAL1 = NEXT_PERIOD * LINES / 4
7043          RESOLV = STROBE_RESOLUTION *
7044          INITIAL_VALUE + RESOLVER_IN_EXTRA *
7045          MULTIPLIER / 18000
7046          PERIOD = MATH_VAL1 / RESOLV
7047
7048 The next statement calculates the current traveled
7049 length for each gear and the gears.
7050
7051 G4  MATH_VAL1 = NEXT_PERIOD * LINES *
7052          MULTIPLIER / 18000
7053          OUTPUT = PERIOD * DISTANCE1
7054
7055 The next statement calculates the correction
7056 required for each gear and the distance error for
7057 the program.
7058
7059 G4  DIFFERENCE1 = MATH_VAL1 - DISTANCE1 *
7060          NEXT_PERIOD * DISTANCE1 / 4
7061          OUTPUT = RESOLVER_VALUE1
7062
7063 END

```

4.7 Restrictions

This section describes limitations and restrictions on the use of this module.

4.7.1 Writing Data to Registers

Registers 0-2 are read only and may not be written to by the application software. Attempts to write to them will cause a bus error (severe system error). The following are examples from programs that write to the module and should therefore be avoided.

- a. Referencing the module on the left side of an equal sign in a LET statement in a control block or BASIC task.
- b. Referencing a resolver input as an output in a control block function.

4.7.2 Interrupts in Remote I/O Racks

This module cannot be used in the interrupt mode in a remote rack.

4.7.3 Feedback Element in a Drive System

When this module is used with a resolver in a drive control system, you must incorporate an independent method of determining its. This module is actually reading proper motor RPM. It is necessary to determine this because this module is not capable of detecting a loss of feedback in all situations, such as, for example, a broken coupling between the motor and resolver.

WARNING

LOSS OF, OR OTHERWISE IMPROPER, RESOLVER SIGNAL CAN RESULT IN UNCONTROLLED MOTOR SPEED. PROVIDE AN INDEPENDENT METHOD OF SHUTTING DOWN EQUIPMENT IF THIS SHOULD OCCUR. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY AND IN DAMAGE TO, OR DESTRUCTION OF, THE EQUIPMENT.

You must also determine the maximum safe operating speed for the motor, connected machinery, and material being processed. Then, either verify that the system is incapable of reaching that speed, or else incorporate the necessary hardware/software to ensure that this limit will never be exceeded.

WARNING

THE PURCHASER IS RESPONSIBLE FOR ENSURING THAT DRIVEN MACHINERY, ALL DRIVE TRAIN MECHANISMS, AND THE WORKPIECE IN THE MACHINE ARE CAPABLE OF SAFE OPERATION AT MAXIMUM SPEEDS. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY AND IN DAMAGE TO, OR DESTRUCTION OF, THE EQUIPMENT.

5.0 DIAGNOSTICS AND TROUBLESHOOTING

This section explains how to troubleshoot the module and field connections.

5.1 Incorrect Data

Problem: The data is either always off, always on, or different than expected. The possible causes of this error are a module in the wrong slot, a programming error, or a malfunctioning module. It is also possible that the input is either not wired or wired to the wrong device. Use the following procedure to isolate the problem:

- Step 1:** Verify that the input module is in the correct slot and that the I/O definitions are correct.
- Refer to figure 3.1. Verify that the slot number being referenced agrees with the slot number defined in the configuration task. Verify that the register number and the bit number are correct.
- For remote I/O installs, one also verify that the master slot and drop numbers are defined correctly. Refer to the DCS 5000 Remote I/O Instruction Manual (I-3829) for more detailed information on configuring your remote I/O system.
- Step 2:** Verify that the module can be accessed.
- Connect the programming terminal to the system and run the ReSource Software. List the I/O MONITOR function to display the four registers on the input module. Repeat steps 7 and 8 in section 3.2.
- Step 3:** Verify that the user application program is correct.
- Review the programming examples in sections 4.4, 4.5, and 4.6. Make certain that the I/O definitions in your configuration task are correct and that the task(s) using this module have declared these variables I/O/MON.
- Verify that an update period has been written to register 4. Recall that each count is 500 microseconds (.0005 seconds). This value specifies the frequency with which the resolver position will be converted to digital numbers.
- Verify that the common clock has been turned on. The "CLOCK OK" LED on the faceplate of the module should be lit. If the common clock is not present on the backplane, the module will not convert the resolver position to digital values. If the common clock is being generated from this module, remember that bit 6 in register 3 must be set.
- Step 4:** Verify that the resolver is wired correctly.
- Remove power from the system. Disconnect the mechanical coupling between the resolver and the motor.
- Confirm that all the terminal strip connections are tight. Refer to figures 3.2 and 3.3. Appendix G also lists the terminal strip connections.
- Apply power to the rack only.

If everything is working properly but the direction of rotation is backwards, it may be reversed by switching the polarity of either the sine or the cosine wires as shown in figure 3.4.

Step 5. Verify that the input circuit is working properly.

Connect an oscilloscope to the proper points on the terminal strip and confirm that the voltages are correct.

The resolver reference voltage across TB 1 and 2 should be a nominal 26 Vrms.

If it is 26 Vrms, check the jumpers on the terminal strip.

One jumper should connect TB 1 and 3. Another jumper should connect TB 2 and 4. Rotate the resolver's shaft and measure the sine voltage (TB 5 and 6) and cosine voltage (TB 7 and 8). Both voltages should range from 0 volts to approximately 11.8 Vrms.

If the resolver reference (TB 1 and 2) is not a nominal 26 Vrms, measure the D-C resistance of the resolver.

Disconnect the resolver cable from the terminal strip (TB 1 and 2) and measure the resistance across the disconnected wires.

The resistance should be in the range of 35 to 125 ohms.

If the resistance is within this range, the input module is malfunctioning and should be replaced. If the resistance is not within this range, disconnect the cable from the resolver and measure the resistance directly on the resolver.

If this resistance is reading within the 35 to 100 ohm range, the resolver is operating properly. Check the cabling for a possible short. If the resistance is not within the 35 to 100 ohm range, the resolver is malfunctioning and should be replaced. If the problem is still present, check the cable for a possible short.

Reconnect the resolver cable at TB 1 and 2.

Remove power from the rack. Reconnect the mechanical coupling between the resolver and the motor. Reapply power to the system.

Step 6. Verify that the hardware is working properly.

WARNING

INSERTING OR REMOVING THIS MODULE OR ITS CONNECTING CABLES MAY RESULT IN UNEXPECTED MACHINE MOTION. POWER TO THE MACHINE SHOULD BE TURNED OFF BEFORE INSERTING OR REMOVING THE MODULE OR ITS CONNECTING CABLES. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.

If all of the proper signals are present and the values are still not correct, the problem lies in the hardware. Verify the hardware functionality by systematically swapping out modules. After each swap, if the problem is not corrected, replace the original item before swapping out the next item.

To test local I/O, first replace the input module. Next, replace the processor module (e). If the problem persists, take all of the modules except one processor module and the input module out of the backplane. If the problem is now corrected, one of the other modules in the rack is malfunctioning. Reconnect the other modules one at a time until the problem reappears. If none of these tests reveals the problem, replace the backplane.

To test remote I/O, first verify that the remote I/O system is communicating with the drop that contains the input module being tested. Next, by systematically swapping out modules, determine whether the input module is the only module that is not working.

If more than one module is not working correctly, the problem most likely lies in the remote I/O system. Refer to the DCS 5000 Remote I/O Instruction Manual (J-3623) for additional information. If the problem does not lie in the system, it probably involves the remote rack.

To test the remote rack, first replace the input module. If the problem persists, take all of the modules out of the remote backplane except the slave remote I/O module and the input module. If the problem is now corrected, one of the other modules in the rack is malfunctioning. Reconnect the other modules one at a time until the problem reappears. If the problem proves to be neither in the remote I/O system nor in the remote rack, try replacing the backplane.

5.2 Bus Error

Problem: A "BI" or "IB" appears on the processor module's LED. This error message indicates that there was a bus error when the system attempted to access the module. The possible causes of this error are a missing module, a module in the wrong slot, or a malfunctioning module. It is also possible that the user has attempted to write to the wrong registers on the module. Use the following procedure to isolate a bus error:

- Step 1:** Verify that the input module is in the correct slot and that the I/O definitions are correct.
- Refer to figure 3-2. Verify that the slot number being referenced agrees with the slot number defined in the configuration rack. Verify that the register number is in the range of 0-1.
- For remote I/O installations, also verify that the master slot and remote drop number are defined correctly.
- Refer to the DCS 5000 Remote I/O Instruction Manual (J-3623) for more information on configuring your remote I/O system.
- Step 2:** Verify that the module can be accessed.
- Connect the programming terminal to the system and run the ReSource Software. Use the I/O MONITOR function to display the four registers on the input module. If the programmer is able to monitor the inputs, the problem lies in the application software (refer to step 3). If the

- programmer cannot monitor the inputs, the problem lies in the hardware (refer to step 4).
- Step 3.** Verify that the user application program is correct.
- Registers 0 through 2 of the input module cannot be written to. If a BASIC task caused the bus error, the error log will contain the statement number in the task where the error occurred. If a control block task caused the error, you will need to search the task for any instances where you write to an input.
- Step 4.** Verify that the hardware is working correctly.
- Verify the hardware functionality by systematically swapping out modules. After each swap, if the problem is not corrected, replace the original item before swapping out the next item.
- To test local I/O, replace the input module, the processor modules (s), and finally the backplane.
- For remote I/O, determine whether the input module is the only module that is not working. If it is not, the problem most likely lies in the remote I/O system. Refer to the DC6500 Remote I/O Instruction Manual (J-3628) for additional information. If the problem does not lie in the remote I/O system, it probably involves the remote rack.
- To test the remote rack, systematically swap out the input module, the slave remote I/O module, and finally the backplane. After each swap, if the problem is not corrected, replace the original item before going on to the next swap. If none of these actions correct the problem, troubleshoot the remote I/O system.

5.3 Interrupt Problems

Problem. No interrupts at all or too many (unexpected) interrupts, signified by error codes on the screen. Note that the module must be in the same rack as the processor module that is to receive the interrupts. Go through the following steps first before going on to the more specific troubleshooting steps.

- Step 1.** Verify that the input module is in the correct slot and that the I/O definitions are correct.
- Refer to Figure 3.2. Verify that the slot number being referenced agrees with the slot number defined in the configuration task.
- Verify that the configuration task contains the proper interrupt control definitions. Refer to the example in section 4.6.
- Step 2.** Verify that the user application program is correct.
- Verify that the application program that uses the symbolic names defined in the configuration task has defined those names as COMMON.
- Compare your interrupt task with the examples given in sections 4.5.1 and 4.5.2. Make certain that the actions shown in the examples are performed in the same order in your task.

5.3.1 No Interrupts

Problem: The program does not execute, but no error codes are displayed on the processor module faceplate. If interrupts are never received by the application program and the timeout parameter in the event definition was disabled, the task will never execute.

The watchdog timer for this module should never be disabled. Before you can determine why the program did not execute, you must first set the timeout parameter in the event definition. Run the program again and proceed to section 5.3.2.

5.3.2 Hardware Event Time-Out

Problem: All tasks in the chassis are stopped and error code *12* appears on the faceplate of the processor module. The interrupt has either never occurred or is occurring at a slower frequency than the value specified in the timeout parameter in the event definition. Use the following procedure to isolate the problem.

- Step 1 Verify that the timeout value is set correctly.

 Check the value specified in the timeout parameter in the event definition. The unit is in ticks. Each tick is equal to 6.5 msec. The timeout value should be at least 2 ticks greater than the interrupt frequency. It can reasonably range up to 1.0 times the interrupt frequency.
- Step 2 Verify that the user application program is correct.

 Review the examples in section 4.5. Make certain that common mode has been enabled.
- Step 3 Verify that the hardware is working correctly.

 Systematically swap out the input module, the processor module (s), and the backplane. After each swap, if the problem is not corrected, replace the original item before swapping out the next item.

5.3.3 Hardware Event Count Limit Exceeded

Problem: All tasks in the chassis are stopped and error code *16* appears on the faceplate of the processor module. A hardware interrupt has occurred but no task is waiting. Use the following procedure to isolate the problem:

- Step 1 Verify that the user application program is correct.

 Verify that your interrupt response task contains either a 'WAIT ON event' or 'CALL SCAN_LOOP' statement that will be executed. Check carefully to determine whether a higher priority task is preventing the interrupt response task from running. Make certain that the ordering of your statements agrees with the examples in section 4.5.
- Step 2 Verify that the hardware is working correctly.

 Verify the hardware functionality by systematically swapping out the input module, the processor module (s), and the backplane. After each swap, if the problem is not corrected, replace the original item before swapping out the next item.

5.3.4 Illegal Interrupt Detected

Problem: All tasks in the chassis are stopped and error code "1F" appears on the faceplate of the processor module. A hardware interrupt has occurred but no event has been defined.

- Step 1. Verify that the user application program is correct.
- Verify that your interrupt response task contains an "EVENT" statement that will be executed. Check carefully to determine whether a higher priority task is preventing the interrupt response task from running. Make certain that the ordering of your statements agrees with the examples in section 4.5.
- Step 2. Verify that the hardware is working correctly.
- Verify the hardware functionality by systematically swapping out the input module, the processor module (s), and the backplane. After each swap, if the problem is not corrected, replace the original item before swapping out the next item.

Appendix A

Technical Specifications

Ambient Conditions

- Storage temperature: -10°C - 65°C
- Operating temperature: 0°C - 60°C
- Humidity: $\geq 90\%$ non-condensing

Maximum Module Power Dissipation

- 10 Watts

Dimensions

- Height: 11.75 inches
- Width: 1.25 inches
- Depth: 7.375 inches

System Power Requirements

- 0 Volts: 1,000 ma
- +1.2 Volts: 90 ma
- -1.2 Volts: 90 ma

Resolver Specifications


- Frequency of operation: 2000 Hz
- Minimum rotor impedance: 400 Ohms
- Transformer ratio: 26/11.0

External Strobe Minimum Trigger Time

- 1 millisecond

Appendix B

Module Block Diagram



MultiBus is a Trademark of Intel Corporation.

Appendix C

Field Connections

Pin No.	Function	Wire Color Code
1	Reference Output (+)	Brown
2	Reference Output (-)	White/Brown Stripe
3	Reference Input (+)	Red
4	Reference Input (-)	White/Red Stripe
5	Sine Input (+)	Orange
6	Sine Input (-)	White/Orange Stripe
7	Coarse Input (+)	Yellow
8	Coarse Input (-)	White/Yellow Stripe
9	External Trigger (+)	Green
10	External Trigger (-)	White/Green Stripe

Appendix D

Related Components

- 80C123-0 - Resolver (X1) (57C360)
- 80C123-3 - Resolver (X2)
- 80C123-T - Resolver (X5)
Designed for both foot-mounting and D-face mounting


80C123-2R - Resolver (X1) (57C361)

80C123-2S - Resolver (X2)

80C123-2T - Resolver (X5)
Designed for direct-coupling.

57C373 - Terminal Strip/Cable Assembly

This assembly consists of a terminal strip, cable, and mating connector. It is used to connect field signals to the backplate of the input module.



www.rpccwellautomation.com

Power, Control and Information Solutions Headquarters

Head Office: Executive, JEL South Road, South Brisbane, QLD 4104-2600, Tel: 01414 902200, Fax: 01414 382444

Group Office: Pty/Ltd/ Director/ Australia, Australia/USA and /a/ Australia 26, 2170 Bracks, Brisbane, Tel: 021 2602 000, Fax: 021 260 260

Asia Pacific: Regional, Australia, Tel: 014 100 0100, Singapore, Tel: 050 1907 000, Fax: 050 2901 010

© 2000 RPCCWELLS

Copyright © 2000 RPCCWELLS, a high technology, private U.S.A.