ElectroCraft PRO-A08V48B-SA-CAN	
Programmable Servo Drive for Step, DC, Brushless DC and AC Motors	Programmable Servo Drive
ElectroCraft Documen: Number A11225 Rev 2	Technical Reference
Electro Craft 2015	

ELECTROCRAFT

PRO-A08V48B-SA-CAN

Technical Reference

ElectroCraft Document Number A11225 Revision 2

ElectroCraft 1 Progress Drive

Dover, NH 03820

www.electrocraft.com

Read This First

While ElectroGraft believes that the information and guidance given in this manual is correct, all parties must rely upon their own skill and judgment when making use of it. ElectroGraft does not assume any liability to anyone for any loss or damage caused by any error or omission in the work, whether such error or omission is the result of negligence or any other cause. Any and all such Lability is disclaimed.

All rights reserved. No part or parts of this document may be reproduced or transmitted in any form or by any means, electrical or mechanical including photocopying, recording or by any information-retrieval system without permission in writing from ElectroGraft, Inc.

The information in this document is subject to change without notice.

About This Manual

This book is a technical reference manual for:

 PRO-A08V48B-SA-CAN hardware version 'B' Standard hardware configuration supports a differential encoder on Feedback #1. Optional hardware configuration supports linear halls on Feedback#1.

In order to operate the **PRO-A06V48** drives, you need to perform the following 3 steps:

- Step 1 Hardware installation
- Step 2 Drive setup using the ElectroCraft PROconfig software for crive commissioning.
- Step 3 Motion programming using one of the options:
 - □ A CANopen master¹
 - ⇒ The drive's buill-in motion controller executing an ElectroCraft Motion PROgramming Language (MPL) program developed using ElectroCraft MotionPRO Suite software
 - → A MPL_LIB motion library for PCs (Windows or Linux)
 - J A MPL_LIB motion library for PLCs
 - A distributed control approach which combines the above options. Like for example a host calling motion functions programmed on the drives in MPL.

This manual covers **Step 1** in detail. It describes the **PRO-A03V48B-SA-CAN** hardware including the technical data, the connectors and the wining diagrams needed for installation. The manual also presents an overview of the following steps, and includes the scaling factors between the real SI units and the crive internal units. For detailed information regarding the next steps, refer to the related documentation.

when PRO-A08V48 is set in CANopen mode.

Notational Conventions

This document uses the following conventions:

- PRO-A08V48 a l products described in this manual
- IU units Internal units of the drive
- SI units International standard units (meter for length, seconds for time, etc.)
- MPL Electrocraft Motion Program Language
- MPLCAN Electrocraft protocol for exchanging MPL commands via CAN-bus

Related Documentation

- Help Screens within the PROconfig software describes how to use PROconfig to quickly setup any ElectroCraft PRO Series drive for your application using only 2 dialogue boxes. The output of PROconfig is a set of setup data that can be downloaded into the drive EEPROM or saved on a PC file. At power-on, the drive is initialized with the setup data read from its EEPROM. With PROconfig it is also possible to retrieve the complete setup information from a drive previously programmed. PROconfig is part of the ElectroCraft Motion PRO Suite. Motion PRO Suite is available as part of a PRO Series Drive Evaluation Kit. Please contact ElectroCraft or your local ElectroCraft sales representative for more information or obtaining MotionPRO Suite or an evaluation kit.
- PRO Series CANOpen Programming Manuel (Document No. A11226) explains now to program the PRO Series family of programmable drives using CANopen protocol and describes the associated object dictionary for CiA 301 v.4.2 application layer and communication profile, CiA WD 305 v.2.2.13 layer settings services and protocols and CiA DSP 402 v3.0 device profile for drives and motion control now included in IEC 61800-7-1 Annex A, IEC 61800-7-201 and IEC 61800-7-301 standards.
- Motion Programming using ElectroCraft MotionPRO Suite (Document No. A11229) describes how to use the MotionPRO Suite to create motion programs using the ElectroCraft Motion PROgramming Language (MPL). The MotionPRO Suite platform includes PROconfig for the drive/motor setup, and a Motion Wizard for the motion programming. The Motion Wizard provides a simple, graphical way of creating motion programs and automatically generates all the MPL instructions. With MotionPRO Suite you can fully benefit from a key advantage of ElectroCraft drives – their capability to execute complex moves without requiring an external motion controller, thanks to their built-in motion controller. Motion PRO Suite is available as part of a PRO Series Drive Evaluation Kit. Please contact ElectroCraft or your local ElectroCraft sales representative for more information on obtaining MotionPRO Suite or an evaluation kit.
- MPL LIB v2.0 (Document No. A11230) explains new to program in C, C++,C#, Visual Basic or Delphi Pascal a motion application for the ElectroCraft programmable drives using ElectroCraft Document Number A11230 motion control library for PCs. The MPL LIB includes ready-to-run examples that can be executed on Windows or Linux (x86 and x64).
- PRO Series and MPL_LIB_LabVIEW Compatibility (Document No. A11231) explains how to program in LabVIEW a motion application for the ElectroCraft programmable drives using MPL_LIB_LabView v2.0 motion control library for PCs. The MPL_LIB_LabVIEW includes over 40 ready-to-run examples.

- PRO Series and PLC Siemens Series S7-300 or S7-400 (Document No. A11232) explains now to program in a PLC Siemens series S7-300 or S7-400 a motion application for the ElectroCrart programmable drives using MPL_LIB_S7 motion control library. The MPL_LIB_S7 library is IEC61131-3 compatible.
- PRO Series and PLC Omron Series MPL_LIB_CJ1 (Document No. A11233) explains how to program in a PLC Omron series CJ1 a motion application for the ElectroCraft programmable drives using MPL_LIB_CJ1 motion control library for PLCs. The MPL_LIB_CJ1 library is IEC61131-3 compatible.
- MPL_LIB_X20 (Document No. A11234) explains how to program in a PLC B&R series X20 a motion application for the ElectroCraft programmable drives using MPL_LIB_X20 motion control library for PLCs. The MPL_LIB_X20 library s IEC61131-3 compatible.
- ElectroCAN (Document No. A11235) presents ElectroCAN protocol an extension of the CANopen communication profile used for MPL commands
- QS-PRO-A0xV36 (Document No. 11235) describes the PRO A08V48 Quick Start board included in the PRO-A08V48 Evaluation Kits

If you Need Assistance ...

If you want to	Conlact ElectroCrait at
Visit ElectroCraft online	World Wide Web: www.electrocraft.com
Receive general information or assistance (see Note)	World Wide Web: <u>www.electrocraft.com</u> Email: <u>crivesupport@clectrocraft.com</u>
Ask questions about preduct operation or report suspected problems (see Note)	Tel : i1 734.662-7771 Email: <u>crivesupport@cloctrocraft.com</u>
Make suggestions about, or report errors in documentation (see Note)	Mall: FlectroCraft 1 Progress Drive Dover, NH 03820 USA

Contents

Read Th	his First	.111
1. Sa	afety information	12
1.1.	Warnings	
1.2.	Cautions	
2. Pr	oduct Overview	13
2.1.	Introduction	
2.2.	Key Features	15
2.3.	Identifying the drive hardware revision	
2.4.	Supported Motor-Sensor Configurations	
2.4.1	1. Single ended configurations.	
2.4.2	2. Dual loop contigurations	
2.5.	PRO-A08V48B-SA-CAN Drive Dimensions	
2.6.	Identification Labels	19
2.7.	Electrical Specifications	
2.7.1	1. Operating Conditions	20
2.7.2	2. Storage Conditions	
2.7.3	3. Mechanical Mounting	
2.7.4	4. Environmental Characteristics	
2.7.5	5. Logic Supply Input (+VLog)	21
2.7.6	 Motor Supply Input (+V_{MOT}) 	21
2.7.7	 Motor Outputs (A/A+, B/A-, C/B-, BR/B-) 	
2.7.8	Digital Inputs (IN0, IN1, IN2/LSP, IN3/LSN, IN5, IN6)	23
2.7.9	 Digital Outputs (OUTD, OUT1, OUT2/Error, OUT3/ Ready, OUT4) 	24
2.7.1	 Digital Hall Inputs (Hall1, Hall2, Hall3) 	24
2.7.1	 Encoder1 Inputs (A1/A1+, A1 , B1/B1+, B1 , Z1/Z1+, Z1) 	25
2.7.1	 Encoder2 Inputs (A2+/Data+, A2-/Data+, B2+/Clk+, B2-/Clk+, Z2+, Z2+) 	25
2.7.1	 Linear Hall Inputs (LH1, LH2, LH3) 	26
2.7.1	Sin Cos Encodor Inputs (Sin+, Sin , Cos+, Cos)	26
2.7.1	 Analog 05V Inputs (REF, FDBK) 	26
2.7.1	16. RS-232	27
2.7.1	17. CAN-Bus	27
2.7.1	 Supply Output (+5V) 	27
3. St	ep 1. Hardware Installation	28
3.1.	Mechanical Mounting	

3.1.1.	Vertical Mounting	
3.1.2.	Horizontal Mounting	
3.2.	Mating Connectors	
3.3.	Connectors and Connection Diagrams	
3.3.1.	Connector Layout	
3.3.2.	J1 Motor and logic supply input connector pinout	
3.3.3.	J2 Motor output and digital hall signals connector pinout	
3.3.4.	J3 Primary feedback connector pinout for the p.n. P027.214.E201	33
3.3.5.	J3 Primary feedback connector pinout for the p.n. P027.214.E701	34
3.3.6.	J4 Secondary feedback connector pinout	34
3.3.7.	J5, J6 GAN connectors pinout	
3.3.8.	J7 Digital, analog I/O and logic supply connector pinout	35
3.3.9.	J8 RS232 connector pinout	35
3.3.10). J9 Enable circuit connector piriout	35
3.3.11	. SW1 Axis ID selection switches	36
3.3.12	 SW2 Hardware Configuration selection DIP switch 	36
3.3.13	 24V Digital I/O Connection 	
3.3.14	Analog Inputs Connection	
3.3.15	5. Motor connections	41
3.3.16	6. Feedback connections	44
3.3.17	 Power Supply Connection 	52
3.3.18	8. Serial RS-232 connection	55
3.3.19). CAN-bus connection	56
3.3.20). Disabling Autorun Mode	58
3.3.21	. Installation Requirements for CE Compliance	58
3.4.	Operation Mode and Axis ID Selection	
3.4.1.	Selection of the Operation Mode	59
3.4.2.	Selection of the Axis ID	59
4. Ste	p 2. Drive Setup	60
4.1.	Installing PRO Config	
4.2.	Getting Started with PRO Config	
4.2.1.	Establish communication	61
4.2.2.	Setup drive/motor	61
4.2.3.	Selecting NPN/PNP inputs type in Setup	64
4.2.4.	Selecting the feedback source for Pulse and Direction	64
4.2.5.	Download setup data to drive/motor	64
4.2.6.	Evaluate drive/motor behavior (optional)	65
4.3.	Changing the drive Axis ID	
4.4.	Setting CANbus rate	
© Electrocraft	2015 VIII PRO-AC8V48B-SA-CAN Technical	ference

4.5.	Creating an Image File with the Setup Data	
5. S	tep 3. Motion Programming	69
5.1.	Using a CANopen Master (for PRO-A08V48 CANopen execution)	
5.1	1. CiA-301 Application Laver and Communication Profile Overview	
5.1	CiA-305 Laver Setting Services (LSS) and Protocols Overview.	
5.1	3. CiA-402 and Manufacturer Specific Device Profile Overview	
5.1	4. ElectroCAN Extension	
5.1	5. Checking Setup Data Consistency	70
5.2	Using the built-in Motion Controller and MPL	
52	1 Electrocraft Motion Program Language Overview	71
5.2	.2. Installing MotionPRO Developer	
5.2	3. Gelling Started with MotionPBO Developer	
5.2	Creating an Image File with the Setup Data and the MPL Program	
5.3.	Combining CANopen /or other host with MPI	
5.3	1. Using MPL Europians to Split Motion between Master and Drives	
5.3	2 Executing MPL programs	
5.3	Loading Automatically Cam Tables Defined in MotionPBO Developer	79
5.3	4. Customizing the Homing Procedures	
5.3	.5. Customizing the Drive Reaction to Fault Conditions	
5.4	Using Motion Libraries for PC-based Systems	81
5.5.	Using Motion Libraries for PLC-based Systems	
6. 5	caling factors	82
	Desilies usits	
6.1.	Position units	
6,1	.1. Brushless / DC prushed motor with quadrature encoder on motor	
6.1	2. Brushless motor with linear Hall signals	
6.1	 DC brushed motor with quadrature encoder on load and tacho on motor Other state of the state	82
6.1	 Step motor open loop control. No reedback device	
6.1	 Step motor open-loop control. Incremental encoder on load Deablace states it size incremental encoder on load 	83
0.1	One advariate	
6.2.	Speed units	
6.2	.1. Brushless / DC brushed motor with quadrature encoder on motor	85
6.2	2. Brushless motor with linear Hall signals	
6.2	 DC brushed motor with quadrature encoder on load and tacho on motor DC brushed motor with the transmitter of the second second	
6.2	.4. DC brushed motor with tacho on motor	
6.2	.5. Step motor open-loop control. No feedback device	
6.2	 Step motor closed-loop control. Incremental encoder on motor 	
6,2	Brushless motor with sine/cosine encoder on motor	

6.3.	Acceleration units	
6.3.1	Brushless / DC brushed motor with quadrature encoder on motor	88
6.3.2	Brushless motor with linear Hall signals	
6.3.3	DC brushed motor with guadrature encoder on load and tacho on motor	
6.3.4	Step motor open-loop control. No feedback device	
6.3.5	Step motor open-loop control. Incremental encoder on load	
6.3.6	Step motor closed-loop control. Incremental encoder on motor	90
6.3.7	Brushless motor with sine/cosine encoder on motor	90
6.4.	Jerk units	
6.4.1	Brushless / DC brushed motor with quadrature encoder on motor	91
6.4.2	Brushless motor with linear Hall signals	91
6.4.3	DC brushed motor with quadrature encoder on load and tacho on motor	92
6.4.4	Step motor open-loop control. No feedback device	92
6.4.5	Step motor open-loop control. Incremental encoder on load	92
6.4.6	Step motor closed loop control. Incremental encoder on motor	93
6.4.7	Brushless motor with sine/cosine encoder on motor	93
6.5.	Current units	
6.6.	Voltage command units	
6.7.	Voltage measurement units	
6.8.	Time units	
6.9.	Master position units	
6.10.	Master speed units	
6.11.	Mator position units	
6.11.	 Brushless / DC brushed motor with guadrature encoder on motor 	
6.11.	2. Brushless motor with linear Hall signals	
6.11.	3. DC brushed motor with guadrature encoder on load and tacho on motor	
6.11.	4. Step motor open-loop control. No feedback device	
6.11.	5. Step motor open-loop control. Incremental encoder on load	96
6.11.	6. Step motor closed-loop control. Incremental encoder on motor	96
6.11.	7. Brushless motor with sine/cosine encoder on motor	96
6.12.	Motor speed units	
6.12.	1. Brushless / DC brushed motor with quadrature encoder on motor	97
6.12.	2. Brushless motor with linear Hall signals	97
6.12.	3. DC brushed motor with quadrature encoder on load and tacho on motor	97
6.12.	4. DC brushed motor with tacho on motor	
6.12. Ioad	 Step motor open-loop control. No feedback device or incremental encode 98 	ron
6.12.	Step motor closed-loop control. Incremental encoder on motor	
6.12.	Brushless motor with sine/cosine encoder on motor	99

100

1. Safety information

Read carefully the information presented in this chapter before carrying out the drive installation and setup! It is imperative to implement the safety instructions listed hereunder.

This information is intended to protect you, the drive and the accompanying equipment ouring the product operation. Incorrect handling of the drive can lead to personal injury or material damage.

Only qualified personnel may install, set up, operate and maintain the drive. A "qualified person" has the knowledge and authorization to perform tasks such as transporting, assembling, installing, commissioning and operating drives.

The following safety symbols are used in this manual:

A	WARNING!	SIGNALS A DANGER THAT MIGHT CAUSE BODILY INJURY TO THE OPERATOR. MAY INCLUDE INSTRUCTIONS TO PREVENT THIS SITUATION
\wedge	CAUTIONI	SIGNALS A DANGER FOR THE DRIVE, WHICH MIGHT DAMAGE THE PRODUCT OR OTHER EQUIPMENT. MAY INCLUDE INSTRUCTIONS TO AVOID THIS SITUATION

1.1. Warnings

A	WARNING!	TO AVOID ELECTRIC ARCING AND HAZARDS, NEVER PLUG / UNPLUG THE PRO-A08V48B-SA-CAN FROM IT'S SOCKET WHILE THE POWER SUPPLIES ARE ON I
A	WARNING!	THE DRIVE MAY HAVE HOT SURFACES DURING OPERATION.
A	WARNING!	DURING DRIVE OPERATION, THE CONTROLLED MOTOR WILL MOVE. KEEP AWAY FROM ALL MOVING PARTS TO AVOID INJURY
1.2. Ca	utions	
\mathbb{A}	CAUTION	THE POWER SUPPLIES CONNECTED TO THE DRIVE MUST COMPLY WITH THE PARAMETERS SPECIFIED IN THIS DOCUMENT
\wedge	CAUTION!	TROUBLESHOOTING AND SERVICING ARE PERMITTED ONLY FOR PERSONNEL AUTHORISED BY ELECTROCRAFT

© Electrocraft 2015

2. Product Overview

2.1. Introduction

The **PRO-A08V48B-SA-CAN** is part of a family of fully digital intelligent servo drives, based on the latest DSP technology and they offer unprecedented drive performance combined with an embedded met on controller.

Suitable for control of brushless DC, brushless AC (vector control), DC brushed motors and step motors, the PRO-A08V48B-SA-CAN drives accept as position feedback incremental encoders (quadrature or sine/cosine) and linear Halls signals.

All drives perform position, speed or torque control and work in single, mult-axis or stand-alone configurations. Thanks to the embedded motion controller, the PRO-A08V48B-SA-CAN drives combine controller, drive and PLC functionality in a single compact unit and are capable to execute complex motions without requiring intervention of an external motion controller. Using the high-level Electrodraft Motion Program Language (**MPL**) the following operations can be executed directly at crive level:

- □ Setting various motion modes (profiles, PVT, PT, electronic gearing or camming, etc.)
- Changing the motion modes and/or the motion parameters
- Executing homing secuences
- Controlling the program flow through:
 - Conditional jumps and calls of MPL functions.
 - MPL interrupts generated on pre-defined or programmable conditions (protections triggered, transitions on imit switch or capture inputs, etc.)
 - · Waits for programmed events to occur
- Hand ing of digital I/O and analogue input signals.
- Executing arithmetic and logic operations
- Performing data transfers between axes
- Controlling motion of an axis from another one via motion commands sent between axes.
- Sending commands to a group of axes (multicast). This includes the possibility to start simultaneously motion sequences on all the axes from the group.
- Synchron zing all the axes from a network.

By implementing motion sequences directly at crive level you can really distribute the intelligence between the master and the drives in complex multi-axis applications, reducing both the development time and the overall communication requirements. For example, instead of trying to command each movement of an axis, you can program the drives using MPL to execute complex motion tasks and more the master when these tasks are done. Thus, for each axis control the master job may be reduced at: calling MPL functions stored in the drive EEPHOM and waiting for a message, which contirms the MPL functions execution completion.

All PRO-A06V48B-SA-CAN drives are equipped with a ser al RS232 and a CAN 2.0B interface and can be set (hardware, via a DIP switch) to operate in 2 modes:

LI CANopen

U MPLCAN

When CANopen mode is selected, the PHO A09V48 conforms to CiA 301 v4.2 application layer and communication profile, CIA WD 305 v2.2.13 and CIA DSP 402 v3.0 device profile for drives and motion.

control, new induced in IEC 61800 7.1 Annex A, IEC 61800 7.201 and IEC 61800 7.301 standards. In this mode, the PRO-A08V48 may be controlled via a CANopen master. As a bonus, PRO-A08V48 offers a CANopen master the option to call motion sequences, written in MPL and stored in the drive EEPROM, using manufacturer specific objects (see for details par. 5.3).

When **MPLCAN** mode is selected, the PRO-A08V48 behaves as standard Electrocraft intelligent drive and conforms to Electrocraft protocol for exchanging MPL commands via CAN-bus. When MPLCAN protocol is used, it is not mandatory to have a master. Any PRO-A08V48 can be set to operate standalone, and may play the role of a master to coordinate both: network communication/ synchronization and the motion application via MPL commands sent directly to the other drives.

When higher level coordination is needed, apart from a CANopen master, the PRO A08V48 drives can a so be control edivia a PC or a PLC using one of the MPL_LIB motion libraries.

For PRO-A08V48 commissioning PRO Config or MotionPRO Developer PC applications may be used.

PRO Config is a subset of Motion PRO Developer, including only the drive setup part. The output of PRO Config is a set of setup data that can be downloaded into the drive EEPROM or saved on a PC file. At power-on, the drive is initialized with the setup data read from its EEPROM. With PRO Config it is also possible to retrieve the complete setup information from a drive previously programmed. PRO Config shall be used for drive setup in all cases where the motion commands are sent exclusively from a master. Hence neither the PRO-A08V48 MPL programming capability nor the drive camming mode is used.

MotionPRO Developer platform includes PRO Config for the drive setup, and a **Motion Wizard** for the motion programming. The Motion Wizard provides a simple, graphical way of creating motion programs and automatically generates all the MPL instructions. *With MotionPRO Developer you can fully benefit from a key advantage of Electrocraft drives – their capability to execute complex motions without requiring an external motion controller, thanks to their built-in motion controllers. MotionPRO Developer, shall be used to program motion sequences in MPL. This is the PRO-A08V48 typical operation moce when MPLCAN protocol is selected. MotionPRO Developer shall also be used with CANopen protocol, if the user wants to call MPL functions stored in the drive EEPROM or to use the camming mode. With camming mode. MotionPRO Developer offers the possibility to quickly download and test a cam profile and also to create a .sw file (see par. 5.2.4) with the cam data. The .sw file can be afterwards stored in a master and down oaded to the drive, wherever needed.*

2.2. Key Features

- Fully digital serve drive suitable for the control of retary or linear brushless, DC brush, and step motors
- Very compact design
- Sinusoidal (FOC) or trapozoidal (Hall based) control of brushless motors
- Open or closed-loop control or 2 and 3-phase steppers
- Various modes of operation, including: cyclic synchronous position; forgue, speed or position control; position or speed profiles, external analogue reference or sent via a communication bus
- Electrocraft Motion Program Language (MPL) instruction set for the definition and execution of motion sequences
- Standalone operation with stored motion sequences
- Communication:
 - RS-292 serial up to 115kbits/s
 - CAN-Bus up to 1Mbit/s
- Digital and analog I/Os:
 - 6 digital inputs: 12-36 V. programmable polarity: sourcing/NPN or sinking/PNP: 2 Limit switches and 4 general-purpose
 - 5 digital outputs: 5-36 V, with 0.5 A, sinking/NPN open-collector (Ready, Error and 9 generalpurpose)
 - 2 analogue inputs: 12 bit, 0-5V: Reference and Feedback or general purpose
 - NTC/PTC analogue Motor Temperature sensor input.
- Feedback devices (cual-loop support):

Feedback #1 devices supported:

- Incremental encoder interface (single ended or differential)
- Pulse & direction interface (single-ended) for external (master) digital reference
- Analog sin/cos encoder interface (different al 1V_{PP})
- Digital Hall sensor interface (single-ended and open collector).
- Linear Hall sensors interface²

Feedback #2 devices supported:

- Incremental encoder interface (differential)
- Pulse & direction interface (differential) for external (master) digital reference
- B SS³ / SSI encoder interface
- Various motion programming modes:
 - · Position profiles with trapezoidal or S-curve speed shape -
 - Position, Velocity, Time (PVT) 3rd order interpolation
 - Position, Time (PT) 1⁻¹ order interpolation
 - Flectronic gearing and camming.
 - 35 Homing modes
- 127 h/w selectable addresses

Differential Feedback 41 is available with the standard hardware configuration

³ Only available with the optional Linear Hals hardware conliguration

Currently in development

[©] Electrocraft 2015

- Two operation modes selectable by DIP switch:
 - CANopen conforming with CIA 301 v4.2, CIA WD 305 v2.2.13 and CIA DSP 402 v3.0
 - MPLCAN intelligent drive conforming with Electrocraft protocol for exchanging MPL commands via CAN-bus
- 16K × 16 internal SRAM memory for data acquisition.
- 16K × 16 E²ROM to store MPL programs and data.
- · PWM switching frequency up to 100kl lz
- Motor supply: 12-50V
- Logic supply: 9-36V.Separate supply is optional
- Output current: PRO-A08V48B-SA-CAN: 8A¹ continuous; 20A peak.
- Operating ambient temperature: 0-40°C (over 40°C with derating)
- Protections:
 - Short-circuit between motor phases
 - Short-circuit from motor phases to ground
 - Over-voliage
 - Under-voltage
 - Over-current
 - Over-temperature
 - Communication error
 - Control error

^{- 84} cont, with DC, step and BLDC motors (trapoznidal), 84 amplitude (5.664_{BMS}) for PMSM (sinuscidal).

2.3. Identifying the drive hardware revision

Figure 2.1 shows new to identify the PRO A08V48B SA CAN version. This manual refers to PRO-A08V48B-SA-CAN (version 'B'). If your hardware version is 'A', please referto the PRO-A08V48x-SA-CAN Technical Reference Manual with revision 1.



Figure 2.1. PRO-A08V18x-SA-CAN v 'A' and v 'B' comparison

Note 1: The hwiver, 'A' has the p.n. PRO-A08V48A-SA-CAN The hwiver, 'B' has the p.n. PRO-A08V48B-SA-CAN

Note 2: Each p.n. has its own Motion PRO software template which is not compatible with the other.

2.4. Supported Motor-Sensor Configurations

The PRO-A08V48B-SA-CAN supports the following configurations:

2.4.1. Single ended configurations

Sensor Motor	PMSM	BLDC	DC BRUSH	STEP (2-ph)	STEP (3-ph)
Incr. Encoder					
Incr. Encoder + Hall	•			-	
Analog Sin/Cos encoder	٠	-	٠		
SSI		8	•	0	1
BiSS-C'					
Linear Halls**	•			1	-
Tacho			8 . 8		
Open-loop (no sensor)		е. С		•	

"currently in development

" only with the p.n. P027.214.E701

2.4.2. Dual loop configurations

Motor type	Feedback #1	Feecback #2
РМЯМ	 Incremental encoder (angle-ended or differential) Analogue Sin/Cos encoder 	 Incremental encoder (differential) \$SI/BISS encoder
OC Brush	 Incremental encoder (angle-ended or differential) A raingue S r/Ces encoder Analogue Tacho (anly or motor) 	 Insteinental ericoder (siffarantial) SSUBISS er coder

Each defined motor type can have any combination of the supported feedbacks either on motor or onload.

Example:

-PMSM motor with Incremental encoder (from feedback #1) on motor and Incremental encoder (from feedback#2) on load

-DC brush motor with SSI anoddar (from faedback #2) on motor and S n/Cos encoder (from feedback #1) on load.



2.5. PRO-A08V48B-SA-CAN Drive Dimensions

Figure 2.2. PRO-A09V480-SA-CAN drive dimensions

All dimensions are in mm. The crawings are not to scale.

2.6. Identification Labels



Figure 2.3. PRO-A08V48B-SA-CAN Identification Labels

2.7. Electrical Specifications

All parameters measured under the following conditions (unless otherwise specified):

 $T_{aut} = 0...40^{\circ}C, V_{LOC} = 24 |V_{LOC}|V_{MOT} = 48 V_{DC} |Supplies start-up / shutdown sequence: -<u>any-</u>Load current (sinusoidal amplitude / continuous BLDC, DC, stopper) = 8A$

2.7.1. Operating Conditions

		Min.	Тур.	Max.	Unita
A maient temperature ¹	Ũ.	0		-40	°C
Amekent humidity	Non-condensing	0		90	⊠R⊧
	Altitude (referenced to sea level)	-0.1	0:2.5	2	Km
A trude / pressure*	Amblent Pressure 0 ¹ 0.75 + 1	10.0	atm		

2.7.2. Storage Conditions

		Min.	Тур.	Max.	Units
Amsiant temperature		-40		105	90
Amplent humidity	Non-condensing	0		100	55RP
A riclent Pressure		U		10.0	807
FSD capability	Not powered; applies to any accessible part			0.5	kV
(Human body model:	Original packaging			115	kV

2.7.3. Mechanical Mounting

Artiow	natural convection ³ , closed box

2.7.4. Environmental Characteristics

		Min.	Тур.	Max.	Units	
na Olaren herri harren harrinten barriaren eta	Willoud on two on moder	98	98.5 x 77 x 16.4			
Size (Length x Width x Height)	where of the trig car tester	-3.4	15 x 3.03	x 0.35	ir.co	
	With recommended mating connectors	9	8 x 85 x 1	9.5	mm	
	File for a file of the file of the former of the former of the file of the fil	-38	16 x 3, 35	×0.77	inen	
Weght	Without mating contractors		164	58	9	
James designation	ldle (na loadi		TBD			
-ower dissipation	Operating		TBD			
Efficiency	(2		96	4	-%	
Cleaning agents	Dry cleaning is recommended	Only Water- or Alcohol- bases			based	
Protection begree	According to IEO80529, JL508		IP20		+1	

Operating temperature at higher temperatures is possible with reduced current and power ratings.

⁵ PRO A08V48 can be operated in vacuum (no a trude restriction), but at altitudes over 2 500m, current and power rating are reduced due to thermal dissipation efficiency.

³ In case of forced cooling (conduction or ventilation) the maximum ambient temperature can be increased substantially.

2.7.5. Logic Supply Input (+VLOB)

	and the state of the state		Min.	Тур.	Max.	Units
Supply voltage	Nominal values		9		36	Vec
	Absolute maximum but culsice gualants Absolute maximum (duration < 10ma)	values ditve operating res parameters values surge	8 -1		40 -40	Vrc. V
Supply current	No Lond on Digital Outputs	-V ₁₀₀ - 97 1V ₁₀₀ - 129 -V ₁₀₀ - 229 -V ₁₀₀ - 409		400 300 150 90		mA

2.7.6. Motor Supply Input (+V_{MOT})

	1200000 UZ UZ UZ UZ UZ	Min.	Тур.	Max.	Units
	Nominal values	11	48	50	VLC
Supply voltage	Absolute maximum values, drive operating but outside guaranteed parameters	્ર		52	Voc
	Absolute maximum values, surger (duration $\leq 10ms)$	-		57	v
	Idle		4	5	mA
Slipply current (Operating	20	+6	-20	A
	Abaniute maximum value, shon-orosit condition (duration \leq 10ms) [†]			26	A

27.30 ²	FZ US 90 12	2201	Min.	Тур.	Max.	Units
	for DC crushed, steppers and BLDC motors with Hall based tracezoidal control				8	Ĭ
continuous	fer PMSM motors with FOC control (sin usedal amplitud	sinusoica c value)			s	A
	fer PMSM motors with FOC control (sinusoidal effective	sinusoica value)			5.66	
Motar output ourrent i peak	maximum 2.5s		-20		20	A
Short-drout: protection threshold	measurement range		±22	=26	±20	A
Short-circuit protection delay		Ĩ.	5	10		зL
On-state vertage drop	for nominal output current; including typical mating connector contact resistance			10.3	6.5	v
Otl-state leakage current			SLOD-	±0.5	±1	mA
Votor inductance (phase-to-	Becommended value, for rippio 5% of measurement range; (V _{NOT} = 48 V	Римн – 2016H2 Римн – 1016H2 Римн – 601kH2 Римн – 501kH2 Римн – 501kH2	390 150 120 80 60			н
Motor Inductance (phase-to- phase)	Absolute minimum value. limited by short-dirouit protection; -V _{H2T} - 48 V	F _{PAN} = 20 kHz F _{PAH} = 40 ldHz F _{PAH} = 60 kHz F _{PAH} = 90 kHz F _{PAH} = 90 kHz	120 40 20 15			- - - - , ин
Motor electrical time-constant (L/R)	Recommended value, for 15% current messarroment error due to ripple	Гени – 100 kHz Гени – 20 kHz Гени – 40 kHz Гени – 60 kHz Гени – 50 kHz Гени – 100 kHz	250 125 100 63 50		-	ha
Current measurement accuracy	FS = Full Scale			+4	+8	3-FS

2.7.7. Motor Outputs (A/A+, B/A-, C/B+, BR/B-)

62399 333	526N6N606	Min.	Тур.	Max.	Units
Made compliance			P	NP	30
Default state	Input flasting (wiring disconnected;		Logis	LCW	
	Logic LOW"	-36	0	2.4	÷
	Legic HIGH	7.5	24	3G	2
input voltage	Electing voltage (not connected) Absolute maximum, continuous	-36	0	- 59	V
	Absolute maximum, sarge (daration \leq 1s) †	-50		50	
	Logic "LOW": Pulled to GND	0	e		Sector
Input current	Legic HIGH	-	Ð	10	
Input frequency		0		150	kH7
Minimora polse width		3.3			зL
ESD protection	Human body model	=2			IØ

2.7.8. Digital Inputs (IN0. IN1, IN2/LSP, IN3/LSN, IN5. IN6)¹

8		Min.	Тур.	Max.	Units
Mode compliance		NPN / C	Open celle	ottor / P4	V outouts
Defaul, state	Input 'kating (wiring disconnected)		Legi	HIGH	6
	Logic 1.OW*		0	0.8	l.
	1 еди. тнісані	2	(1424		
Input voltage	Floating voltage (not connected)		3		٧
	Absolute maximum, continuous	-10		S0	
	Absolute maximum, surge (duration $\leq 18)^{\frac{1}{2}}$	-20		40	
6	Logic "LOW"; Pulled to GND		0.6	- 19 - 19	
Input current	Legic HIGH: internal 4 /KO pull-up to -3.2	0	o	5	mA
	Legic HICH; Pulled to -5V		0.15	0.2	li –
	Logic 'HIGH': Pulled to -24V		2	2.5	1i
hput frequency.		0		150	kHz
Minimum palse width		3.3			зL
FSD protection	Human body model	-2			kV

The digital inputs are software selectable as PNP or NPN © Electrograft 2015

	10			Min.	Тур.	Max.	Unils
Mada compliance	All autputs (OUTE OUT3:Ready, OUT	о лт 14)	. OUT2/Enor.	TTL / Open-collector / NPN			N 24V
	Not supplied (+V _{LDD} floating or to GND)				High-Z	(floating)	
Default state	and the second second	QUTQ,	OUT1, OUT4		Logir	: "HIGH"	
	after cower-up	GUT2/ Roady	Error, OUT3/		Logi	10W	
	Normal C	DUTO. DUTO:	OUT1. Fror, OUT4		Logic	"HIGH"	
	operation C	outa/	Ready		Logia	: LOW	
O the it with as	Legic "LOW"; output	ut curr	ent = 0.5A			3.8	1
	Legic "HIGH"; P	0U12/ Vesdy	Error, OUT3/	2.9	8	3.3	ν
	= 0, no load Cr	CUTD.	CUT1. OUT/	<u>_</u> 1	1.5	5	
	Logic fHiGH", external load to #V ₁₀₀				Yuce		
	Absolute maximum, continuous			-0.5		Vinse0.0	
	Accoute maximum	n, surg	e (duration \pm 15) [†]	- 83		Vies-1	1
	Legic LOW, sink :	синтег	t, continuous			9.5	А
	Logic LOW", sink :	curren	t, pulse ≤ 5 sec.			11	A
Onto it a unage	Logic "HIGH", sour	08	OUT2/Enar OUT3/ Beacy			2	MA
oups conert.	to GND, V _{DLT} >= 2.	.0V	OUT6, OUT1 OUT4			4	mA
	Lopic "HIGH", leakage current; external load to (V.oc; V.oc – V.oc max – 40V			C. 1	0.2	MA	
Minimum pulse width				2			μs
ESD protection	Human body model		=15			IN.	

2.7.9. Digital Outputs (OUT0, OUT1, OUT2/Error, OUT3/ Ready, OUT4)

2.7.10. Digital Hall Inputs (Hall1, Hall2, Hall3)

	12	Min.	Тур.	Max.	Units
Mode compliance		TTL / CMOS / Open-callector			il ector
Jersuit state	Input riseting (wring disconnected)		000	HIGH	
	Legic 1.CW		U	0.8	
	Logic 10GIF	Z	5		100
input voltage	Floating voltage (not connectes)		4.4		- X
	Absolute maximum, surge (duration $<$ 1S) †	-10		+15	
hand aurout	Logic 1LGW"; Pull to GND			1.2	1
input current	Logic 1HGH"; Internal 4.7Ks2 pul-up to 5	0	0	0	0.06
Minimum palse width		2			μ5
ESD protection	Human body model	5			kV

© Electrocraft 2015

972	54 98 65 45 85 -	Min.	Тур.	Мак.	Units
Single-ended mode compilarice	Leave negative inputs disconnected	TTL)	CMCS.	Open-ca	liector
	Legic LOW"		2	1.6	1
nput vollage, single-ended mode	Logic fHIGH*	1.8	, i		v
A.A+. 3'8+	Floating voltage (not connected)		3.3	2	
	Logic LOW*			1.2	Č.
hput voltage, single-ended mode Z/Z i	Logic 'HIGH'	1.4		0.025	v
	Floaling voitage (nut connected)		4.7		1 2
hput current, single, ended mode A/A+, R/B+, 7/7+	Legic (LOW); Pull to GND		5.5	6	10.5755
	Logic 'HIGH': Internal 2.2KO pul-up to -5	0	0	0	Am [
Jilferent al mode compliance	For full RS422 compliance, see ¹	TIA/EIA-422-A			Č
	Hysteresis	+0.06	+0.1	+0.2	10
hput vollage, cifferential mode	Common mode range (A+ to GND, etc.)	-7		-7	۷
hput impedance, differential	Á1- ta Á1-, B1- ta B1- Z*+ ta Z1-		1		kΩ
1. 242-01	Single-ended mode, Open-collector ² NPN	0		5	k lz
Input frequency	Differential mode, or Single-ended driven by post-pull (TTL / CMCS)	0		10	MHZ
	Single-ended mode, Open-pollector / NPN	्रम			µ.s
Minimum palse width	Differential mode, or Single-ended driven by push-pull (TTU/ SMCS)	50			r5
0.00	Absolute maximum values, continuous	- of St		+7	1000
hput vultage, any pin to GND	Absolute maximum, surge (duration \pm 1S) 1	-11		11/	V
FSD protection	Human body model	+1			kV

2.7.11. Encoder1 Inputs (A1/A1+, A1-, B1/B1+, B1-, Z1/Z1+, Z1-)

2.7.12. Encoder2 Inputs (A2+/Data+, A2-/Data-, B2+/Clk+, B2-/Clk-, Z2+, Z2-)²

2.4	280 111 280	Min.	Тур.	Max.	Units
Different al mode compliance		2	TIA:FI	A 422 A	<u>22</u>
	Hysteresis	10.06	0.1	10.2	1
laget voltage	Differential mode	-14	-00.50	14	v
-100-001000	Common-mode range (A+ to GND, etc.)	-11	6. 	14	
Input impedance, differential	A2+, 32+, 22+ A2-, 82-, 22-		150		2
Input frequency	Differential mode	0	- 9	1Q	WHz
Minimum palse width	Differential mode	50		- 220-	TIS .
CSD protocilian	Human body model	17			k∀

For full RS-422 compliance 1503 termination resistors must be connected across the differential pairs, set SW2 pins 3, 4 and 5 to ON

Encoder2 differential input pins have internal 15003 term hat on resisters connected across 25

2.7.13. Linear Hall Inputs (LH1, LH2, LH3)¹

		Min.	Тур.	Мак.	Units
	Operational range	0	0.5:4.5	4 E	2
Input voltage	Absolute maximum values continuous	-7		7	v
	Absolute maximum, surge (duration \leq 15) †	-11		+14	
Input current	Input voltage 0 +6V	-1	+0.9	-1	mА
Interpolation Resolution	Descricing on software settings		1 î	11	hrs
Frequency		0		1	KHZ
±SD protection	Human cody model	=1			KV

2.7.14. Sin-Cos Encoder Inputs (Sin+, Sin-, Cos+, Cos-)²

	18	Min.	Тур.	Max.	Units
hput vollage, cifferential	Sin to Sink Casi to Cas-		1	1.25	Mrg.
	Operational range	-1	2.5	1	
Input voltage, any pin to GND	Absolute maximum values, continuous	28.		-7	v
	Absolute maximum, surge (duration < 16) ¹	-11		+14	
	Differential, Sin- to Sin , Cos- to Cos	42	4.7		0
hput impedance	With SW2 pins 2,3 to ON		150		2
	Common-mode, to GND		2.2		kΩ
Interpolation Resolution	Depending on software settings			11	bits
Declaration	Sin-Cas interpolation	0		450	xHz
requency	Quadrature, no interpolation	0		10	MHz
±SD protection	Human body model	- 31			kV

2.7.15. Analog D...5V Inputs (REF, FDBK)

		Min.	Тур.	Max.	Units
	Operational range	0		5	1
laput voltage	Absolute maximum values, continuous	-12		+16	y.
	Absolute maximum, surge (duration \leq 15) 1			138	
Input impedance	To GND		28	-	cO.
Resolution			12		hès
Integral linearity				=2	tits
Offset error			±2	±10	bits
Gain error			-1%;	+3%	% FS ⁸
Bandwidth (3dB)	Depending on software settings	0		1	(Hz
ESD protection	Human body model	=5			kV

Available only with the Linear Halls hardware configuration Available only with the Standard Fardware configuratoin

¹ "FS" stands for 'Full Scale"

2.7.16. RS-232

	3.	Min.	Typ.	Max.	Unita	
Standards compliance		HA/EIA-232-C				
3 Inate	Depending on software settings	5630		115200	Rau d	
Short-circuit protection	אדעצע short to GND		Guaranteed		50	
ESD protocolor	Human body model	2			kV	

2.7.17. CAN-Bus

		Min.	Тур.	Max.	Units
Standards compliance		ISO11896, CiA 301v4.2, CiA 505 v2.2 13, CiA DSP402v			CiA WD 32v3.0
Bitrate	Depending on software settings	125		1000	Kb;z;
	1Mbps			25	
Bus length	500KLps			100	т
	is 250Kops			250	18
Number of GAN nodes/drives				125	6
Termination resistor	Belwiser CANH II, CAN-Lu	none on-board			20.
Node addressing	Hardware: by Hex swilch (SW1)	1 : 15 & LSS hon-comigure (CANoper); 1 :15 & 255 (MPLCAN)			(gured IN)
1000 000193211 g	Schware	1 + 127 (CANopen) 1- 25 (MPLCAN)			255
Voltage, CAN Hilor CAN le to GNU		-26		-26	v
=SD protection	Human body model	+15			KV

2.7.18. Supply Output (+5V)

		Min.	Тур.	Max.	Units
r5V output vullage	Content sourced = 500mA	4.8	5	5.2	٧
+5V output current		900	650		nA
Short-circuit protection	8		NOT protected		30
Over-voltage protection		NOT protected			
ISD protection	Human body model	21			KV

[†] Stresses beyond values listed under fabsolule maximum ratings" may cause permanent damage to the device. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.

3. Step 1. Hardware Installation

3.1. Mechanical Mounting

The PRO-A08V48B-SA-CAN drive is intended to be mounted vertically or horizontally on a metallic support using the provided mounting holes and the recommended mating connectors, as specified in chapter 3.2.

For thermal calculations, each PRO-A08V48 drive can be assumed to generate 1 Watt at idle, and up to 5 Watts (= 17 BTU/hour) worst case while driving a motor and using all digital outputs.

3.1.1. Vertical Mounting

When the PRO-A08V48B-SA-CAN is mounted vertically, its overall envelope (size) including the recommended mating connectors is shown in *Figure 3.1*. Fixing the PRO-A08V48B-SA-CAN onto a support using the provided mounting holes is strongly recommended to avoid vibration and shock problems.



Figure 3.1 Overall dimensions using recommended making connectors

The PRO-A08V48B-SA-CAN drive(s) can be cooled by natural convection. The support can be mounted horizontally or vertically.

Figure 3.2. shows the recommended spacing to assure proper airflow by natural convection, <u>in the worst</u> <u>case</u> – closed box done from a plastic (non-metal c) material with no ventilation openings.

Whenever possible, ventilation openings shall be foreseen on the top side wall or the box and at the bottom of the lateral walls. When using a horizontal support considerably larger than the size of the hosted PRO-A08V48B-SA-CAN drives, it is recommended to provide ventilation holes in the support also.

© Electrocraft 2015

Remark: In case of using a metallic box, with ventilation openings, all spacing values may be reduced substantially. With proper ventilation, keeping the air surrounding the PRO-A08V48B-SA-CAN inside the limits indicated, the spacing values may be reduced down to zero.



Figure 3.2 Recommended spacing for vertical mounting, worst case: non-metallic, closed box.

If ventilation driven by natural convection is not enough to maintain the temperature surrounding the PRO-A08V49B-SA-CAN drive(s) inside the limits indicated, then alternate forced cooling methods must be applied.

3.1.2. Horizontal Mounting

Figure 3.3 shows the recommended spacing to assure proper a rflow by natural convection, <u>in the worst case</u> – closed box done from a plastic (non-metallic) material with no ventilation openings. Whenever possible, ventilation openings shall be foreseen.

Remark: In case of using a metallic box, with ventilation openings, all spacing values may be reduced substantially. With proper ventilation, keeping the air surrounding the PHO A08V488 SA CAN inside the limits indicated, the spacing values may be reduced down to the mechanical tolerance limits of Figure 3.1.



Figure 3.3 Recommended spacing for nonzontal mounting, worst case: non-metailie, clused box

3.2. Mating Connectors

Connector	Description	Manufacturer	Part Number	Wire Gauge
J1	MINIFIT JR. receptacle nousing, 2x2 way	MOLEX	39 03 9042	AWG 18 20
J2	MINIFIT JR. receptacle nousing. 2x5 way	MOLEX	39-03-9102	AWG 18-20
J1,J2	CRIMP PIN, MINIFIT JR., 13A	MQI FX	45750-111	AWG 18-20
	C-Grid III ^{III} Crimp Housing Dual Row, 10 Circuits, with retention	NOLEY	90142-0010	ANIC 102 04
JJ, J4	C-Grid III™ Crimp Housing Dual Row, 10 Circuits. without retention	MOLEX	90143-0010	- AWG 2224
J3, J4	C-Grid III™ Crimp Terminal	MOLEX	90119-0109	AWG 2224
J7	MICROFIT RECEPTACI E HOUSING: 2x9 WAY	MOLEX	43025-1800	AWG 2024
J5,J6,J8,J9	MICROFIT RECEPTACLE HOUSING, 2x2 WAY	MOLEX	43025-0400	AWG 2024
J5.J6.J7, J8, J9	CRIMP PIN, MICROFIT, SA	MOLEX	43030-0007	AWG 2024

3.3. Connectors and Connection Diagrams

3.3.1. Connector Layout



Figure 3.4. PRO-A08V48B-SA-CAN onlye connectors

3.3.2. J1 Motor and logic supply input connector pinout

Ċ¢	onnect	or descri	ption	
-	Pin	Name	Туре	Description
	1	GND		Negative return (ground) of the power supply
-	2	GND		Negative return (ground) of the power supply
-	3	+VLOC	1	Positive terminal of the logic supply input 9 to 36V ₃₆ . Internally connected to 37 pin 6
	4	+VMOT	- 15-	Positive terminal of the motor supply: 11 to 50V ₀₀

3.3.3. J2 Motor output and digital hall signals connector pinout

	Pin	Name	Туре	Description
-	1.	A'A+	0	Phase A for 3-ph motors, A+ for 2-sh steppers, Motor+ for DC brush motors
	2	C/B+	0	Phase C for 3-ph motors Ballior 2-ph/stopports
	3	Hall 1	12	Digital Input Hall 1 aenagr
	4	Hall 2	- F	Digital input Hall 2 senser
N	5	Hall 3	.15	Digital input Hall Sistensor
4	6	B/A-	0	Phase B for 3 phinoto s. All for 2 phistoppers. Motor i for DC brush moto s.
	7	BR.B.	0	Brake resistor - Phase B, for stop motors
	в	GND		Negative return (ground) of the motor supply
	9	+5VoLT	0	6V curput supply - Internally generated
	10	GND	- 2	Negative return (ground) of the motor supply

3.3.4. J3 Primary feedback connector pinout for the p.n. P027.214.E201

Ç	Connector description								
	Pin	Name	Type	Description					
-	1	Z1-	1	locr encodert Z-dill, opul					
	2	Z1+	1	Incr. encoder1 Z single-ended, of Z); dFL input					
	3	81-/Cos-	1	Inor encoderf B-bih, input, or analogue encoder Cos- d H, input					
	4	BI++Cos+		Incri encoderf, 6 single-enced, or 8+ drt. Input, or shalogue encoder Cos+ dtt. input					
0	5	At- /Sin-		Incri encoderf A-citt, input, or analogue encoder Sin-citt, input					
-	6	A1+/Sin+	1	Incr. encoderf A single-enced, or An diff, input, or analogue encoder Sin- slift, input					
	7	GND		Return ground for sensors supply					
	8	Temp Mot	1	NTC/PTC input Used to read an analog temperature value					
	9	GND	2	Return ground for sensors supply					
6	10	+5Veur	0	5V pulput supply for FO usage					

Ç	Connector description							
	Pin	Name	Туре	Description				
	1	LHS / FOBK	1	Linear Tall 0 in part of Analogue input, 12-bit, 0-5V. Level to read an analogue position or speed feedback (as tache), or used as general purchase analogue input.				
-	2	Z1	1	Incritancoder1 Zisingle-ended				
	3	LH2	1	Lineer Hall Linput				
	4	81	1	Inor encodert Bisingle-enced				
2	5	LH1	- 1	Unear Hall 1 Input				
20	6	A1	1	Inor encodert Alsingle-enced				
	7	GND	18	Return ground for sensors supply				
	8	Temp Mot	1	NTC/PTC input. Used to read an analog temperature value				
	9	GND		Return ground for sensors supply				
	10	+5Vour	0	5V output supply for I/O usage				

3.3.5. J3 Primary leedback connector pinout for the p.n. P027.214.E701

3.3.6. J4 Secondary feedback connector pinout

Co	nne	ctor descripti	on	
	Pin	Name	Туре	Description
	1	Z2-	- 21 - 2	Iner encoder2 Z- diff. input; has 1600 realister between pins 1 and 2
	2	Z2+	1	Iner, encoder2 Z+ dift, input ; has 150Ω resistor between pins 1 and 2.
	3	B2-/Dir-	1/0	Incri encoder2 B- ciff, input, or Dirk or Clock- for SSI, or Master- for BISS: has 1500 resistor between pins 3 and 4
	4	B2+/Dir+/CL K+/MA+	0%	Iner encoder2 Bi-diff, input, or Biri, or Glock-, for SSL or Mestern for BiSS; has 1500 resistor between pins 3 and 4
4	5	A2- (Pulse-/ Dala-/SL-	1	Incr. encoder2 A- citr. Input, or PLise-, or Data- for SSI, or Slave- for BISS; has 1500 resistor between pins 5 and 5
	Б	A2+;Pulse+/ Data+;SL+	1	Incr. encoder2 An ciff incul, or Pulsel, or Datan for SSI, or Stavel for BiSS; has 150Ω resistor between pins 5 and 8
	7	GND	- 72 - J	Return ground for sensors supply
	ß	FDBK	1	Analogue input, 12-bit, 0-5V. Used to read an analogue position or speed leenback (as tacho), or used as general purpose analogue input; Also connected to U7 pin12.
	9	GNID	12	Bet a straine to sensors a ppty
	10	+5Vam	0	5V cultuit subbly for sensors usage

3.3.7. J5, J6 CAN connectors pinout

Connector description					
	Pin	Name	Турс	Description	
Test.	1	N.C.	37	not connected	
\$	2	GND	- 24	Return ground for CAN-Bus	
J5.	3	Can-Hi	1/0	CAN Bus besitive line (dominant high)	9
	4	Can-Lo	D'I	CAN-Bus negative line (dominant low)	

C	nneo	tor descript	ion	
	Pin	Name	Туре	Description
	1	INS	1	12-36V general-purpose digital PNP/NPN input
10.00 M	2	+5Vour	0	5V putput sapply for FO usage
	3	REF	1	Analogue input 12-bit, 0-5V. Used to read an analog previour, speed or torque reference, or used as general purpose analogue input
	4	IND	1	12-36V general-purpose digital PNP/NPN input
	5	n.c.	94. 1	rot connected
	6	IN3'LSN	1	12-36V digital PN-VNPN input. Negative limit switch input
	7	OUT2-Error	•	5-36V 0.5A, drive Error output, active low, NPN spen-collector/TTL pull-up. Also crives the red Error LED.
	В	+VLac	1	Positive terminal of the logic supply: 9 to \$6V _{EC} ; internally connected to J1 pin 5
4	B	n.c.		not connected
	10	IN6	1	12-36V general-purpose digital PNP/NPN input
	11	GND	- 92 -	Ratum ground for I-O pins
80	12	FDBK	1	Analogue input, 12-bit, 0-5V. Used to read an analogue position or speed feedback (as racho), priused as general purpose analogue input; Connected also to J4 pin 8.
- 3	13	INT	1	2-36V general-purpose digital PNP/NPN reput
	14	IN2/LSP	1	12-36V dig til PNP:NPN inpart. Positive limit switch input
	15	OUTO	0	5-36V 0.5A. general-purpose digital output, NPN oper reallector TTL pull-up
	16	OUT3/Ready	0	5-36V 0.5A, drive Ready output, active law INPN open-collector/TTL pull-up. As a drives the green Ready LED.
	17	OUT1	0	5.36V 0.5A, general purpose digital output, NPN open collector TTL pull up
- 22	16	OUT4	0	5.36V 0.5A, general purpose digita output, NPN open collecter/TTL pull up

3.3.8. J7 Digital, analog I/O and logic supply connector pinout

3.3.9. J8 RS232 connector pinout

Connector description						
	Pin	Name	Туре		Description	~
骂-	1	232TX	0	RS-282 Data Transmission		
	2	GND	<u>1</u> 2	Extrem ground for ES-282 pins		
	3	232ŘX	1	RS-232 Data Reception		
	4	GND	- 92 -	Return ground for PS-202 pins		

3.3.10. J9 Enable circuit connector pinout

Connector description			
Pin	Name	Туре	Description
1	ENA2	1	Enable circuit input? connect ENA1&ENA2 to +24V to activate motor operation
2	ENA1	1	Enable circuit input: connect ENA1&ENA2 to 124V to activate motor operation
3	GND	1	Return ground
4	GND		Return ground
	Pin 1 2 3 4	Pin Name I ENA2 2 ENA1 3 GND 4 GND	Pin Name Type I ENA2 1 2 ENA1 1 3 GND - 4 GND -
3.3.11. SW1 Axis ID selection switches

Switch description		
Switch	Position	Description
5W1	0F(15)	HAV Axis ID + 1F(15) Exception: SW1_0Axis ID = 255 when in MPLCAN and LSS Non-combjured when In CANopen.

3.3.12. SW2 Hardware Configuration selection DIP switch

witch	description		
Pin Position		Description	
1	down(ON)	Disable ENV: functionality, Cornects internally, V _{Loc} to ENA1	
2	down(ON)	Disable ENA2 functionality. Connects internally -VLoc to ENA2	
3	down(ON)	Connect an 1530 resistor between Z1+ and Z1-footback pins	
4	down(ON)	Connect an 1530 resistor between B1- and B1, feedback pins	
5	down(ON)	Connect an 1930 resistor between A1- and A1- tootback pins	
6	down(ON)	Select GANopen protoco	
	up(Off)	Select MPLCAN protocol	

3.3.13. 24V Digital VO Connection

3.3.13.1 PNP Inputs



Figure 3.5. 24V Digital PNP Inputs connection

Remarks:

- 1. The inputs are selectable as PNP/ NPN by software.
- 2. The inputs are compatible with PNP type outputs (input must receive a positive voltage value (12-36V) to change its default state)

3.3.13.2 NPN Inputs



Figure 3.6. 24V Digital NPN inputs connection

37

Remarks:

- 1. The inputs are selectable as PNP/ NPN by software.
- 2. The inputs are compatible with NPN type outputs (input must be pulled to GND to change its defaulf state)

3.3.13.3 NPN outputs



Figure 3.7. 24V Digital NPN Inputs connection

Remarks:

 The outputs are compatible with NPN type inputs (load is tied to common +V_{LOO}, output pulls to GND when active and is licating when inactive)

3.3.14. Analog Inputs Connection

3.3.14.1 0-5V Input Range



Figure 3.8. Analog inputs connection

Remark: Delault input range for analog inputs is 0+5 V for REF and FBDK. For a +/-10 V range, see Figure 3.9.

3.3.14.2 +/- 10V to 0-5V Input Range Adapter



Figure 3.9. +/-10V to 9-5V adapter

3.3.14.3 Recommendations for Analog Signals Wiring

- a) If the analogue signal source is single-ended, use a 2-wire shielded cable as follows: 1st wire connects the live signal to the drive positive input (+); 2st wire connects the signal ground to the drive negative input(-).
- b) If the analogue signal source is differential and the signal source ground is isolated from the drive GND, use a 3-wire shielded cable as follows: 1st wire connects the signal plus to the drive positive input (+); 2nd wire connects the signal minus to the drive negative input (-) and 3rd wire connects the source ground to the drive GND.
- c) If the analogue signal source is differential and the signal source ground is common with the crive GND, use a 2 wire shielded cable as follows: 1st wire connects the signal plus to the drive positive input (-); 2st wire connects the signal minus to the drive negative input (-);
- d) For all of the above cases, connect the cable shield to the drive GND and leave the other shield end unconnected to the signal source. To further increase the noise protection, use a double shielded cable with inner shield connected to drive GND and outer shield connected to the motor chassis (earth).

3.3.15. Motor connections

3.3.15.1 Brushless Motor connection



Figure 3.10. Brushless mator connection





Figure 3.11. 2 phase stop motor connection, one coil per phase -



Figure 3.12. 2-phase step motor connection, two colls per phase





Figure 3.13. S-phase step motor connection

3.3.15.4 DC Motor connection



Figure 3.14. DC Motor connection

3.3.15.5 Recommendations for motor wiring

- a) Avoid running the motor wires in parallel with other wires for a distance longer than 2 meters. If this situation cannot be avoided, use a shielded cable for the motor wires. Connect the cable shield to the PRO-A08V48 GND pin. Leave the other end disconnected.
- b) The parasitic capacitance between the motor wires must not bypass 10nF. If very long cables (tens of meters) are used, this condition may not be met. In this case, add series inductors between the PRO-A08V48 outputs and the cable. The inductors must be magnetically shelded (toroidal, for example), and must be rated for the motor surge current. Typically the necessary values are around 100 µH.
- c) A good shielding can be obtained if the motor wires are running inside a metal ic cable guide.

3.3.16. Feedback connections





Figure 3.15. Single-ended incremental encoder Feedback #1 connection



CAUTIONI DO NOT CONNECT UNTERMINATED WIRES. THEY CAUTIONI MIGHT PICK UP UNWANTED NOISE AND GIVE FALSE ENCODER READINGS. 3.3.16.2 Differential Incremental Encoder Feedback #1 Connection¹



Figure 3.16. Differential incremental encoder teedback I/1 connection

Remark: 150Ω terminators are required for long encoder cables, or noisy environments. They are available through the SW2 DIP switch.

© Electrocraft 2015

Different al Foodback #1 is not available with the Linear Halls hardware version.



3.3.16.3 Differential incremental Encoder Feedback #2 Connection

Figure 3.17. Differential incremental encoder feedback #2 connection

Remark: The Feedback #2 input has internal 150Ω terminators present in the drive. Single-ended connections are not supported



3.3.16.4 Master - Slave connection using the second incremental encoder input

Figure 3.18. Master - Slave connection using second encoder input

This type of hardware connection is useful when executing an Electronic Gearing or Camming motion, to not send the feedback data over the communication bus.

3.3.16.5 Digital Hall Connection



Figure 3.19. Digital Hall connection

3.3.16.6 Pulse and direction connection

See 4.2.4 to select Feecback #1 or #2 as the Pulse & Direction source in the software setup.

3.3.16.6.1 Single ended connection on Feedback #1



Figure 3.20. Single ended 5V Pulse & Direction Feedback #1 connection

3.3.16.6.2 Differential connection of Feedback #2



Figure 3.21. Differential (RS-422) Pulse & Direction Feedback #2 connection





Figure 3.22. SSI Foodback #P connection

Remark: The Feedback #2 input has internal 150Ω terminators present in the drive

3.3.16.8 BiSS Feedback #2 Connection¹





Remark: The Feedback #2 input has internal 150Ω torminators present in the drive

3.3.16.9 Linear Hall Feedback #1 Connection





Remark: The linear hall connection is available only on the Linear Halls hardware version of the PRO-A08V49B-SA-CAN.

Gurrently in development

© Electrocraft 2015



3.3.16.10 Sine-Cosine Analog Encoder Feedback #1 Connection

Figure 3.25. Sine-Cosine analogue encoder Feedback #1 connection

3.3.16.11 Recommendations for wiring

- a) Always connect both positive and negative signals when the position sensor is differential and provides them. Use one twisted pair for each differential group of signals as follows: A+/Sin+ with A-/Sin-/LH1, B+/Cos+ with B-/Cos-/LH2, Z+ with Z-/LH3. Use another twisted pair for the 5V supply and GND.
- b) Always use shielded cables to avoid capacitive-coupled noise when using single-ended encoders or Hall sensors with cable lengths over 1 meter. Connect the cable shield to the GND, at only one end. This point could be either the PRO-A08V48 (using the GND pin) or the encoder / motor. Do not connect the shield at both ends.
- c) If the PRO-A08V48 5V supply output is used by another device (like for example an encoder) and the connection cable is onger than 5 motors, add a decoupling capacitor near the supplied device, between the +5V and GND lines. The capacitor value can be 1...10 µF, rated at 6.3V.

3.3.17. Power Supply Connection

3.3.17.1 Supply Connection





3.3.17.2 Recommendations for Supply Wiring

The PRO-A08V48B-SA-CAN always requires two supply voltages: V_{loc} and $V_{-\alpha}$.

Use short, thick wires between the PRO-A08V48 and the motor power supply. Connect power supply wires to all the indicated pins. If the wires are longer than 2 meters, use twisted wires for the supply and ground return. For wires longer than 20 meters, acd a capacitor of at least 4,700µF (rated at an appropriate voltage) right on the terminals of the PRO-A09V48.

It is recommended to connect the negative motor supply return (GND) to the Earth protection near the power supply terminals.

3.3.17.3 Recommendations to limit over-voltage during braking

During abrupt motion brakes or reversals the regenerative energy is injected into the motor power supply. This may cause an increase of the motor supply to tage (depending on the power supply characteristics). If the voltage bypasses 53V, the drive over-voltage protection is triggered and the drive power stage is disabled. In order to avoid this situation you have 2 options:

Option 1. Add a capacitor on the motor supply big enough to absorb the overall energy flowing back to the supply. The capacitor must be rated to a voltage equal or bigger than the maximum expected overvoltage and can be sized with the formula:

$$C \ge \frac{2 \times E_{ss}}{U_{Max}^2 - U_{NOM}^2}$$

where:

 $J_{MAX} = 53V$ is the over-voltage protect on limit.

J_{NCM} is the nominal motor supply voltage

 $E_{\rm V}$ – the overall energy flowing back to the supply in Joules. In case of a rotary motor and bad, $E_{\rm V}$ can be computed with the formula:

$$E_{M} = \frac{1}{2} (J_{M} + J_{L}) \overline{\sigma}_{M}^{2} + (m_{M} + m_{L}) g(h_{intia} - h_{tinal}) - 3l_{M}^{2} R_{Pi} t_{d} - \frac{t_{d} \overline{\sigma}_{M}}{2} T_{F}$$
Kinetic energy Potential energy Copper losses Friction losses

where:

J_M – lotal rotor mertia [kgm²]

J_L - total load inertia as seen at motor shaft after transmission [kgm²]

Transformation (rad/s)

 M_v – motor mass [kg] – when motor is moving in a non-horizontal plane.

 $M_{\rm E}$ – load mass [kg] – when load is moving in a non-horizontal plane.

g - gravitational acceleration i.e. 9.8 [m/s²]

ninkiel - in tial system altitude [m]

ntinet - final system altitude [m]

 $I_{\rm W}$ – motor current during deceleration [A_{RVS}/phase]

R_{Ph}- motor phase resistance [Ω]

Id - time to decelerate [s]

T= - total friction torque as seen at motor shaft [Nm] - includes load and transmission

In case of a linear motor and load, the motor inertia J_M and the load inertia J_I will be replaced by the motor

mass and the load mass measured in [kg], the angular speed $\overline{m}_{\rm M}$ will become linear speed measured in [m/s] and the friction torque T- will become friction force measured in [N].

Option 2. Connect a brake resistor R_{BR} between phase BB/B- (J2/ pin 7) and ground (J2/ pins 8,10), and activate the software option of dynamic braking.

This option is not available when the drive is used with a step motor.

The cynamic braking option can be found in the Drive Setup dialogue within EasyMotion / PRO Config. The braking will occur when DC bus voltage increases over U_{DHAR} . This parameter (U_{DHAR}) should be adjusted depending on the nominal motor supply. Optimally (from a braking point of view), U_{BRAKE} should be a few volts above the maximum nominal supply voltage. This setting will activate the brake resistor earlier, before reaching dangerous voltages – when the over-voltage protection will stop the drive. Of course, U_{BRAKE} must always be less than U_{MAR} – the over-voltage protection threshold.

Remark: This option can be combined with an external capacitor whose value is not enough to absorb the entire regenerative energy E_V but can help reducing the brake resistor size.

Brake resistor selection

The brake resistor value must be chosen to respect the following conditions:

1. to limit the maximum current below the drive peak current $I_{\text{FEAK}}=20A_{\odot}$

2. to sustain the required braking power.

$$P_{BR} = \frac{E_{M} - \frac{1}{2}C(U_{MAX}^{2} - U_{brake}^{2})}{t_{a}}$$

where C is the capacitance on the motor supply (external), i.e.

3. to limit the average current below the drive nominal current $I_{\rm NOV}$ -8A

$$B_{BH} > \frac{P_{BR} \times t_d}{t_{CYCLE} \times l_{NOW}^2}$$

where $t_{\rm cVOID}$ is the time interval between 2 brakes in case of repetitive moves.

4. to be rated for an average power
$$P_{AV} = \frac{P_{BR} \times t_c}{t_{CYCLF}}$$
 and a peak power $P_{PEAK} = \frac{U_{MAX}^2}{R_{BR}}$

Remarks:

 $I_{\rm c} = it \frac{J_{\rm MAX}}{I_{\rm PEAK}} > \frac{U_{\rm BRAKE}^2}{2 \times {\rm PBR}} \text{ the braking power } P_{\rm AR} \text{ must be reduced by increasing either } t_i - the time to the trace of the time to the time$

decelerate or G - the external capacitor on the motor supply

2. If $\frac{P_{BR} \times I_{d}}{CYCLE \times I_{NON}^2} > \frac{U_{BRAKE}^2}{2 \times P_{BR}}$ either the braking power must be reduced (see Remark 1) or t_{CYCLE} .

- the time interval between braking cycles must be increased



WARNING!

THE BRAKE RESISTOR MAY HAVE HOT SURFACES DURING OPERATION.

3.3.18. Serial RS-232 connection

3.3.18.1 Serial RS-232 connection



Figure 3.27. Social RS-232 connection

3.3.18.2 Recommendation for wiring

- a) If the serial cable is built separately, use a 3 wire shielded cable with the shield connected to BOTH ends. Do not use the shield as GND. The ground wire (pin 2 or 4 of J8) must be included inside the shield, ike the 232Rx and 232Tx signals.
- b) Always power-off all the PRO-A08V48B-SA-CAN supplies before inserting/removing the RS-232 serial connector
- c) Do not rely on an earthed PC to provide the PRO A08V48 GND connection! The drive must be earthed through a separate circuit. Most communication problems are caused by the lack of such connection



CAUTION! DO NOT CONNECT/DISCONNECT THE RS-232 CABLE CAUTION! WHILE THE DRIVE IS POWERED ON. THIS OPERATION CAN DAMAGE THE DRIVE

3.3.19. CAN-bus connection

3.3.19.1 CAN connection





Remarks:

- 1. The CAN network requires a 120-Ohm terminator. This is not included in the drive.
- 2. CAN signels are not insulated from other PRO-A08V48 circuits.

3.3.19.2 Recommendation for wiring

- a) Build CAN network using cables with twisted wires (2 wires/pair), with CAN-H twisted together with CAN-Lo. It is recommended but not mandatory to use a shielded cable. If so, connect the shield to CND. The cable impedance must be 105 ... 135 ohms (120 ohms typical) and a capacitance below 30pl/meter.
- b) The 120Ω termination resistors must be rated at 0.2W minimum. Do not use winded resistors, which are inductive.



Figure 3.29. Multiple-Axis CAN network

Remarks:

- The axis IDs in Figure 3.29, are valid for MPLCAN mode. For CANopen mode, the highest axis ID a drive can have is 127.
- 2. Linex is the bus length defined in paragraph 2.7.17.

3.3.20. Disabling Autorun Mode

When an PHO A09V48B SA CAN is set in MPLCAN operation mode, by cerault after power on it enters automatically in *Autorum* mode. In this mode, if the drive has in its local EEPROM a valid MPL application (motion program), this is automatically executed as soon as the motor supply V_{kop}- is turned on.

In order to disable Autorun mode, there are 2 methods:

- a) Software by writing value 0x0001 in first EEPROM location at address 0x4000
- b) Hardware by temperary connecting all digital Hall inputs to GND, during the power-on for about 1 second, until the green LED is turned on, as shown in *Figure 3.30*. This option is particularly useful when it is not possible to communicate with the drive.

After the drive is set in *non-Autorun/slave* mode using 2^w method, the ^{***} method may be used to invalidate the MPL application from the EEPROM. On next power on, in absence of a valid MPL application, the drive enters in the *non-Autorun/slave* mode independently of the digital Hall inputs status.



Figure 3.30. Temporary connection during power-on to disable Autorun mode

3.3.21. Installation Requirements for CE Compliance

For EMC compliance, correct cable selection and wiring practices are mandatory. The following contains installation instructions necessary for meeting EMC requirements according to EN 61800-312004.

- Cables should not exceed 3m (9.8ft) in length without consulting factory.
- Shielded cables are mandatory for the motor, power and control cabling to the drive. The shielding suppresses interference with other devices and reduces electrical noise. The cables must be connected according to the instructions in the above wiring sections of this manual.



WARNING: This product is not intended to be used on a lowvoltage public network which supplies domestic premises. Radio frequency interference is expected if used on such a network.

3.4. Operation Mode and Axis ID Selection

3.4.1. Selection of the Operation Mode

On PRO-A08V48B-SA-CAN, the selection of the operation mode CANoper or MPLCAN is done by setting the JP1 jumper:

- CANopen mode, SW2 pin6 ON
- MPLCAN mode, SW2 pin6 OFF

3.4.2. Selection of the Axis ID

The Hardware Axis ID selection is core through the hex switch SW 1. It contains numbers from 0x0 to 0xF: Depending on SW1 position, the axis ID will be:

\$W1 position	AxişID in MPLCAN mode	AxisID in CANopen mode
0×0	255	LSS non- configured state
0x1	1	. 3
0x2	2	2
0x3	3	3
0x4	4	4
0x5	15	5
0x6	6	6
Dx7	Z	7
Dx8	8	8
0x9	9	9
0xA	10	10
0xB	11	11
0xC	12	12
OxD	13	13
0xE	14	14
0xF	15	15

Note: LSS 'non configured' state, is a state in which the drive does not have assigned an active Axis ID while connected to the CAN network. In this mode the Axis ID for RS232 communication is 255. The Axis ID can be configured via a LSS master using CiA-305 protocol, which can set and save a new unique value. While the drive has a non-configured Axis ID, it cannot communicate with other drives in the network.

4. Step 2. Drive Setup

4.1. Installing PRO Config

PRO Conlig is a PC software platform for the setup of the Electrocraft drives. PRO Config comes with an *Update via Internet tool* through which you can check if your software version is up to date, and when necessary down bad and install the latest updates.

PRO Config is installed together with **MolionPRO Developer** platform for motion programming using MPL. You will need MotionPRO Developer only if you plan to use the advanced features presented in Section 5.3.

4.2. Getting Started with PRO Config

Using PRO Config you can quickly setup a drive for your application. The drive can be connected with your PC in one of the following ways:

- Via an RS232 link, directly connected to the PC, or via an USB to RS232 adapter or using Electrocraft Ethernet to RS232 adapter, function of your PC communication interfaces:
- Via a CAN-bus link, directly connected to the PC through a PC-CAN interface, or using Electrocraft Ethernet to CAN adapter
- Via another drive from the same CAN-bus network, which is connected to the PC via one of the above options from point 1.

The output of PRO Config is a set of setup date, which can be downloaded into the drive EEPROM or saved on your PC for later use.

PRO Centig includes a set of evaluation tools like the Data Logger, the Centrol Panel and the Command-Interpreter which help you to quickly measure, check and analyze your drive commissioning.

PRO Config works with **selup** data. A **selup** contains all the information needed to configure and parameterize a Electrocraft drive. This information is preserved in the drive EEPROM in the *setup table*. The setup table is copied at power-on into the RAM memory of the drive and is used during runt me. With PRO Config it is also possible to retrieve the complete setup information from a drive previously programmed.

Note that with PRO Config you do only your drive/motor commissioning. For motion programming you have the following options:

- Use a CANopen master to control the PRO-A08V48 as a standard CANopen drive
- Use MotionPRO Developer to create and download a MPL program into the drive/motor memory.
- Use one of the MPL_LIB motion libraries to control the drives/indices from your host/master. If
 your host is a PC, MPL_LIB offers a collection of high level motion functions which can be called
 from applications written in C/C++. Visual Basic, Delphi Pascal or LabVIEW. If your host is a PLC,
 MPL_LIB offers a collection of function blocks for motion programming, which are IEC61131-3
 compatible and can be integrated in your PLC program.
- Implement on your master the MPL commands you need to send to the crives/meters using one
 of the supported communication channels. The implementation must be core according with
 Electrocraft communication protocols.
- Combine MPL programming at drive level with one of the other options (see Section 5.9)

[©] Electrocraft 2015

4.2.1. Establish communication

PRO Config starts with an empty window from where you can create a **New** setup, **Open** a previously created setup which was saved on your PC, or **Upload** the setup from the drive/motor.



Before selecting one of the above options, you need to establish the communication with the drive you want to commission. Use menu command **Communication | Setup** to check/change your PC communication estings. Press the **Help** button of the cialogue opened. Here you can find detailed information about how to setup your drive and do the connections. Power on the drive, then close the Communication | Setup dialogue with OK. If the communication is established, PRO Config displays in the status bar (the bottom line) the text "Online" plus the axis ID of your drive/motor and its firmware version. Otherwise the text displayed is "Offline" and a communication error message tells you the error type. In this case, return to the Communication | Setup dialogue, press the Help button and check troubleshoots.

Remark: When first started, PRO Config tries to communicate via RS-232 and COM1 with a drive having axis ID=255 (default communication settings). If the drive has a different axis ID and you don't know it, select in the Communication | Setup dialogue at "Axis ID of drive/motor connected to PC" the option **Autodetected**. If this drive is part of a CANbus network, use the menu command **Communication** | **Scan Network**

4.2.2. Setup drive/motor

Press New button and select your drive type.

LEDSE TOT Disconstructions	PROFESSION INVESTIGATION PROFESSION INVESSION INVESSION PROFESSION INVESSION INVESSION PROFESSION INVESSION INVESSION PROFESSION INVESSION INVESSION PROFESSION PROF	2 Pluse Support 1 Phone Theoper dicanad Motor Businese Hotary Editor acumiese Hotary Editor by Call Information by Solution by Servery Draves	Incrumental Encocky, Tacho
		(fflor	1

The selection continues with the motor technology (for example: brushless or brushed) and type of feedback device (for example: Incremental encoder, Linear Halls).

The selection opens 2 satup dialogues: or **Motor Setup** and or **Drive setup** through which you can configure and parameterize a Electrocraft drive, plus several preceitined control panels customized for the product selected.

1.4	Lass second	Martare.	
Datas Se	Suppl. Select your sites 'this is detailed. If you want to be deal to be and printing process?		Drive
(ad	I much the first and denote over model region entry. Sold and strict video in the first are the first too	75.58	Satun
No.	Provide standard weige details and standard st	1	Serop
Sec.		Televis for between Landon	- DADA
	Harris		
2-14	Humduavet 0.83 A 👻		LOI
1	Field - awai 1.1 A. y		
	Tort of the state UL-102 Hin Ar 🛛 🛨		Ah I
Fam	Plana vo danvita a divi b. 0.17 💽		
Anne	Phavindestanyticas disy 0.1 a.4 💌	8	
	vooraut - [21] 1,1257 💽 [How teta collect	
	Here est est wasau	and a second s	
	to manual encode to more the minester 5	linen 🔄 TextConnuctory	-
250	and on the stroke stroke a part of the stroke strok	Wang T	
15.00	Fri behonn volet F = at at aska ita.	aw 724 - The sum sately	-
	- Pane We	jor (a subset a share algebra of special si	-
	Torac da. E.F.I. C.F.E. E. Investe encourt	touring .	
1.000	Hosticate		
- 200	H.o. alconotation.	al-cadw	
	film -	254011-146	
	North Automatical Physics - School and de-	Robinst A	2.10
	set and a set of a se		
sul	Listeness a the red		
	Tradition of Baselouder Ho	100 M	1
	Transmission for the method of the second	der and a liter a	

In the **Motor setup** dialogue you can introduce the data of your motor and the associated sensors. Data introduction is accompanied by a series of tests having as goal to check the connections to the drive and/or to determine or validate a part of the motor and sensors parameters. In the **Drive setup** dialogue you can configure and parameterize the drive for your application. In each dialogue you will find a **Guideline Assistant**, which will guide you through the whole process of introducing and/or checking your data. Close the Drive setup dialogue with **OK** to keep all the changes regarding the motor and the drive setup.

00.0811 for the other · 1.+* 10 1. 24 * 18.40 Colour F. Berris Hesser monetrigensation and s (* 121H 100.00 graphs califies adate. Here with some could really Daministre websch Hotor Lourse. X a atomic Sector grant all all of Setup 100.00 • 1 ie. EX. 7 4 44 14.145.4 2 With making 10.0 Ξ÷ -Co. Subcreak 2 ARCI april 14 7 sc 1.14 Combi. F -1 1-5 14 8 1940 14 16 AM Conces 150 10 1 ¥ int is 3 ы a chickle state In ware bet 1.1.1.41 24 124.00.00.00.0 π Constant and water an active lights for S S LEADY C CALLY INF Ser. - nilitem Pageson of + PXX PRATE Ŀ FT 2 : 20 100 14 Chiefe. 10.00 nd-I it.m Same rith . di te Halese a with a weather of the 21 C. Albeira estituyon C. Novine Juden sizere. 310.50

4.2.3. Selecting NPN/PNP inputs type in Setup

In Drive Setup, choose the inputs type PNP or NPN.

4.2.4. Selecting the feedback source for Pulse and Direction

The Pulse and Direction feedback source can be chosen in Setup/ Drive Setup/ External reference Setup button.



Feedback #1 or Feedback #2 will be available for Pulse and Direction only if they are not already selected as primary feedback for the motor.

4.2.5. Download setup data to drive/motor



Press the **Download to Drive/Motor** button Dive/Voter to download your setup data in the drive/motor EEPROM memory in the setup table. From now on, at each power-on, the setup data is copied into the



the selup

drive/motor RAM memory which is used curing runtime. It is also possible to **Save** , data on your PC and use it in other applications.

To summarize, you can define or change the setup date in the following ways:

- create a new setup data by going through the motor and drive dialogues.
- use setup data previously saved in the PC
- upload setup data from a drive/motor EEPROM memory.

4.2.6. Evaluate drive/motor behavior (optional)

You can use the **Data Logger** or the **Control Panel** evaluation tools to quickly measure and analyze your application behavior. In case of errors like protections triggered, use the Drive Status control panel to fine the cause.

Dure the system	Entimizada Editor estevence	1.K
		Dared
Step in the second of models' group the relation and on any you want to control prefirm speed of stronger. If the	A special strategy intervention of the second secon	Lab
 International related is graphing as free an associated and the second se	Lamitor rehod	1.440
nde montanes anticipas hallour des	Ather and C. Teacher & Simmaild	Moto
2	Ditte File Serviciante assi 12 449	etup
Cerlana	-Bulling	Code tox of
M Taimiera F/-Tuble T Chierestaalings	Provisional 3	-
Dites and in parameters	Totacan (54)4 Ch of	5 5
Verser super y [24] [v [v]] [dect	Partners C. It. There is a filler	
Lucio Bai. 4 A V	Four All	- <u>1</u>
Clarent cor sole	20.5.4 Mar 200 Lat T 10.00.4 Mar 1.	
1. 0.110	T Bas and Granin	
K [33:403	₩ I2.	
1,0,12	Concercion feer die 🖂 in tee d	N 2
A anal safuts	T torothe State	
4.* (28229 silvers in 141 (2	T T T T T T T T T T T T T T T T T T T	
4 28,229	receiption of the second s	
	Active with Donnected to effort () 🐨 🖓 🖓 🖓	IF PNP
Tracia.	(Arier an Year An connection) 🐔 🗖 🖉 🖉 🚽	supplier a
Line we notify at	interested and and the second second second	
a farmer and a second sec	Transfer and the second second second second	
Kn (7-3) olege in 111 (7 💌	10-2040 0 [m]	ii <u>*</u>
Figure Pactore de la pacteristica.	- Sa, rah	
KU N/S/	19 How I denot which and C. interved 3 of the	× •
reast a	C D_DC with its associal formulation (
The second se	The Remark Converse The Walger Star (1997)	

4.3. Changing the drive Axis ID

The axis ID of an PRO-A08V48 drive can be set in 3 ways:

- Hardware (H/W) according with AxisID hexiswitch SW1 par. 3.4.2.
- Software (via Satup)- any value between 1 and 255, stored in the satup table. If the drive is in CANopen mode, a Node ID value above 127 is automatically converted into 255 and the drive is

© Electrocraft 2015

set with CAN communication in "non-configured" mode waiting for a CANopon master to configure it using CiA-305 protocol. <u>A "non-configured" drive answers only to CiA-305 commands.</u> <u>All other CANopon commands are ignored and transmission of all other CANopon messages (including boot up) is disabled</u>. In absence of a CANopon master, you can get out a crive from "non-configured" mode, by setting another axis ID between 1 and 127, from above dialogue using a serial link between the crive and the PC.

Software (via CANopen master) – using C A-305 protocol.

The axis ID is initialized at power on, using the following algorithm:

- a) If a valid setup table exists, and this setup table was created with the Axis ID Selection checkbox <u>checked</u> in the Drive Setup dialogue (see above) – with the value read from the setup table. This value can be an axis number 1 to 255 or can indicate that axis ID will be set according with the AxisID hex switch. If the crive is set in CANopen mode and the Axis ID is over 127 it is converted into 255 and the drive enters in GAN communication "LSS non-configured" mode
- b) If a valid the setup table exists, and this was created with the Axis ID Selection checkbox <u>unchecked</u> in the Drive Setup dialogue (see above) – with the last value set either from a valid setup table or by a CANopen master via CiA-305 protocol. This value can be an axis number 1 to 255 for MPLCAN. 1 to 127 for CANopen, or can indicate that axis ID will be set according with the AxisID hex switch.
- c) If the setup table is invalid, with the last value set either from a valid setup table or by a CANopenmaster via CiA-305 protocol. This value can be an axis number 1 to 255 for MPLCAN. 1 to 127 for CANopen, or can indicate that axis ID will be set according with the AxisID hex switch.
- d) If the setup table is invalid, there is no previous axis ID set from a valid setup table or by a CANopen master, according with the AxisID nex switch.

Remark: If you don't know the axis ID set in a drive, you can find it in the following way:

- a) Connect the drive via a serial BS232 link to a PC where PBO Config or MotionPBO Developer are installed
- b) With the drive powered, open PBO Config or MotionPBO Developer and check the status bar. If communication with the drive is established, the status bar displays **Online** in green and nearby the drive's Axis ID. If the status bar displays **Offline** in red, execute menu command "Communication/Setup...," and in the dialogue opened select at "Channel Type" **R\$232** and at "Axis ID of drive/motor connected to PC" the option **Autodetected**. After closing the dialogue with OK, communication with the drive shall be established and the status bar shall display the drive's Axis ID.
- c) If the access to the drive with the unknown Axis ID is difficult, but this drive is connected via CANbus with other Electrocraft drives having an easier access, connect your PC senally to one of the other drives. Use PRO Config or MotionPRO Developer menu command Communication [Scan Network to find the axis IDs of all the Electrocraft drives present in the network.

4.4. Setting CANbus rate

we Setup	
G. deine sourcest	Solid roads Life is interacts Scop DS Ø Reviser Ø No. Ø Yes Scop DS Ø State Ø Anderse Ø anderse Scop DS
Soop 1 - In the Channel months around the service when an	C Tomas E Concerculo activitado te Filcor Co He-
notice equation to the spectral rate spectra and spectral and spectral and spectral spectra.	Moto
	Dischler R State Setup
12/9hov	1 wind the
Scaladz have detected Contactor extinguity Contactor participation Contactor participation Contactor participation	Movement bit A Thomsetter II 1 a
Publica State Stat	Fr Counter on Festion entric [05] [03] <u>I</u> to note than [2] (c) <u>I</u> II to note than [2] (c) <u>I</u>
Darser moluler	Constants (20 per 2 server) (2 p 2
Kp (1.590) Ki (0.3949) Ture 4 A*	17 13 11-4-54940 25 A x 30 / 2 3
riper, order a	I dear here ware F Come et COURS CONCORE UII 2
11 [2223	Trade condex Freehier I where here him weither in Spec- Anite him (Connected and any Conference of the Specified X Anite here Outs of the contraction (Conference of the Conference of the Specified X Anite here Outs of the contraction (Conference of the Conference of the Specified X Anite here Outs of the contraction (Conference of the Conference of the Specified X Anite here Outs of the contraction (Conference of the Specified X Anite here Outs of the contraction (Conference of the Specified X Anite here Outs of the Specified X Anite here Outs of the Conference of the Specified X Anite here Outs of the Specified X Anite her
Postor carto: et	Section line velocity Regular Line III Restler volument contact - Review Line .
Kp 4/636 hangelin: 1. S 💌	[10/2/21/32] vit [2] [10/2/21/32] v =
12 2.000 -readless of 6. <th7.< th=""> <th7.< th=""> <th7.< td="" th7.<="" th7<=""><td>Statemak ⁽²⁾ Novaš algent, siletans ⁽⁴⁾ Carent and (Not 1) (2) (2) (2)</td></th7.<></th7.<></th7.<>	Statemak ⁽²⁾ Novaš algent, siletans ⁽⁴⁾ Carent and (Not 1) (2) (2) (2)
Tune 2.7 cs.	C FIEC with that services in the mining strategy in the services in the matter strategy in the services in the services in the services on the services in the services on the services in the

The PRO-A08V48 drives accept the following CAN rates: 125Kbps, 250 Kbps, 500kbps and 1Mbps. Using the Drive Setup dialogue you can choose the initial CAN rate after power on. This information is stored in the setup table The CAN rate is initialized using the following algorithm:

- a) If a valid setup table exists, and this setup table was created with the Set baud rate checkbox <u>checked</u> in the Drive Setup dialogue (see above) with the value read from the setup table. This value can be one of the above 4 values or the firmware default (F/W default) which is 500kbs.
- b) If a valid setup table exists, and this setup table was created with the Set baud rate checkbox <u>unchecked</u> in the Drive Setup dialogue (see above) – with the last value set either from a valid setup table or by a CANopen master via CIA 305 protocol
- c) If the setup table is invalid, with the last value set either from a valid setup table or by a CANopen master via CiA-305 protocol.
- d) If the setup table is invalid, there is no previous CAN rate set from a valid setup table or by a CANopen master, with f/w default value which is 500kbs

4.5. Creating an Image File with the Setup Data

Once you have validated your setup, you can create with the manu command Selup | Create EEPROM **Programmer File** a software file (with extension .aw) which contains all the setup data to write in the EEPROM of your drive.

A softwara file is a text file that can be read with any text acitor. It contains blocks of data separated by an empty row. Each block of data starts with the block start address, fo lowed by data values to place in ascending order at consecutive addresses: first data – to write at start address, second data – to write at start address + 1, etc. All the data are nexacecimal 16- bit values (maximum 4 hexadecimal digits). Each raw contains a single data value. When less then 4 hexadecimal digits are shown, the value must be right justified. For example 92 represents 0x0092.

The .aw file can be programmed into a drive:

- from a CANopen master, using the communication objects for writing data into the drive EEPROM.
- from a host PC or PLC, using the MPL_LIB functions for writing data into the drive EEPROM.
- using the FEPROM Programmer tool, which comes with PRO Config but may also be installed separately. The EEPROM Programmer was specifically designed for repetitive fast and easy programming of .sw files into the Electrocraft crives during production.

5. Step 3. Motion Programming

5.1. Using a CANopen Master (for PRO-A08V48 CANopen execution)

The PRO-A09V48 drive conforms to **CiA 301 v.4.2** application layer and communication profile. **CiA WD 305 v.2.2.13** layer settings services and protocols and **CIA DSP 402 v3.0** device profile for drives and motion control the new included in IEC 61800-7-1 Annes A, IEC 61800-7-201 and IEC 61800-7-301 standards. For details see **PRO Series CANopen Programming Manual**.

5.1.1. CiA-301 Application Layer and Communication Profile Overview

The PRO A08V49 drive accepts the following basic services and types of communication objects of the CANopen communication profile CiA301 v4.2:

Service Data Object (SDO)

Service Data Objects (SDOs) are used by CANopen master to access any object from the drive's Object Dictionary. Both expected and segmented SDO transfers are supported. SDO transfers are continued services. The SDOs are typically used for drive configuration after power-on, for PDOs mapping and for infrequent low priority communication between the CANopen master and the drives.

Process Data Object (PDO)

Process Data Objects (PDO) are used for high priority, real-time data transfers between GANopen master and the drives. The PDOs are unconfirmed services which are performed with no protocol overhead. Transmit PDOs are used to send data from the drive, and receive PDOs are used to receive on to the drive. The PRO-A08V48 accepts 4 transmit PDOs and 4 receive PDOs. The contents of the PDOs can be set according with the application needs using the dynamic PDO-mapping. This operation can be done during the drive configuration phase using SDOs.

Synchronization Object (SYNC)

The SYNC message provides the basic network clock, as the SYNC producer broadcasts the synchronization object periodically. The service is unconfirmed. The PRO A08V48 supports both SYNC consumer and producer.

Time Stamp Object (TIME)

The Time Stamp Object is supported by the PRO-A08V48 device.

Emergency Object (EMCY)

Emergency objects are triggered by the occurrence of a drive internal error situation. An emergency object is transmitted only once per 'error event'. As long as no new errors occur, the drive will not transmit further emergency objects.

Network Management Objects (NMT)

The Network Management is node oriented and follows a master-slave structure. NMT objects are used for executing NMT services. Through NMT services the drive can be initialized, started, monitored, reset or stopped. The PRO-A08V48 is a NMT slave in a CANopen network.

- Module Control Services through these unconfirmed services, the NMT master centrols the state of the drive. The following services are implemented: Start Remote Node, Stop Remote Node, Enter Pro-Operational, Reset Node, Reset Communication
- Error Control Services through these services the NMT master detects failures in a CANbased network. Both error control services defined by DS301 v4.02 are supported by the PRO-A08V48: Node Guarding (including Life Guarding) and Heartbeat.
- Bootup Service through this service, the drive indicates that it has been properly initialized and is ready to receive commands from a master

5.1.2. CiA-305 Layer Setting Services (LSS) and Protocols Overview

When used in a CANopen network, the PHO A09V48 drives accept node ID and CAN bus bit timing settings according with CiA 305 protocol. This allows a CANopen master supporting CiA WD 305 to configure each PRO-A08V48 from the network with the desired node-ID and CAN bus bit timing. CiA-305 protocol allows connecting non-configured drives to a CANopen network and performing the drives configuration on-the-fly via the CANopen master.

5.1.3. CIA-402 and Manufacturer Specific Device Profile Overview

The PRO-A08V48 supports the following CiA 402 modes of operation:

- Profile position and velocity modes
- Homing mode
- Interpolated position mode

Additional to these modes, there are also several manufacturer specific modes defined:

- External reference modes (position, speed or torque)
- Electronic gearing and camming position mode

5.1.4. ElectroCAN Extension

In order to take full advantage of the powerful Electrocraft Motion Program Language (MPL) built into the PRO-A08V48, Electrocraft has developed an extension to CANopen, called ElectroCAN through which MPL commands can be exchanged with the crives. Thanks to ElectroCAN you can inspect or reprogram any of the Electrocraft drives from a CANopen network using EastSafup or MotionPRO Developer and an RS-232 link between your PC and any of the crives.

ElectroCAN uses only identifiers outside of the range used by the default by the CANopen preceived connection set (as defined by CIA 301). Thus, ElectroCAN protocol and CANopen protocol can co-exist and communicate simultaneously on the same physical CAN bus, without disturbing each other.

5.1.5. Checking Setup Data Consistency

During the configuration phase, a CANopen master can quickly verify using the checksum objects and a reference **.sw** file (see 4.5 and 5.2.4 for details) whether the non-volatile EEPROM memory of an PRO-A08V48 drive contains the right information. If the checksum reported by the drive doesn't match with that computed from the **.sw** file, the CANopen master can download the entire **.sw** file into the drive EEPROM using the communication objects for writing data into the drive EEPROM.

5.2. Using the built-in Motion Controller and MPL

One of the key advantages of the Electrocraft drives is their capability to execute complex motions without requiring an external motion controller. This is possible because Electrocraft drives offer in a single compact package both a state of art digital drive and a powerful motion controller.

5.2.1. Electrocraft Motion Program Language Overview

Programming motion directly on a Electrocraft drive requires creating and downloading a MPL (Electrocraft Motion Program Language) program into the drive memory. The MPL allows you to:

- Set various motion modes (profiles, PVT, PT, electronic gearing or camming¹, etc.)
- Change the motion modes and/or the motion parameters
- Execute homing sequences²
- Control the program flow through:
 - Conditional jumps and calls of MPL functions.
 - MPL interrupts generated on pre-defined or programmable conditions (protections triggered, transitions on imit switch or capture inputs, etc.)
 - · Waits for programmed events to occur
- Handle digital I/O and analogue input signals
- Execute an thmetic and logic operations
- Perform data transfers between axes
- Control motion of an axis from another one via motion commands sent between axes.
- Send commands to a group of axes (multicast). This includes the possibility to start simultaneously motion sequences on all the axes from the group.
- Synchronize all the axes from a network.

In order to program a motion using MPL you need MotionPRO Developer software platform.

Octional for PHO-A08V48 CANopen execution

² The customization of the homing routines is available only for PRO-A08V48 CAN execution

71

© Electrocraft 2015
5.2.2. Installing MotionPRO Developer

MotionPRO Developer is an integrated development environment for the setup and motion programming of Electrocraft intelligent drives. It comes with an **Update via Internet tool** through which you can check if your software version is up-to-cate, and when necessary download and install the latest updates.

Once you have started the installation package, reliew its indications. After installation, use the update via internet tool to check for the latest updates.

5.2.3. Getting Started with MotionPRO Developer

Using MotionPRO Developer you can duickly do the setup and the motion programming of an Electrocraft a drive according with your application needs. The drive can be connected with your PC in one of the following ways:

- 1. Vis an RS232 link, directly connected to the PC, or vis an USB to RS232 adapter
- 2. Via a CAN-bus link, directly connected to the PC through a PC-CAN interface
- Via another drive from the same CAN-bus network, which is connected to the PC via one of the above options from point 1.

The output of the MotionPRO Developer is a set of setup data and a motion program, which can be downloaded to the drive/motor EEPROM or saved on your PC for later use.

MotionPRO Developer includes a set of evaluation tools like the Data Logger, the Control Panel and the Command Interpreter which help you to quickly develop, test, measure and analyze your motion application.

Mot on PRO Developer works with projects. A project contains one or several Applications.

Each application describes a motion system for one axis. It has 2 components: the Setup data and the **Motion** program and an associated axis number: an integer value between 1 and 255. An application may be used either to describe:

- 1. One axis in a multiple-axis system
- 2. An alternate configuration (set of parameters) for the same axis.

In the first case, each application has a different axis number corresponding to the axis ID of the drives/motors from the network. All data exchanges are cone with the drive/motor having the same address as the selected application. In the second case, all the applications have the same axis number.

The setup component contains all the information needed to configure and parameterize a Electrocraft drive. This information is preserved in the drive/motor EEPPOM in the setup table. The setup table is copied at power-on into the RAM mamory of the drive/motor and is used our ng runtime.

The motion component contains the motion sequences to do. These are described via a MPL (Electrocraft Motion Program Language) program, which is executed by the drives/motors built-in motion controller.

5.2.3.1 Create a new project

Mot onPRO Developer starts with an empty window from where you can create a new project or open a praviously created one.



When you start a new project. MotionPRO Developer automatically creates a first application. Additional applications can be added later. You can cuplicate an application or insert one defined in another project.



Press New button is to open the "New Project" dialogue. Set the axis number for your first application acual with your drive motor axis ID. The initial value proposed is 255 which is the default axis ID of the crives. Press New button and select your crive type. Depending on the product chosen, the selection may continue with the motor technology (for example: brushless or brushed) and the type of fisedback device (for example: incremental encoder).



Click on your selection. MotionPRO Developer opens the Project window where on the left side you can see the structure of a project. At beginning both the new project and its first application are named "Untitled". The application has 2 components: **S** Sotup and **M** Motion (program).



5.2.3.2 Step 2 Establish communication

If you have a drive/motor connected with your PC, new its time to check the communication. Use menu command **Communication | Setup** to check/change your PC communication settings. Press the **Help** button of the dialogue opened. Here you can find detailed information about how to setup your drive/motor and the connections. Power on the drive, then close the Communication | Setup dialogue with OK. If the communication is established. MotionPRO Developer displays in the status bar (the bottom line) the text ***Online*** plus the axis ID of your drive/motor and its firmware version. Otherwise the text displayed is ***Offline*** and a communication error message tells you the error type. In this case, return to the Communication | Setup dialogue, press the Help button and check troubleshoots.

Remark: When first started. MetionPHO Developer tries to communicate via HS 232 and COM1 with a drive having axis ID=255 (default communication settings).). If the drive has a different axis ID and you don't know it, select in the Communication | Setup dialogue at "Axis ID of drive/motor connected to PC" the option **Autodetected**. If this drive is part of a CANbus network and the PC is senally connected with another drive, use the menu command **Communication | Scan Network**.

5.2.3.3 Setup drive/motor

In the project window left side, select "S Selup", to access the setup data for your application.





Press View/Modify button were valled with this opens 2 setup dialogues: for Motor Setup and for Drive Setup (same like on PRO Config) through which you can configure and parameterize a Electrocraft drive. In the Motor setup dialogue you can introduce the data of your motor and the associated sensors. Data introduction is accompanied by a series of tests having as goal to check the connections to the crive and/or to determine or validate a part of the motor and sensors parameters. In the Drive setup dialogue you can configure and parameterize the drive for your application. In each dialogue you will find a Guideline Assistant, which will guide you through the whole process of introducing and/or checking your data.



Press the **Download to Drive/Motor** button **Drive/Motor** button **Drive/Motor Drive/Motor** button **Drive/Motor** b

To summarize, you can define or change the setup data of an application in the following ways:

- create a new setup data by going through the motor and drive dialogues.
- use setup data proviously saved in the PC
- upload setup data from a drive/motor EEPROM memory.

5.2.3.4 Program motion

In the project window left side, select "M Motion", for motion programming. This automatically activates the Motion Wizard.

Those PSC Developer	totile					
Novel Approximents	noninenten New Contr 医本面いして今く	ifenel Wendow Help I al al Ali X 10 Li	0 2 2 2 2 1			
1. L. Valie	Same 10 2,0 m 10 19 3.	CANopar 11 4 Drive Fictor				
Internet	Digital D	tus woi SRH - Stat	us Register High	SRL - Status Regis	ster Low	MER - Error Regis
Z =	r-			100	100	at is ins
te logar	1 へんめから設置きぎ合いた o 11 コ 3 8 5 15 None o la 「夢unesa					
	 Unified Application Section 					ar ige
1 1	H Malan					L D Urive
	(C) Functions					T I. Miller
2.6	Ca CAM Tables					25 Int
						+) active
9						a rapamun
2.6						F- por
						np data
2.4						TOP
1.00						
1						
1	••	** *		**		** •1
Devriy			Chine Past 255 100	D-ARRAN CAN	VAPUISIN LINES	erinaliti SenciD2016

The Motion Wizard offers you the possibility to program all the motion sequences using high level graphical dialogues which automatically generate the corresponding MPL instructions. Therefore with Motion Wizard you can develop motion programs using almost all the MPL instructions without needing to learn them. A MPL program includes a main sector, followed by the subroutines used: functions, interrupt service routines and homing precedures¹. The MPL program may also include cam tables used for electronic camming applications².

When activated, Motion Wizard adds a set of toolbar buttons in the project window just below the title. Each button opens a programming dialogue. When a programming dialogue is closed, the associated MPL instructions are automatically generated. Note that, the MPL instructions generated are not a simple.

The customization of the interrupt service routines and homing routines is available only for PRO-A06V48 CAN execution Optional for PRO-A06V48 CANopon execution

text included in a file, but a motion object. Therefore with Motion Wizard you define your motion programas a collection of motion objects.

The major advantage of encapsulating programming instructions in motion objects is that you can very easily manipulate them. For example, you can:

- Save and reuse a complete motion program or parts of it in other applications.
- Add. delete, move, copy, insert, enable or disable one or more motion objects.
- Group several motion objects and work with bigger objects that perform more complex functions.

As a starting point, push for example the leftmost Motion Wizard button - Trapezoidal profiles, and set a position or speec profile. Then press the **Run** button. At this point the following operations are done automatically:

- A MPL program is created by inserting your motion objects into a precefined template.
- The MPL program is compiled and downloaded to the drive/motor.
- The MPL program execution is started.

For learning how to send MPL commands from your host/master, using one of the communication channels and protocols supported by the drives use menu command **Application** | **Binary Code Viewer...** Using this too, you can get the exact contents of the messages to send and of those expected to be received as answers.

5.2.3.5 Evaluate motion application performances

Mot onPRO Developer includes a set of evaluation tools, like the **Data Logger**, the **Control Panel** and the **Command Interpreter** which help you to quickly measure and analyze your motion application.

5.2.4. Creating an Image File with the Setup Data and the MPL Program

Once you have validated your application, you can create with the monu command **Application | Create EEPROM Programmer File** a software file (with extension .sw) which contains all the data to write in the EEPROM of your drive. This includes both the setup data and the motion program. For details regarding the .sw file format and how it can be programmed into a drive, see paragraph 4.5

5.3. Combining CANopen /or other host with MPL

Due to its embedded motion controller, an PRO-A08V48 offers many programming solutions that may simplify a lot the task of a CANopen master. This paragraph overviews a set of advanced programming features which arise when combining MPL programming at drive level with CANopen master control. A detailed description of these advanced programming features is included in the **CANopen Programming** manual. All features presented below require usage of MotionPRO Developer as a MPL programming tool.

Remark: If you don't use the advanced features presented below you don't need MotionPHO Developer. In this case the PRO-A06V48 is treated like a standard CANopen drive, whose setup is done using PRO-Countig.

5.3.1. Using MPL Functions to Split Motion between Master and Drives

With Electrocraft intelligent drives you can really distribute the intelligence between a CANopen master and the drives in complex multi-axis applications. Instead of trying to command each step of an axis movement, you can program the drives using MPL to execute complex tasks and inform the master when these are done. Thus for each axis, the master task may be reduced at: calling MPL functions (with possibility to abort their execution) stored in the drives EEPROM and waiting for a message, which confirms the finalization of the MPL functions execution.

5.3.2. Executing MPL programs

The distributed control concept can go one step further. You may prepare and cownload into a drive a complete MPL program including functions, hom ng procedures , etc. The MPL program execution can be started by simply writing a value in a dedicated object,

5.3.3. Loading Automatically Cam Tables Defined in MotionPRO Developer

The PRO-A08V48 offers others motion modes like²: electronic gearing, electronic camming, external modes with analogue or digital reference etc. When electronic camming is used, the cam tables can be loaced in the following ways:

- a) The master downloads the cam points into the drive active RAM memory after each power on;
- b) The cam points are stored in the drive EEPROM and the master commands their copy into the active RAM memory.
- c) The cam points are stored in the drive EEPROM and during the drive initialization (transition to Ready to Switch ON status) are automatically copied from EEPROM to the active RAM

For the last 2 options the carritable(s) are defined in MotionPRO Developer and are included in the information stored in the EEPROM together with the setup data and the MPL programs/functions.

Remark: The carn tables are included in the .**sw** file generated with MotionPRO Developer. Therefore, the drives can check the carn presence in the drive EEPHOM using the same procedure as for testing of the setup data.

The custo nization of the interrupt service routines and homing routines is available only for PBO-A08V48 CAN executions
 ² Optional for the PRO-A08V48 CANopen execution

5.3.4. Customizing the Homing Procedures

The PRO-A08V48 supports all horning modes defined in CiA402 device profile, plus 4 custom based on hard stop. If needed, any of these horning modes can be customized. In order to do this you need to select the Horning Medes from your MetionPHO Developer application and in the right side to set as "User defined" one of the Horning procedures. Following this operation the selected procedure will occur under Horning Modes in a subtree, with the name *HorneX* where X is the number of the selected horning.



If you click on the *HomeX* procedure, on the right side you'll see the MPL function implementing in. The homing routine can be customized according to your application needs. It's calling name and method remain unchanged.

5.3.5. Customizing the Drive Reaction to Fault Conditions

Similarly to the homing modes, the default service routines for the MPL interrupts can be customized according to your application needs. However, as most of these routines handle the crive reaction to fault conditions, it is mandatory to keep the existent functionality while adding your application needs, in order to preserve the correct protection level of the drive. The procedure for modifying the MPL interrupts is similar with that for the homing modes.

5.4. Using Motion Libraries for PC-based Systems

A **MPL Library for PC** is a collection of high-level functions a lowing you to control from a PC a network of Electrocraft intelligent drives. It is an ideal tool for quick implementation on PCs of motion control applications with Electrocraft products.

With the MPL Motion Library functions you can: communicate with a drive / motor via any of its supported channels (RS-232, CAN-bus, etc.), send motion commands, get automatically or on request information about drive / motor status, check and modify its setup parameters, read inputs and set outputs, etc.

The MPL Motion Library can work under a Windows or Linux operating system. Implemented as a .dl/.so, it can be included in an application developed in C/C++/C#, Visual Basic, Delphi Pascal or Labview.

Using a MPL Motion Library for PC, you can focus on the main aspects of your application, while the motion programming part can be reduced to calling the appropriate functions and gatting the confirmation when the task was done.

5.5. Using Motion Libraries for PLC-based Systems

A MPL Motion Library for PLC is a collection of high-level functions and function blocks allowing you to control from a PLC the Electrocraft intelligent drives. The motion control function blocks are developed in accordance with the PLC IEC61131-3 standard and represent an ideal tool for quick implementation on PLCs of motion control applications with Electrocraft products.

With the MPL Motion Library functions you can: communicate with a drive/motor via any of its supported channels, send motion commands, get automatically or on request information about drive/motor status, check and modify its setup parameters, read inputs and set outputs, etc. Depending on the PI C type, the communication is done either cirectly with the CPU unit, or via a CANbus or RS-232 communication module.

Using a MPL Motion Library for PLC, you can focus on the main aspects of your PLC application, while the motion programming part can be reduced to calling the appropriate functions and monitoring the confirmations that the task was done.

All these blocks have been designed using the guidelines described in the PLC standards, so they can be used on any development platform that is **IEC 61136 compliant**.

6. Scaling factors

Electrocraft drives work with parameters and variables represented in the drive internal units (IU). These correspond to various signal types: position, speed, current, voltage, etc. Each type of signal has its own internal representation in IU and a specific scaling factor. This chapter presents the drive internal units and their relation with the international standard units (SI).

In order to easily identify them, each internal unit has been named after its associated signal. For example, the **position units** are the internal units for position, the **speed units** are the internal units for speed, etc.

6.1. Position units

6.1.1. Brushless / DC brushed motor with quadrature encoder on motor

The internal position units are encoder counts. The correspondence with the load position in SI units is:

Load_Post on[SI] = $\frac{2 \times \pi}{4 \times No_encoder_lines \times Tr} \times Motor_Post on[IU]$

where:

No_encoder_lines - is the rotary encoder number of thes par revolution

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

6.1.2. Brushless motor with linear Hall signals

The internal position units are counts. The motor is rotary. The resolution i.e. number of counts per revolution is programmable as a power of 2 between 512 and 8192. By default it is set at 2048 counts per turn. The correspondence with the load position in St units is:

For rotary motors:Load_Position[SI] = $\frac{2 \times \pi}{resolution \times Tr} \times Motor_Position[IU]$ For linear motors:Load_Position[SI] = $\frac{Polo_Pltch}{Tr} \times Motor_Position[IU]$

where:

resolution - is the motor position resolution

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

Pole_Pitch - s the magnetic pole pitch NN (distance expressed in [m])

6.1.3. DC brushed motor with quadrature encoder on load and tacho on motor

The internal position units are encoder counts. The meter is rotary and the transmission is rotary to rotary. The correspondence with the load position in SI units is:

Load Position[rad] $\frac{2 \times \pi}{4 \times No_encoder_lines}$ Load Position[U]

where:

No_encoder_lines - is the encoder number of lines per revolution

Silunits for position are: [rad] for a intery novement. [in] for a linear novement

6.1.4. Step motor open-loop control. No feedback device

The internal position units are motor usteps. The correspondence with the load position in SI units is:

Load Position[SI] No usteps × No steps × Tr × Motor Position[IU]

where:

No_steps - is the number of motor steps per revolution

No_usteps – is the number of microsteps per step. You can read/change this value in the "Drive Setup" d alogue from PRO Config.

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

Step mater closed-loop control. Incremental encoder on motor-

The internal position units are motor encoder counts. The correspondence with the load **position in SI** units is:

Load_Position[SI] = $\frac{2 \times \pi}{1 - No_encoder_lines \times Tr} \times Motor_Position[IU]$

where:

Ne_encoder_lines - is the motor encoder number of lines per revolution -

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

6.1.5. Step motor open-loop control. Incremental encoder on load

The internal position units are bad encoder counts. The transmission is rotary-to-rotary. The correspondence with the load position in SI units is:

Load Position[S] $\frac{2 \times n}{4 \times No_encoder_lines} \sim Load Position[IU]$

where:

No_encoder_lines -- is the rotary encoder number of lines per revolution --

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

Silurits for position are [rad] for a intery movement . [in] for a linear movement

6.1.6. Brushless motor with sine/cosine encoder on motor

The internal position units are interpolated encoder counts. The correspondence with the load position in SI units is:

For rotary motors:

 $Load_Positior[SI] = \frac{2 \times \pi}{4 \times Enc_periods \times Interpolation \times Tr} = Motor_Positior[IU]$

For linear motors:

Load_Position[SI] = <u>
Load_Position[SI]</u> =

where:

Enc_periods - is the rotary encoder number of sine/cosine periods or lines per revolution

Interpolation – is the interpolation level inside an encoder period. Its a number power of 2 between 1 an 256, 1 means no interpolation

Encoder_accuracy - is the linear encoder accuracy in [m] for one sine/cosine period

Tr + transmission ratio between the motor displacement in SI units and load displacement in SI units

6.2. Speed units

The internal speed units are internal position units / (slow loop sampling period) i.e. the position variation over one slow loop sampling period

6.2.1. Brushless / DC brushed motor with quadrature encoder on motor

The internal speed units are encoder counts / (slow loop sampling period). The correspondence with the load **speed in SI units** is:

 $Load_Speed[SI] = \frac{2 \times \pi}{4 \times No_encoder_lines \times Tr \times T} \times IV otor_Speed[IU]$

where:

No encoder lines - is the rotary encoder number of lines per revolution

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

T - is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

6.2.2. Brushless motor with linear Hall signals

The internal speed units are counts / (slow loop sampling period). The motor is rotary. The position resolution tell number of counts per revolution is programmable as a power of 2 between 512 and 8192. By default it is set at 2048 counts per turn. The correspondence with the load speed in SI units is:

For rotary motors: Load Speed(SI) $\frac{2\pi}{\text{resolution}/\text{Tr}/\text{T}}$ Motor Speed(IU)

For linear motors: Load_Speed[SI] = <u>Pole_Pitch</u> *(Motor_Speed[IU])

where:

resolution - is the motor position resolution

In - transmission ratio between the motor displacement in SI units and load displacement in SI units.

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

Pole_Pitch - is the magnetic pole pitch NN (distance expressed in [m])

6.2.3. DC brushed motor with quadrature encoder on load and tacho on motor

The internal speed units are encoder counts / (slow loop sampling period). The motor is rotary and the transmission is rotary-to-rotary. The correspondence with the load speed in St units is:

Load_Speed[SI] = $\frac{2 \times \pi}{4 \times No_encoder_lines \times T} \times Load_Speed[U]$

where:

No_encoder_lines - is the ancoder number of lines per revolution

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

6.2.4. DC brushed motor with tacho on motor

When only a tachemater is mounted on the motor shall, the internal speed units are A/D converter bits. The correspondence with the load **speed in Si units** lis:

Load_Speed[SI] = Analogue_Input_Range_ 4096 × Tacho_gain × Tr

where:

Analogue_Input_Range – is the range of the drive analogue input for feedback, expressed in [V]. You can read this value in the "Drive Info" dialogue, which can be opened from the "Drive Setup"

Tacholigain - is the tachometer gain expressed in [V/rad/s]

6.2.5. Step motor open-loop control. No feedback device

The internal speed units are motor usteps / (slow loop sampling period). The correspondence with the load **speed in SI units** is:

 $I \text{ oad Speed[SI]} = \frac{2 \times \pi}{No_\mu \text{steps} \times No_\text{steps} \times Tr \times T} \times Motor_Speed[U]}$

where:

No_steps - is the number of motor steps per revolution

No justops – is the number of microsteps per step. You can read/change this value in the "Drive Setup" dialogue from PRO Config.

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

1 – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

Step motor open-loop control. Incremental encoder on load

The internal speed units are load encoder counts / (slow loop sampling period). The transmission is rotary-to-rotary. The correspondence with the load speed in SI units is:

Load Speed[rad/s] $\frac{2 \times u}{4 \text{ No encoder lines}(T)} \times \text{Load Speed[IU]}$

where:

No encoder lines - is the rotary encoder number of lines per revolution

In - transmission ratio between the motor displacement in [rac] and load displacement in [rad] or [m]

T – is the slow loop sampling parind expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup".

83

Silurits for speed are [radis] for a rotary movement, [mis] for a linear movement

6.2.6. Step motor closed-loop control. Incremental encoder on motor

The internal speed units are motor encoder counts / (slow loop sampling period). The correspondence with the load **speed in SI units** is:

 $Load_Speed[SI] = \frac{2 \times \pi}{4 \times No_encoper_lines_Tr + 1} \times Molor_Speed[U]$

where:

No encoder lines - is the motor encoder number of lines per revolution.

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units.

T - is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup".

6.2.7. Brushless motor with sine/cosine encoder on motor

The internal speed units are interpolated encoder counts / (slow loop sampling period). The correspondence with the load speed in SI units is:

For rotary motors:

Load Speed[SI] 4 Enc periods Interpolaton×Tr×T *Motor Speed[U]

For linear motors:

where:

Enc_periods – is the retary encoder number of sine/cosine periods or lines per revolution Encoder_accuracy – is the linear encoder accuracy in [m] for one sine/cosine period

Interpolation – is the interpolation level inside an checkler period. Its a number power of 2 between 1 an 256, 1 means no interpolation

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

Silurits for speed are [radis] for a rotary inevernent , [in/s] for a linear renvement

6.3. Acceleration units

The internal acceleration units are internal position units / (slow loop sampling period)² i.e. the speed variation over one slow loop sampling period.

6.3.1. Brushless / DC brushed motor with quadrature encoder on motor

The internal acceleration units are encoder counts / (slow loop sampling period)². The correspondence with the load **acceleration in SI units** is:

Load_Acceleration[SI] = $\frac{2 \times \pi}{4 \times No_{oncoder_{int}} \cos 2r \times Tr \times T^{2}} \times Motor_Acceleration[U]$

where:

No encoder lines - is the rotary encoder number of lines per revolution

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

6.3.2. Brushless motor with linear Hall signals

The internal acceleration units are counts / (slow loop sampling period)². The motor is rotary. The position resolution tile, number of counts per revolution is programmable as a power of 2 between 512 and 8192. By default it is set at 2048 counts per turn. The correspondence with the load **acceleration in SI units'** is:

For rotary motors:

Load Acceleration[SI] $\frac{2 \times \pi}{\text{resolution} \times \text{Tr} \times \text{T}^2} \times \text{Motor Acceleration[IU]}$

For linear motors:

$$\label{eq:loss_loss} \begin{split} Load_Acceleration[SI] = \frac{Pole_Pitch}{resolution \times Tr \times T^2} \times Motor_Acceleration[IU] \end{split}$$

where:

resolution - is the motor position resolution

Tr - transmission ratio between the motor displacement in St units and load displacement in St units

T - is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

Pole_Pitch - s the magnetic pole pitch NN (distance expressed in [m])

Silurits for acceleration are [racts²] for a rotary movement, [ms²] for a linear movement

6.3.3. DC brushed motor with quadrature encoder on load and tacho on motor

The internal acceleration units are encoder counts / (slow loop sampling period)². The motor is rotary and the transmission is rotary-to-rotary. The correspondence with the load acceleration in SI units is:

Load Acceleration[SI] = $\frac{2 \times \pi}{4 \times No_encoder_0.nesx T^2} \times Load Acceleration[IU]$

where:

No_encoder_lines -- is the anooder number of lines per revolution

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

6.3.4. Step motor open-loop control. No feedback device

The internal acceleration units are motor µsteps / (slow loop sampling period)^s. The correspondence with the bad **acceleration in SI units** is:

Load Acceleraton[SI] $\frac{2 \times \pi}{N_0 \mu steps \times N_0} \times Motor Acceleraton]U]$

where:

No_steps - is the number of motor steps per revolution

No_usteps – is the number of microsteps per step. You can read/change this value in the "Drive Setup" dialogue from PRO Config.

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

6.3.5. Step motor open-loop control. Incremental encoder on load

The internal acceleration units are load encoder counts ? (slow loop sampling period)². The correspondence with the load acceleration in SI units is:

For rotary-to-rotary transmission:

Load_Acceleration[SI] = $\frac{2 \times \pi}{4 \cdot Nc_ancoder_1 \cdot nes \times T^2} \times Load_Acceleration[IU]$

For rotary-to-linear transmission:

Load Acceleration[m/s²] = $\frac{\text{Encoder_accuracy}}{T^2} \times Load$ Acceleration[IU]

where:

No_encoder_lines - is the rotary encoder number of lines per revolution .

Encoder accuracy - is the linear encoder accuracy i.e. distance in [m] between 2 pulses.

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units.

T - is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup".

6.3.6. Step motor closed-loop control. Incremental encoder on motor

The internal acceleration units are motor encoder counts / (slow loop sampling period)². The transmission is retary to rotary. The correspondence with the load **acceleration in SI units** is:

Load_Acceleration[SI] = $\frac{2 \times \pi}{4 \times No_encoder_||nes \times Tr \times T^2} \times Motor_Acceleration[IU]$

where:

No encoder lines - is the motor encoder number of lines per revolution.

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

T - is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

6.3.7. Brushless motor with sine/cosine encoder on motor

The internal acceleration units are interpolated encoder counts / (slow loop sampling period)². The correspondence with the load **acceleration in SI units**¹ is:

For rotary motors:

Load_Acceleration[SI] =
$$\frac{2 \times \pi}{4 \times \text{Enc} \text{ periods} \cdot \text{Interpolaton} \times \text{Tr} \times \text{T}^2} \times \text{Motor_Acceleration[IU]}$$

For linear motors:

Load_Acceleration[SI] = $\frac{\text{Encoder}_\text{accuracy}}{\text{Interpolator} \times \text{Tr} \times \text{T}^2} \times \text{Motor}_\text{Acceleration[II]}$

where:

End_periods - is the rotary encoder number of sine/cosine periods or lines per revolution

Encoder_accuracy - is the linear encoder accuracy in [m] for one sine/cosine period

Interpolation – is the interpolation level inside an encoder period, its a number power of 2 between * an 256, 1 means no interpolation

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

90

I – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

¹ SI units for acceleration are (rad/s²) for a rotary movement, (m/s²) for a linear movement

6.4. Jerk units

The internal jerk units are internal position units t (slow dop sampling period)³ i.e. the acceleration variation over one slow loop sampling period.

6.4.1. Brushless / DC brushed motor with quadrature encoder on motor

The internal jerk units are encoder counts *t* (slow loop sampling period)³. The correspondence with the loac jerk in SI units lis:

Load_Jerk[SI] = $\frac{2 \times \pi}{4 \times No _encoder_lines \times Ir \times T^3} \times Motor_Jerk[IU]$

where:

No encoder lines - is the rotary encoder number of lines per revolution

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

T - is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

6.4.2. Brushless motor with linear Hall signals

The internal (erk units are counts / (slow loop sampling period)³. The motor is rotary. The position resolution technomore of counts per revolution is programmable as a power of 2 between 512 and 8192. By default it is set at 2048 counts per turn. The correspondence with the load acceleration in SI units is:

For rotary motors: Load Jerk[SI] $\frac{2 \times n}{resolution \times Tr \times T^3}$ Motor Jerk[IU]

For linear motors: Load Jerk[SI] - Pole_Pitch resolution×Tr×T^s *Motor Jerk[IU]

where:

resolution - is the motor position resolution.

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

91

Pole_Pitch - s the magnetic pole pitch NN (distance expressed in [m])

Si units for jerk are [rad/s²] for a retary movement, [rnts²] for a linear movement

6.4.3. DC brushed motor with quadrature encoder on load and tacho on motor

The internal jerk units are encoder counts / (slow dop sampling period)³. The motor is rotary and the transmission is rotary-to-rotary. The correspondence with the load jerk in SI units is:

Load_Jork[SI] - ^{2 × n} ×Load_Jork[IU] 4×No_encoder_Tines×T³

where:

No_encoder_lines -- is the anopder number of lines per revolution

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup" $\,$

6.4.4. Step motor open-loop control. No feedback device

The internal jerk units are motor µsteps / (slow loop sampling period)³. The correspondence with the load **jerk in SI units**¹ is:

Load Jerk[SI] $\frac{2 \times \pi}{N_0 \text{ usteps} \times N_0 \text{ steps} \times \text{Tr} \times \text{T}^3} \times \text{Motor Jerk}[U]$

where:

No_steps - is the number of motor steps per revolution

No_usteps – is the number of microsteps per step. You can read/change this value in the "Drive Setup" dialogue from PRO Config.

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

6.4.5. Step motor open-loop control. Incremental encoder on load

The internal jerk units are load encoder counts / (slow pop sampling period)³. The transmission is relaryto-rotary. The correspondence with the load jerk in SI units is:

Load Jerk[SI] <u>4×No_encoder_lines</u>×T³×Loao_Jerk[IU]

where:

No encoder lines - is the rotary encoder number of lines per revolution.

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup".

92

Silurits for jork are [radis²] for a rotary movement, [rics²] for a linear inovement.

6.4.6. Step motor closed-loop control. Incremental encoder on motor

The internal jerk units are motor encoder counts / (slow loop sampling period)³. The correspondence with the pad jerk in SI units is:

Load Jerk[SI] - 2×× 4×No_encoder_lines<1r×1³ Motor Jerk[IU]

where:

No_encoder_lines - is the motor encoder number of lines per revolution.

Tr - transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup".

6.4.7. Brushless motor with sine/cosine encoder on motor

The internal jerk units are interpolated encoder counts / (slow loop sampling period)³. The correspondence with the load jerk in SI units is:

For retary motors:	Load	Jork[SI] -	2×3	Motor	Jerkii) I	
r or rotary notoro.			4 Enc_periods/Inte	erpolaton× Tr× T*	Motor	ocidital
For linear motors:	l cao	.lerk[SI] =	Encoder_accuracy	Motor Jerk10		
			Interpolation/ $Tr > T^2$	2007-010-01000-0200		

where:

Enc_periods – is the rotary encoder number of sine/cosine periods or lines per revolution. Encoder accuracy – is the linear encoder accuracy in [m] for one sine/cosine period Intervolution – is the intervolution tevel inside an encoder period. Its a number prover of 2 to

Interpolation – is the interpolation level inside an encoder period. Its a number power of 2 between 1 an 256, 1 means no interpolation

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

T - is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" clalogue, which can be opened from the "Drive Setup"

6.5. Current units

The internal current units refer to the motor phase currents. The correspondence with the motor currents in [A] is:

 $Current[A] = \frac{2 \times Ipeak}{65520} \times Current[IU]$

where lipeak - is the drive peak current expressed in [A]. You can read this value in the "Drive Info" dialogue, which can be opened from the "Drive Setup".

6.6. Voltage command units

The internal voltage command units refer to the voltages applied on the motor. The significance of the voltage commands as well as the scaling factors, depend on the motor type and control method used.

In case of **brushless motors** driven in **sinusoidal** mode, a field oriented vector control is performed. The voltage command is the amplitude of the sinusoidal phase voltages. In this case, the correspondence with the motor phase voltages in St units i.e. [V] is:

 $Voltagecommand[V] = \frac{1.1 \times Vdc}{65534} \times Voltagecommand[U]$

where Vdc - is the crive power supply voltage expressed in [V].

In case of **brushless** motors driven in **trapezoidal** mode, the voltage command is the voltage to apply between 2 of the motor phases, according with Hall signals values. In this case, the correspondence with the voltage applied in SI units i.e. [V] is:

 $Voltagecommand[V] = \frac{Voc}{32767} \lor Voltagecommand[U]$

This correspondence is also available for **DC brushed** motors which have the voltage command internalunits as the brushless motors driven in trapezoidal mode.

6.7. Voltage measurement units

The internal voltage measurement units refer to the drive V_{VCT} supply voltage. The correspondence with the supply voltage in [V] is:

Voltage measured[V] <u>VddVaxMeasirable</u> × Voltage measured[IU]

where VdcMaxMeasurable – is the maximum measurable DC veltage expressed in [V]. You can react this value in the "Drive Info" dialogue, which can be opened from the "Drive Setup".

Remark: the voltage measurement units occur in the scaling of the over voltage and under voltage protections and the supply voltage measurement

6.8. Time units

The internal time units are expressed in slow loop sampling periods. The correspondence with the time in [5] is:

Tim(s) - T × Tim(IU)

where T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup". For example, if T = 1ms, one second = 1000 IU.

6.9. Master position units

When the master position is sent via a communication channel, the master position units depend on the type of position sensor present on the master axis.

6.10. Master speed units

The master speed is computed in internal units (IJ) as master position units / slow loop sampling period i.e. the master position variation over one position/speed loop sampling period.

6.11. Motor position units

6.11.1. Brushless / DC brushed motor with quadrature encoder on motor

The internal motor position units are encoder counts. The correspondence with the motor **position in Si-units**¹ is:

Motor_Post or[SI] = $\frac{2 \times \pi}{4 \times No}$ encoder lines Motor_Postior[IU]

where:

No encoder lines - is the rotary encoder number of lines per revolution

6.11.2. Brushless motor with linear Hall signals

The internal motor position units are counts. The motor is rotary. The resolution i.e. number of counts per revolution is programmable as a power of 2 between 512 and 8192. By default it is set at 2048 counts per furn. The correspondence with the motor position in SI units is:

For rotary motors:Motor_Position[SI] = $\frac{2 \times \pi}{\text{resolution}} \times \text{Motor_Position[IU]}$ For linear motors:Motor_Position[SI] - $\frac{\text{Polo_P tch}}{\text{resolution}} \times \text{Motor_Position[IU]}$

where:

resolution - is the motor position resolution

Pole_Pitch - is the magnetic pole pitch NN (distance expressed in [m])

Sil units for inclor position are: [rad] for a rotary motor, [m] for a linear motor

6.11.3. DC brushed motor with quadrature encoder on load and tacho on motor

The motor pasition is not computed.

6.11.4. Step motor open-loop control. No feedback device

The internal motor position units are motor usleps. The correspondence with the motor **position in SI** units¹ is:

 $Motor_Position[S]] = \frac{2 \times \pi}{No_, usteps \times No_steps} \times Matar_Position[U]$

where:

Ne_steps - is the number of meter steps per revolution

No justeps – is the number of microsteps per step. You can read/change this value in the "Drive Setup", dialogue from PRO Config.

6.11.5. Step motor open-loop control. Incremental encoder on load

In open-loop control configurations with incremental encoder on load, the motor position is not computed.

6.11.6. Step motor closed-loop control. Incremental encoder on motor

The internal motor position units are motor encoder counts. The correspondence with the motor position in-SI units is:

Motor Position[SI]
$$\frac{2 \times n}{4 \times N_0 = ncoder_lines} \times Motor Position[IU]$$

where:

No encoder lines - is the motor encoder number of lines per revolution.

6.11.7. Brushless motor with sine/cosine encoder on motor

The internal motor position units are interpolated encoder counts. The correspondence with the motor position in SL units is:

For rotary motors:

 $Motor_Position[SI] = \frac{2 \times \pi}{4 \times Enc_periods \times Interpolation} + Motor_Position[IU]$

For linear motors:

Motor Positior[SI] - Encoder_accuracy Motor Positior[IU] Interpolation

where:

Enc_periods - is the rotary encoder number of sine/cosine periods or lines per revolution.

Interpolation – is the interpolation level inside an encoder period. Its a number power of 2 between 1 an 256.1 means no interpolation

Encoder_accuracy - is the linear encoder accuracy in [m] for one sine/cosine period

6.12. Motor speed units

6.12.1. Brushless / DC brushed motor with quadrature encoder on motor

The internal motor speed units are encoder counts / (slow loop sampling period). The correspondence, with the motor **speed in SI units** is:

For rotary motors: Motor_Speed(SI) = $\frac{2 \times \pi}{1 \times No_encoder_lines_T} \times Notor_Speed[IU]$

where:

No_encoder_lines - is the rotary encoder number of lines per revolution

 $T_{\rm e}$ is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

6.12.2. Brushless motor with linear Hall signals

The internal motor speed units are counts / (slow loop sampling period). The motor is rotary. The position resolution i.e. number of counts per revolution is programmable as a power of 2 between 512 and 8192. By default it is set at 2048 counts per turn. The correspondence with the motor speed in SI units is:

For retary metors:Motor_Speed[SI] =
$$\frac{2 \times \pi}{\text{resolution} \times T} \times \text{Motor}_Speed[U]$$
For linear metors:Motor_Speed[SI] = $\frac{\text{Pole} \cdot \text{Pitch}}{\text{resolution} \times T} \times \text{Motor}_Speed[IU]$

where:

resolution - is the motor position resolution

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

Pole_Pitch - s the magnetic pole pitch NN (distance expressed in [m])

6.12.3. DC brushed motor with quadrature encoder on load and tacho on motor

The internal motor speed units are A/D converter bits. The correspondence with the motor **speed in SI** unlis¹ is:

Motor_Speed[SI] = <u>Analogue_Input_Range</u> \ Motor_Speed[IU] 4096 | I acho_ga n

where:

Analogue_Input_Hange – is the range of the drive analogue input for feedback, expressed in [V]. You can read this value in the "Drive Info" dialogue, which can be opened from the "Drive Setup"

Tacho gain - is the tachometer gain expressed in [V/rad/s]

Shurits for minter speed are [rad/s] for a retary motol: [m/s] for a linear motor.

6.12.4. DC brushed motor with tacho on motor

The internal motor speed units are A/D converter bits. The correspondence with the motor speed in SI units is:

Motor Speed[SI] - Analogue_Input_Range 4096×Tacho gain

where:

Analogue_Input_Bange – is the range of the drive analogue input for feedback, expressed in [V]. You can read this value in the "Drive Info" dialogue, which can be opened from the "Drive Setup"

Tacho_gain - is the tachometer gain expressed in [V/rad/s]

6.12.5. Step motor open-loop control. No teedback device or incremental encoder on load

The internal motor speed units are motor µsteps / (slow loop sampling period). The correspondence with the motor **speed in Si units** is:

 $Mo.or_Speed[SI] = \frac{2 \land \pi}{No_\mu sleps \land No_sleps \land I} \land Molor_Speed[U]$

where:

No steps - is the number of motor steps per revolution.

No_usteps – is the number of microsteps per step. You can read/change this value in the "Drive Setup" dialogue from PRO Config.

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup"

6.12.6. Step motor closed-loop control. Incremental encoder on motor

The internal motor speed units are motor encoder counts / (slow loop sampling period). The correspondence with the load speed in SI units is:

Motor Speed[SI] $\frac{2 \times \pi}{4 \times No}$ encoder lines T Motor Speed[U]

where:

No_encoder_lines - is the motor encoder number of lines per revolution.

T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced" dialogue, which can be opened from the "Drive Setup".

6.12.7. Brushless motor with sine/cosine encoder on motor

The internal motor speed units are interpolated encoder counts / (slow loop sampling period). The correspondence with the motor speed in SI units is:

For rotary motors:

Motor_Speed[SI] =
$$\frac{2 \times \pi}{4 \times \text{Enc} \text{ periods} \times \text{Interpolaton} \times T} \times \text{Motor}_Speed[IU]$$

For linear motors:

where:

Enc_periods – is the rotary encoder number of sine/cosine periods or lines per revolution Encoder, accuracy – is the linear encoder accuracy in [m] for one sine/cosine period

Interpolation – is the interpolation level inside an encoder period, its a number power of 2 between 1 an 256, 1 means no interpolation

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units T – is the slow loop sampling period expressed in [s]. You can read this value in the "Advanced".

dialogue, which can be opened from the "Drive Setup"

7. Memory Map

PRO A08V49B SA CAN has 2 types of memory available for user applications: 16K×16 SRAM and 16K×16 seria E³ROM.

The SRAM memory is mapped in the address range: C000h to FFFFh. It can be used to download and run a MPL program, to save real-time data acquisitions and to keep the earn tables curing run time.

The E²ROM is mapped in the address range: 4000h to 7FFFh. It is used to keep in a non-volatile memory the MPL programs, the cam tables and the drive setup information.

Remark: MotionPRO Developer handles automatically the memory allocation for each motion application. The memory map can be accessed and modified from the main folder of each application



Figure 7.1. PRO-A08V48B-SA-CAN Memory Map

