Installing, Operating and Maintaining Regenerative FlexPak Plus D-C V+S Drive

and

Modification Kits



DRIVES

Instruction Manual D-3901-4

December, 1991



TABLE OF CONTENTS

Sec./Pa	ar. Title	Page
1	Introduction	1
1.0	General	1
2	General Controller Information	
2.0	General	
2.1	Operator's Controls	
2.2	D-C Drive Motors	
2.3	Modification Kits	
2.4	Specifications	
2.4.1	Line Frequency	
2.4.2	Voltage Tolerance	
2.4.3	Line Impedance Requirements	
2.4.4	Relay Control Circuit	
2.4.5	A-C Line Fuse Requirements	6
-		
3	Installation	
3.0	General	
3.1	Layout Guidelines	
3.2	Mounting	
3.3	Power Wiring	
3.4	Tachometer Feedback	13
3.5	Isolation Transformers	
3.6	50-Hz Operation	14
3.7	HP/Current Jumper	15
3.8	Regulation Mode Jumper	15
4	Start-Up and Adjustment	
4.0	General	
4.1	Power Off Inspection	
4.2	Motor Ground Check	
4.3	Power On Adjustments	17

Sec. /Pa	ar. Title	Page
4.3.1	Regulator Module Potentiometers	18
4.3.2	Maximum Speed (Voltage)	18
4.3.3	Minimum Speed (Voltage)	18
4.3.4	Acceleration/Deceleration Rates	18
4.3.5	Current Limit 1 and 2	19
5	Modification Kits	21
5.0	General	
5.1	Auxiliary Panel	
5.2	Dynamic Braking	
5.3	Voltage/Tachometer Follower	
5.4	Instrument Interface/Preset Speed	24
5.4.1	Installing Instrument Interface	
5.4.2	Installing Preset Speed	25
5.5	Field Supply	
5.6	Auxiliary M Contacts	
5.7	Test Meter Adapter	
5.8	Dancer Follower	
5.9	Master Isolated Reference Receiver	
5.10	Contactor Adapter	30
6	Troubleshooting	31
6.0	General	31
6.1	Wiring Errors	
6.2	A-C Line Problems	
6.3	Motor Problems	31
6.4	Mechanical	
6.5	Controller Malfunctions	31
6.6	Schematics, Diagrams	31
7	Replacement Parts	
7.0	General	45

© Copyright Reliance Electric Industrial Company Reliance and V \pm S are Trademarks of Reliance Electric Industrial Company

LIST OF FIGURES

Figure	Title	Page
1.1	Regenerative FlexPak Plus Complete Controller and Typical Motor	1
2.1	Basic Controller and Auxiliary Panel	
2.2	Regenerative FlexPak Plus Complete Controller with Modification Kits	4
3.1	Enclosure Mounting Minimum	
3.2	Distances	
3.2 3.3	Mounting and Wiring Orientations	
3.4	Mounting Dimensions	
.	System Connection Diagram	12
3.5	Feedback Connection on	
	Regulator Module	
3.6	50-Hz Resistor Removal	14
3.7	HP/Current Scaling Pins	15
4.1	Regulator Module Potentiometers	18
5.1	Pin Alignment	
5.2	Auxiliary Panel Mounting	
5.3	Dynamic Braking Kit	
5.4	Dynamic Braking Kit Installed	
5.5	Dynamic Braking Connections	
5.6		
	Voltage/Tachometer Follower	
5.7	Jumper J1	23

Figure	Title	Page
5.8	Instrument Interface Kit	24
5.9	Jumper J1, mA Pins	
5.10	Field Supply Kit	
5.11	Connecting Field Supply	26
5.12	Auxiliary M Contactor Kit	26
5.13	External Wiring, Auxiliary M	26
5.14	Test Meter Adapter	27
5.15	Dancer Follower Module	27
5.16	Jumpers J1, J2 and Resistor (R6)	28
5.17	Master Isolated Reference	
	Receiver Kit	28
5.18	Jumpers J1 and J2 on Switch	
	Receiver Module	29
5.19	Jumper J1 on Reference	
	Receiver Module	29
5.20	Connecting User-supplied M Contactor	30
6.1	Control Circuit	32
6.2	Relay Control Sequencing	32
6.3	Regulator Module Screen	33
6.4	Controller Schematic	41
6.5	Modification Kits Schematics	42, 43
6.6	Controller Technical Data	44

LIST OF TABLES

Table	Title	Page
2.A	Regenerative FlexPak Plus Features Summary	5
2.B	Specifications	
2.C	Fuse Requirements	
2.D	D-C Motor/Controller/Transformer Specifications	7
3.A	Typical Wire, Fuse Sizes	10
3.B	Tachometer Voltage Scaling	13
3.C 3.D	Reliance Electric Isolation Transformers Horsepower Calibration	

Table	Title	Page
5.A	Modification Kit Quick Reference List	22
5.B	Wire Specifications	25
5.C	Test Adapter Terminals, Readings	27
6.A	Color Coding System	32
6.B	Troubleshooting Suggestions for	
	the Basic Controller	34
6.C	Troubleshooting Suggestions for	
	the Complete Controller	37
7.A	Replacement Modules	45

Section 1 INTRODUCTION

1.0 General — This manual familiarizes the user with the Regenerative FlexPak[™] Plus D-C V★S[®] drive controller. (Refer to Figure 1.1.) It describes assembly and installation procedures, gives a general overview of operation, and contains information on troubleshooting, maintenance, the ordering of spare parts, and specifications.

The manual should be read **before** performing installation or start-up activities. Also, there are certain fundamental warnings which must be kept in mind **at all times.** These are:

DANGER

THE DRIVE SYSTEM SHOULD BE INSTALLED, ADJUSTED AND SERVICED BY QUALIFIED ELEC-TRICAL MAINTENANCE PERSONNEL FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF ALL EQUIPMENT IN THE SYSTEM. PERSONAL INJURY AND/OR EQUIPMENT DAMAGE MAY OCCUR IF INDIVIDUALS ARE NOT FAMILIAR WITH THE HAZARDS RESULTING FROM IM-PROPER OPERATION.

DANGER

CONTROLLER EQUIPMENT IS AT LINE VOLTAGE WHEN A-C POWER IS CONNECTED TO THE POWER UNIT IN THE REGENERATIVE FLEXPAK PLUS CONTROLLER. THUS, A-C POWER MUST BE REMOVED FROM THE UNIT BEFORE IT IS SAFE TO TOUCH INTERNAL PARTS OF THE CON-TROLLER. PERSONAL INJURY MAY RESULT UNLESS POWER IS REMOVED.

WARNING

THE NATIONAL ELECTRICAL CODE REQUIRES THAT AN N.E.C. APPROVED FUSED DISCON-NECT SWITCH OR CIRCUIT BREAKER BE USED AHEAD OF THE CONTROLLER AND POWER TRANSFORMER (IF USED) ON THE INCOMING A-C LINE. PERSONAL INJURY MAY RESULT IF AN EASILY ACCESSIBLE MEANS OF LINE VOLT-AGE DISCONNECTION IS NOT PROVIDED.

WARNING

DO NOT OPERATE THE REGENERATIVE FLEX-PAK PLUS CONTROLLER ON POWER SUPPLIES WITH AVAILABLE SHORT-CIRCUIT CURRENTS IN EXCESS OF 5000 AMPERES. DAMAGE TO EQUIPMENT AND PERSONAL INJURY MAY OCCUR.




Figure 1.1 — Regenerative FlexPak Plus Complete Controller and Typical Motor

Section 2 GENERAL CONTROLLER INFORMATION

2.0 General — The Regenerative FlexPak Plus D-C V \star S drive controller may be applied to single-phase d-c drive applications with ratings within the following ranges:

- From ¹/₄ to ³/₄ hp with a 115 VAC, 50/60 Hz input voltage
- From $\frac{1}{2}$ to 5 hp with a 230 VAC, 50/60 Hz input voltage

Reliance Electric d-c motors, which may be used with the controller, may be either permanent magnetic motors up to $1\frac{1}{2}$ hp or wound field (excited) motors up to 5 hp.

The controller provides power-conversion and control circuits which convert the a-c line voltage into adjustable d-c voltage in order to effectively control the drive motor.

The Regenerative FlexPak Plus controller is provided, as standard, in a chassis type configuration for panel mounting within a larger electrical enclosure. The Remote Operator Controls may then be placed on the larger enclosure's face or some distance away.

The Regenerative FlexPak Plus is available in two basic configurations: the Basic Controller and the Complete Controller (Basic Controller with Auxiliary Panel). Both the Basic Controller and the Auxiliary Panel (Figure 2.1) are

Underwriters Laboratories (U.L.) recognized. Both units, when used together (Complete Controller) are U.L. Listed.

Optional Modification Kits conveniently expand the capability of the Basic Controller and Auxiliary Panel.

The controller's features are summarized in Table 2.A.

2.1 Operator's Controls — For proper operation of the Regenerative FlexPak Plus controller, it is necessary to provide Remote Operator's Controls. Reliance Electric offers a wide variety of operator control stations which may include the following devices:

- SPEED control potentiometer (5K)
- TORQUE control potentiometer (10K)
- AUTO/MANUAL selector switch (SPDT)
- RUN/JOG selector switch (SPST)
- FORWARD/REVERSE selector switch (DPDT)

• START/STOP selector switch (pushbuttons or special) 2.2 D-C Drive Motors — Reliance Electric offers a complete power-matched drive system for the controller and the application. Thus, the choice of Reliance Electric motors assures optimum performance and unmatched single-source responsibility.




Figure 2.1 — Basic Controller and Auxiliary Panel

2.3 Modification Kits — The basic capability of the controller can be quickly and conveniently extended with the use of a variety of optional Modification Kits. (Refer to Figure 2.2.) The Basic Controller modifications are:

- Voltage/Tachometer Follower
- Instrument Interface/Preset Speed
- Field Supply (Standard on 2, 3, 5, and 7-1/2 hp controllers)
- Test Meter Adapter
- Dancer Follower
- Master Isolated Reference Receiver

- Contactor Adapter
- The Auxiliary Panel modifications are:
 - Dynamic Braking
 - Auxiliary M Contact

Complete descriptions of each Kit are given in Section 5. Refer also to Table 5.A.

2.4 Specifications — The more important specifications for the Regenerative FlexPak Plus controller are listed in Table 2.B. Refer also to Table 2.D where other ratings are indicated in relation to d-c motors of specific horsepower.




Figure 2.2 — Regenerative FlexPak Plus Complete Controller with Modification Kits

2.4.1 Line Frequency — The Regenerative FlexPak Plus controller is able to operate without modification from a single-phase power source having a frequency range from 48 to 62 Hz. However, for optimum 50-Hz operation, it is recommended that two resistors be removed from the Regulator Module. (Complete details are given at Paragraph 3.6.) If the resistors are not removed, there is a slight loss of performance.

2.4.2 Voltage Tolerance — The Regenerative FlexPak Plus controller delivers output current and voltage, as listed in Table 2.D. It will also operate within these regulation specifications even with incoming line voltage at $\pm 10\%$ of nominal.

Table 2.A

REGENERATIVE FLEXPAK PLUS FEATURES SUMMARY

CATEGORY	FEATURE
Controller Functions	 START/STOP RUN/JOG FORWARD/REVERSE Speed selection (0 to 100%) Torque selection (10 to 150%) Full four-quadrant operation with coast-to-rest on stop command standard. (Dynamic braking available as option.) 20:1 controlled-speed range by means of armature voltage control. With Auxiliary Panel specified, armature loop contactor removes power to drive motor. Isolated armature voltage and current feedback decouples armature power from operator devices and provides additional noise immunity. With tachometers specified in this manual, 0.5% or 1.0% speed regulation with a 95% load change. Operates and delivers rated output speed with specified regulation tolerance limits even with a-c line variations of ±10% of nominal rated input voltage.
Speed Regulation	 Jumper reconnectable regulator circuits which allow armature (A), or tachometer feedback (T) regulation. With voltage regulation, 3 to 5% speed regulation with 95% load change. With tachometer specified, 1% speed regulation with a 95% load change. (Tachometers are 5PY or RE-020 d-c tachometer.) With tachometer specified, 0.5% speed regulation with 95% load change. (Tachometer is BC42.)
User Adjustments	 Separately adjustable forward and reverse current limits (10 to 150% of full-load current). Adjustable maximum speed (50 to 100% of base motor speed). Adjustable minimum speed (up to 50% of base motor speed). Separately adjustable linear acceleration and deceleration rates (0.5 to 30 sec.).
Safety	 Control circuitry guards against automatic restarting of equipment after resumption of interrupted a-c incoming power. Regulator and Operator's Controls isolated from a-c line for personnel protection. Armature voltage and current feedback isolated to assure separation of power and regulator circuits. Motor thermostat protection (all horsepower ratings).
Hardware	 Conveniently located screw terminal connections for incoming a-c and outgoing d-c power allow easy cable entry and connection. With Auxiliary Panel specified, a-c line fuses protect Power Cube from armature short circuit and power relays provide positive power disconnect. Circuit breaker in armature circuit to prevent power module failure due to inverter fault. Protection from momentary surges on a-c line and from d-c load transients. D-c motor contactor for positive motor disconnection. Contactor sequencing so that contactor closes and opens at zero armature current.

2.4.3 Line Impedance Requirements — The Regenerative FlexPak Plus controller must be connected to a shortcircuit protection system designed to operate on plant power supplies with maximum permissible available symmetrical RMS fault currents of 5000 amperes. (Refer to Table 2.D.)

WARNING

DO NOT OPERATE THE REGENERATIVE FLEX-PAK PLUS CONTROLLER ON POWER SUPPLIES WITH AVAILABLE SHORT-CIRCUIT CURRENTS IN EXCESS OF 5000 AMPERES. DAMAGE TO EQUIPMENT AND PERSONAL INJURY MAY OCCUR.

2.4.4 Relay Control Circuit — The regulator board is set up for use with main contactors having a coil resistance greater than or equal to 100 ohms. The control logic sequences the contactor and the control relay on the regulator so that current flow thru the main contactor is never broken in normal operation by the contacts. Refer to Figures 6.1, 6.2 and 6.3. The Basic Controller does not have an M contactor. An M contactor is required to provide positive power disconnect.

WARNING

THE USER MUST INSTALL AN M CONTACTOR THAT HAS A 24 VDC COIL WITH A MAXIMUM CURRENT DRAW OF 150 MILLIAMPS. FOR TIM-ING, A 200 MICROFARAD CAPACITOR MUST BE INSTALLED WITH CORRECT POLARITY ACROSS THE RELAY COIL. THE CONTACTOR ADAPTER KIT MUST BE INSTALLED WITH THE USER'S M CONTACTOR. (REFER TO TABLE 5.A AND PARAGRAPH 5.10.) PERSONAL INJURY MAY OCCUR IF THIS IS NOT INSTALLED.

2.4.5 A-C Line Fuse Requirements — A-c line protection is provided when the Auxiliary Panel is specified. The Basic Regenerative FlexPak Controller, however, does not include a-c line protection. Fused a-c line protection must be used. Refer to Table 2.C for proper fuse sizing.

Table 2.B

SPECIFICATIONS

A-C Line Input Voltage 115/230 VAC (nominal) single-phase only

Line Voltage Variation $\pm 10\%$ of nominal

A-C Line Frequency Single Phase, 50/60 Hz (Jumper selectable) ①

Line Frequency Range 48 to 62 Hz

Output Voltages (armature and field) See Table 2.D

Controller-Drive HP Range $\frac{1}{4}$ - $\frac{3}{4}$ hp (with 115 VAC input) $\frac{1}{2}$ -5 hp (with 230 VAC input)

Direction Control Forward/Reverse

Maximum Speed Adjustment 50 to 100% of base motor speed (user adjustable)

Minimum Speed Adjustment up to 50% of base motor speed (user adjustable)

Operator Speed Adjustment Infinitely adjustable with optional control pot (up to 100% of base speed) Operator Torque Adjustment Infinitely adjustable at optional control pot (10 to 150% of rated load)

Controllable Speed Range 20:1

Current Limit Factory shipped: 150% of full load User adjustable: 10 to 150% of full load (user separately adjustable positive and negative)

Regulation (with 95% load change) 3 to 5% with voltage feedback 1.0% with specified tachometer feedback 0.5% with specified tachometer feedback

Minimum Load for Stable Operation 5%

Acceleration / Deceleration Rates 0.5 to 30 sec. linear time (user-adjusted separately)

Armature Circuit Overload Capacity 150% of armature current rating for 1 minute (max.)

Efficiency (rated speed/rated load) Controller only: 97% Complete drive including motor: 85% (typical) (2)

> Displacement Power Factor 68% (typical) (2)

Transient Protection MOV, Output RC Circuit, and Thyristor RC Circuits (4)

Controller Service Factor 1.0

Duty Continuous

Ambient Temperature (storage and operational) 0° to 55°C (32° to 131°F)

Relative Humidity (storage and operational) 5 to 95% (without condensation)

Operational Altitude To 3300 ft (1000 m) above sea level without derating

Controller Weight (approx.) Basic = 9.0 lb (4.08 kg)Complete = 11.0 lb (4.99 kg)

Controller Dimensions (LWD) Basic = $7.22 \times 8.37 \times 7.93$ inches (184 x 213 x 201 mm) Complete = $11.97 \times 8.37 \times 7.93$ inches (305 x 213 x 201 mm)

See Paragraph 3.6.

 Typical percent shown. Exact figure dependent on motor base speed and frame size.

FUSE REQUIREMENTS

HP	A-C Line	Dual Elem K5, RK5 250	
• • •	Volts	Quantity	Amp
FO	R BASIC M	OTOR PROTECT	ION
1/43/4	115	11	15
1/2-1-1/2	230	2	15
2-3	230	2	30
5	230	2	50
7.5	230	2	60
FOR	SUPERIOR	MOTOR PROTE	CTION
1/4	115	11	6.25
1/3	115	11	10
1/2	115	1.1	10
3/4	115	11	15
1/2	230	2	6.25
3/4	230	2	10
1	230	2	10
1-1/2	230	2	15
2	230	2	25
3	230	2	30
5	230	2	50
7.5	230	2	60
1	nstall fuse in	input line L1 (hot li	ne).

Table 2.D

D-C MOTOR/CONTROLLER/TRANSFORMER SPECIFICATIONS

CONTROLLER MODEL NUMBER				A-C	D-C	D-C	OPTIONAL		POWER	TRANSF.				
BASIC	COMPLETE	HP	VAC	VAC	VAC	VAC	AMPS (RMS)	ARM. (VOLTS)	ARM. AMPS AVG.	D-C FIELD VOLTS	AMP. MAX	SUPPLY CAPACITY ²	MAX KVA/ PHASE	FULL LOAD KVA
14C60	14C106-1	1/4 1/3 1/2 3/4	115 115 115 115 115	3.5 5.2 7.0 10.5	90 90 90 90	2.5 3.7 5.0 7.5	100 100 100 100	3.0 3.0 3.0 3.0	5000 5000 5000 5000	40 40 40 40	.5 0.75 1.0 1.5			
14C61	14C107-1	1/2 3/4 1 1-1/2	230 230 230 230	3.5 5.2 7.0 10.5	180 180 180 180	2.5 3.7 5.0 7.5	200 200 200 200	3.0 3.0 3.0 3.0	5000 5000 5000 5000	40 40 40 40	1.0 1.5 2.0 3.0			
14C62	14C108-1	2 3	230 230	14.0 21.0	180 180	10.0 15.0	200 200	3.0 ¹ 3.0 ¹	5000 5000	40 40	5.0 5.0			
14C63	14C109-1	5	230	35.0	180	25.0	200	3.0 ¹	5000	40	10.0			
	14C111-1	7.5	230	48	180	36.0	200	3.0 ¹	5000	40	10.0			

Section 3

3.0 General — This Section outlines the procedures that are to be followed in order to properly install a Regenerative FlexPak Plus controller.

The d-c motor should be installed and wired in accordance with installation instructions supplied with each drive.

There are certain general warnings and cautions that should be kept in mind **before** planning begins. They should be considered a general checklist which, if followed, will minimize installation problems and decrease assembly time. As a user aid, they are listed here.

DANGER

THIS UNIT SHOULD BE INSTALLED, ADJUSTED AND SERVICED BY QUALIFIED ELECTRICAL MAINTENANCE PERSONNEL FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THIS TYPE OF EQUIPMENT. THEY SHOULD ALSO BE FAMILIAR WITH THE POTENTIAL HAZARDS IN-VOLVED. IF THIS WARNING IS NOT OBSERVED, PERSONAL INJURY OR EQUIPMENT DAMAGE MAY RESULT.

DANGER

BE ABSOLUTELY CERTAIN THAT A GROUND WIRE FROM THE INCOMING A-C POWER LINE IS PROPERLY CONNECTED TO THE CHASSIS GROUND TERMINAL PROVIDED. WITHOUT PROPER GROUNDING, PERSONAL INJURY MAY OCCUR.

WARNING

THE CONTROLLER REQUIRES A SINGLE-PHASE POWER SUPPLY THAT PROVIDES EITHER 115 VAC OR 230 VAC AT 50/60 HZ. IF CORRECT VOLTAGE IS NOT AVAILABLE, IT WILL BE NECESSARY TO INSTALL A TRANSFORMER BETWEEN THE POWER SUPPLY AND THE CON-TROLLER. DO NOT OPERATE THE REGENERA-TIVE FLEXPAK PLUS CONTROLLER ON POWER SUPPLIES WITH AVAILABLE SHORT-CIRCUIT CURRENTS IN EXCESS OF 5000 AMPERES. DAMAGE TO EQUIPMENT AND PERSONAL INJURY MAY OCCUR.

WARNING

THE USER IS RESPONSIBLE FOR CONFORMING WITH THE NATIONAL ELECTRICAL CODE WITH RESPECT TO MOTOR, CONTROLLER AND OPER-ATOR DEVICE INSTALLATION, WIRING AND START-UP. THE USER IS ALSO RESPONSIBLE FOR UNDERSTANDING AND APPLYING ALL OTHER APPLICABLE LOCAL CODES WHICH GOVERN SUCH PRACTICES AS WIRING PRO-TECTION, GROUNDING, DISCONNECTS AND OVERCURRENT PROTECTION. 3.1 Layout Guidelines — This Paragraph lists recommended layout procedures common to all Regenerative FlexPak Plus controllers.

Guideline 1 — The Regenerative FlexPak Plus controller is designed as a panel-mounted unit. It is to be hung within 10° of vertical with the rear of the Chassis firmly resting against the mounting surface. (**Do not** position the Chassis on a horizontal surface.)

Guideline 2 — It is necessary to leave at least a 2-inch (50 mm) clearance between the top of one controller and the bottom of another controller. This unobstructed area allows for proper air circulation through the heat sink. **Do not** place the controller directly in a corner. Leave at least 8 inches (200 mm) from the top or 6 inches (150 mm) from the bottom of the enclosure. (Refer to Figure 3.1.) Heat builds up at the cabinet's top and may exceed the permissible inside ambient temperature upper limit. At the cabinet's bottom, the unit must be high enough to allow air to flow upwards.




Figure 3.1 — Enclosure Mounting Minimum Distances

Guideline 3 — Regardless of the above placement guidelines, the user is responsible for providing ambient temperatures that meet the controller's specifications of 0° to 55° C (32° to 131°F). Relative humidity must be kept between 5 and 95% without condensation.

Guideline 4 — Due to the U-shaped panel design of the Regenerative FlexPak Plus, the controller must be mounted in the vertical position to allow for proper cooling.

The controller is also designed to allow for power wiring to enter from the top and for control and signal wiring to be routed in thru the openings in the sides of the controller or from the bottom. (Refer to Figure 3.2.)




Figure 3.2 — Mounting and Wiring Orientations

Guideline 5 — Do not route the tachometer feedback signal cable, if used, with a-c or d-c control or power wiring. Also use the specified wire for this function.

Guideline 6 — Although auto-transformers may step up and step down a-c power supply voltage, they **do not** isolate the drive system from the a-c line. Users should consider using an isolation transformer if the application conditions warrant it.

If an isolation or auto-transformer is used ahead of the controller, the disconnect switch should be placed on the a-c power line between the power source and the transformer primary. Again, use a fused disconnect switch. (Do

not use a circuit breaker type switch because of the high inrush of transformer equipment.) Refer to Table 3.A for sizes and types.

An isolation transformer is not necessary unless the application conditions require one. However, its use provides distinct advantages. With an isolation transformer:

- Personal injury is guarded against should accidental contact be made with an electrical conductor from the drive.
- A-c power line disturbances, or transients, are minimized by an isolation transformer, thereby reducing or eliminating damage to other solid-state equipment power-conversion components in the controller and other user-equipment on the same a-c line.
- The transformer provides electrical isolation between the a-c power lines and the drive motor. Damaging currents may be eliminated in instances where a d-c output accidentally becomes grounded in a unit where the a-c electrical system is grounded.

For detailed information, refer to Paragraph 3.5.

Guideline 7 — The National Electrical Code requires that a two-pole, fused disconnect switch be installed on the incoming a-c line **ahead** of the controller to provide branch circuit protection. Fuses for this disconnect switch should be chosen from Table 3.A. They should be dual-element, slow blow type, or Class K5 or RK5.

It is recommended that the disconnect switch be placed within easy reach of operating and maintenance personnel. **Do not** place it inside a surrounding enclosure since cabinet doors may be locked. (Consult your local codes.)

Guideline 8 — It is necessary to connect the GND (green/ ground) wire of the three-conductor incoming a-c line to the terminal provided on the Chassis. Ring type connectors are recommended. The user must be sure that the ground wire is connected to the plant ground at the source.

The motor frame should also be grounded. In many cases it is adequate to use a screw in the conduit box near the motor. **Guideline 9** — A thermostat is used to guard against motor overload protection. It is essential to properly connect the motor thermostat **in series** with the Operator's Control Station **STOP** selector switch at connections 32 and 132.

CAUTION: An external overload device must be connected between terminals 32 and 132. The drive will not start without it.

Refer to Figure 3.4 where a typical Operator's Control Station schematic is shown.

Guideline 10 — When planning signal or control wire runs, as listed in Table 5.B, follow these practices:

- Conduits should be steel.
- If these conduits cross 440 VAC conductors, make sure the cross is at 90°.

 Do not route signal wires through junctions or terminal boxes that contain non-signal a-c or d-c (115/230/460 V) wires.

Guideline 11 — Operational altitude above sea level may not exceed 3300 ft (1000 m). Derate horsepower 3% for each 1000 ft (300 m) above this altitude.

3.2 Mounting — This Paragraph outlines the procedures to be followed to mount the Regenerative FlexPak Plus controller.

Determine the exact placement of the Chassis on the panel. (Refer to Figure 3.3 for mounting dimensions.) Scribe the panel. Drill three holes large enough to accept No. 10 mounting bolts. Scrape the paint around the holes to allow washers and bolts to make a ground contact.

3.3 Power Wiring — This Paragraph briefly outlines the procedures to be followed when wiring a-c power supply lines to the controller and d-c control circuits to the drive. A basic connection diagram is given at Figure 3.4.





Figure 3.3 — Mounting Dimensions





12

~

DANGER

BEFORE WIRING, MAKE SURE THE A-C LINE DISCONNECT SWITCH IS LOCKED OPEN. EVEN IF POWER HAS NOT BEEN APPLIED TO THE INCOMING LINE, THIS PRACTICE ASSURES PERSONAL SAFETY. IF NO LOCKOUT DEVICE EXISTS, REMOVE THE FUSES WITH AN INSU-LATED TOOL AND PLACE A WARNING TAG ON THE BOX. FAILURE TO OBSERVE THIS PRE-CAUTION COULD RESULT IN FATAL INJURY.

WARNING

THE USER MUST INSTALL AN M CONTACTOR THAT HAS A 24 VDC COIL WITH A MAXIMUM CURRENT DRAW OF 150 MILLIAMPS. FOR TIM-ING, A 200 MICROFARAD CAPACITOR MUST BE INSTALLED WITH CORRECT POLARITY ACROSS THE RELAY COIL. THE CONTACTOR ADAPTER KIT MUST BE INSTALLED WITH THE USER'S M CONTACTOR. (REFER TO TABLE 5.A AND PARAGRAPH 5.10.) PERSONAL INJURY MAY OCCUR IF THIS IS NOT INSTALLED.

All interconnecting wire should primarly be sized and installed in conformance with N.E.C., C.E.C. or local codes. Refer to the controller and motor nameplates for electrical data. Note that long cable runs may require that a larger gauge be used to avoid excessive voltage drop. Use of stranded wire is also recommended. Wire according to Figure 3.4.

After wiring, examine all terminals to determine that connections are correctly made at **both** ends. Confirm wire identification. Examine the firmness of the connections.

If the Auxiliary Panel is employed, wires to the motor armature (A1 and A2) must be lugged with the provided lugs, or equivalent, before connection to the appropriate relay terminals. Select wiring sizing according to N.E.C., C.E.C., or applicable local codes.

WARNING

DO NOT ALLOW CONDUCTORS TO GROUND ON THE CHASSIS. CHECK INTEGRITY OF ALL WIRE INSULATION BEFORE DRAWING. REMOVE ONLY ENOUGH INSULATION TO MAKE A FIRM TERMINAL CONNECTION. PERSONAL INJURY COULD RESULT IF A BARE WIRE TOUCHES THE CHASSIS.

<u>3.4 Tachometer Feedback</u> — The Regenerative FlexPak Plus controller may be connected to a d-c tachometer. An a-c tachometer cannot be used.

Not all drives require the use of a tachometer. This Paragraph should be read and followed **only** if the specific system requires one. If your drive system does not use a tachometer, proceed to Paragraph 3.5. The following procedures assume that Guideline 5 has been considered. These procedures are limited to preparing the incoming signal wires and wiring them at the tachometer.

Note that a twisted pair signal wire **must** be used for the tachometer feedback circuit. It is specified in Table 5.B.

The cable run between the motor and the controller must be through a dedicated conduit. Under no circumstances attempt to use the a-c or d-c conduits.

Wire according to Figure 3.4 and the following procedure.

Step 1 — Connect the tachometer wires to the terminal strip on the Module. Plus (+) is the left side, minus (-) the right. Do not strip off more than $\frac{1}{8}$ inch (3 mm) of insulation since shorts occur at exposed points. Maintain the twist as long as possible.

Step 2 — Locate the black pig-tail jumper on the Tachometer Module. It is to be placed on one of eight pins on the Module. Exactly which depends on the voltage scaling factor. On the motor's nameplate, find the base speed (rpm). On the tachometer's nameplate, find the output voltage per 1000 rpm.

Take these two figures and relate them to Table 3.A. Read across to the right column, where the 100% voltage figure is indicated. Place the jumper on the Module's pin that corresponds to this figure.

Table 3.A

TACHOMETER VOLTAGE SCALING

MOTOR BASE SPEED (rpm)	TACHOMETER (volts/1000 rpm)	100% VOLTAGE CONNECTION
1150	20 VDC	23
1750	20 VDC	35
1150	50 VDC	58
3450	20 VDC	69
1750	50 VDC	88
1150	100 VDC	115
3450	50 VDC	175
1750	100 VDC	175

Step 3 — The Feedback Jumper on the Regulator Module must be connected for tachometer feedback. (Refer to Figure 3.5.) Place the Regulator Module's fixed black jumper on the pin marked T.

DANGER

IMPROPER TACHOMETER CONNECTION WITH RESPECTTOPOLARITY WILL RESULT IN UNCON-TROLLED MOTOR SHAFT ACCELERATION WHICH MAY RESULT IN SEVERE OR FATAL PER-SONAL INJURY AND/OR EQUIPMENT DAMAGE.




Figure 3.5 — Feedback Connection on Regulator Module

NOTE: A recommended way to check the polarity of the tachometer is to run the controller as a Voltage Regulator while observing the tachometer output with a d-c voltmeter.

Step 4 — This Step assumes that the complete drive system, including the controller, has been successfully started up and debugged according to Section 4 thru Paragraph 4.3.1. It is necessary to carry out a power-on test. Set the SPEED Potentiometer at approximately 25% of full rotation. Start the drive. It should run as set. If it accelerates to full speed, the tachometer is not providing a signal or is improperly connected.

Stop the drive, turn off all power, and check and correct the leads to the Tachometer Module's terminal strip. Repeat the test with power on in order to confirm that proper feedback signals are being received by the regulator. If erratic behavior continues, check the placement of the two pig-tail jumpers against Steps 2 and 3.

Step 5 — The Maximum and Minimum Speed Potentiometers should now be adjusted to Paragraphs 4.3.2 and 4.3.3. Be sure to follow 4.3.4 and 4.3.5.

After wiring, examine connections at **both** ends to make sure wire connections were correctly made. Confirm wire identification. Examine the firmness of connections.

3.5 Isolation Transformers — Although an auto-transformer may be required because of a-c line voltage levels, it is unable to provide a number of benefits standard with an isolation transformer.

The general requirements for an isolation transformer are:

- Single phase
- 3 to 8% impedance
- Nonregulated
- Sinusoidal output
- 50/60 Hz, as required
- 150% overload for 1 minute (max.)

Refer also to Table 2.D for specific information on transformer sizing requirements. In the "Transformer" column at the right, maximum kVA and full-load kVA figures are listed in relation to specific d-c motor hp/VAC ratings.

Reliance Electric offers a number of isolation transformers suitable for use with the Regenerative FlexPak Plus controller. (Refer to Table 3.B.)

<u>**3.6 50-Hz Operation**</u> — There may be cases when the Regenerative FlexPak Plus controller is to be operated continuously on 50 Hz. If so, two resistors should be removed from the Regulator Module for optimum performance. (Refer to Figure 3.6.)




Figure 3.6 — 50-Hz Resistor Removal

3.7 HP/Current Jumper — It is necessary to inspect the Current Scaling/Horsepower Jumper on the Regulator Module to be sure that it is connected correctly for a specific drive motor.

Step 1 — On the drive motor, locate the nameplate. Note the full-load current.

Step 2 — Or, if current is not shown on the nameplate, refer to Table 3.C. Relate the left or center columns in the table with known motor data. Read across to the right column marked "Motor Current." This figure indicates the proper jumper connection to make on the Module where a corresponding number is etched.

Step 3 — On the Regulator Module, locat i the scaling pins. (Refer to Figure 3.7.) Near them, locate the black pig-tail type jumper. Do not move it if it is connected to the proper pair of pins. If it must be reconnected, carefully lift it straight up and off the pins. Slide the connector straight down over the proper set of pins.




Figure 3.7 — HP/Current Scaling Pins

3.8 Regulation Mode Jumper — The Regenerative Flex-Pak Plus controller offers three types of drive regulation. The first, which is factory shipped, is an armature voltage feedback (A). Optionally, the user may also use tachometer feedback (T) regulation. In order to use this mode, however, the Regulation Mode Jumper, one end of which is permanently fixed to the Regulator Module, must be moved to one of two positions. (Refer to Figure 3.5.) Details of jumper placement are noted in Section 3.

DANGER IF YOU ARE UNSURE WHICH REGULATION MODE A CONTROLLER SHOULD HAVE, IT IS IMPORTANT YOU FIND OUT. IF THE JUMPER IS NOT PROPERLY CONNECTED, PERSONAL INJURY MAY RESULT.

Table 3.B

RELIANCE ELECTRIC ISOLATION TRANSFORMERS

HP	kVA	PRIMARY VAC	SECONDARY VAC	ORDER NUMBER:
1/4	.5	230/460	115	77530-16A
1/4	.5	575	115	77530-17A
1/3	.75	230/460	115	77530-16B
1/3	.75	575	115	77530-17B
1/2—3/4	1.5	115	115	77530-15D
1/2—3/4	1.5	230/460	115	77530-16D
1/2—3/4	1.5	575	115	77530-17D
1/2—3/4	1.5	230/460	230	77530-16D
1/2—3/4	1.5	575	230	77530-17D
1	2.0	230/460	230	77530-16E
1	2.0	575	230	77530-17E
1-1/2	3.0	230/460	230	77530-16F
1-1/2	3.0	575	230	77530-17F
2	5.0	230/460	230	77530-16G
2	5.0	575	230	77530-17G
3—5	10.0	230/460	230	77530-16H
3—5	10.0	575	230	77530-17H
7-1/2	15	230/460	230	77530-16J
7-1/2	15	575	230	77530-17J

Table 3.C

HORSEPOWER CALIBRATION

мото	OR HP	MOTOR CURRENT/
115 VAC	230 VAC	PIN CONNECTIONS
1/4	1/2	2.5A
1/3	3/4	3.7A
1/2	1	5A
3/4	1-1/2	7.5A
_	2	10 A
_	3	15A
_	5	25A
	7-1/2	36A (Conn. 10 & 25A)

Section 4 START-UP AND ADJUSTMENT

4.0 General — This Section provides start-up and adjustment procedures to be followed after the assembly and installation of the controller is complete. All initial operation checks and final adjustments to the controller **must** be made in conformance to the procedures, warnings and recommendations listed here.

DANGER

THE REGENERATIVE FLEXPAK PLUS CONTROL-LER IS AT LINE VOLTAGE WHEN A-C LINE POWER IS CONNECTED TO THE POWER UNIT INSIDE THE CONTROLLER. BEFORE WORKING ON, OR TOUCHING ANY INTERNAL PARTS OF, THE CONTROLLER, REMOVE INCOMING A-C LINE POWER AT THE MAIN DISCONNECT SWITCH. PERSONAL INJURY MAY RESULT IF THIS WARN-ING IS NOT FOLLOWED.

DANGER

DURING INITIAL START-UP, THE CONTROLLER AND ITS ASSOCIATED EQUIPMENT MUST BE OPERATED AND/OR ADJUSTED ONLY BY QUALIFIED ELECTRICAL MAINTENANCE PER-SONNEL. THESE INDIVIDUALS SHOULD BE FAMILIAR WITH THE DESIGN AND OPERATION OF THIS EQUIPMENT AND WITH THE HAZARDS INVOLVED. PERSONAL INJURY AND/OR DAM-AGE TO THE CONTROLLER COULD RESULT FROM UNFAMILIARITY.

4.1 Power Off Inspection — It is necessary to make a superficial inspection of the Regenerative FlexPak Plus controller and its associated units. The purpose of this check is to look for possible physical damage or improper connections.

Inspect all plug-in Modification Kits. Test each for a firm mounting condition.

Each should be mechanically connected to the Regulator Module by means of a mounting post screw. Each should be electrically connected to the Module by a series of parallel pins. If any of the pins are bent, improper operation results. Examine the pins to make sure they are perfectly parallel. Only one pin may fit through a hole in the Kit.

Inspect all screw terminal connections on the Modification Kits. Make sure the wires are firmly connected. Also make sure that there is enough insulation on the wires to prevent a short between the conductors.

Inspect the signal wiring from the Operator Control Station. A series of wires will connect to individual terminals on a strip mounted on the Remote Operator Interface Module. (This Module is mounted on the Regulator Module.) Determine that all wires are firmly seated in the terminal strip. Make sure all wires are connected. **4.2 Motor Ground Check** — It may be necessary to make a check of the drive motor to assure that no damaging grounds—other than earth ground—exist within the motor.

CAUTION: Although a megger may be used for this test, if one is used, all conductors between the drive motor and the Regenerative FlexPak Plus controller are to be disconnected and moved aside. The megger's high voltage can cause damage to the controller's circuits.

Step 1 — Attach one lead from the ohmmeter to the motor frame to make a simple resistance check.

Step 2 — Touch the test probe to each of the two power, two thermostat, and two field leads to the motor.

If the reading to ground on any terminal is **less than** 100,000 ohms, a ground condition exists.

Step 3 - If a ground condition exists, inspect the motor thoroughly for internal shorts.

Step 4 — When the grounding condition is corrected, reconnect the conductors from the Regenerative FlexPak Plus controller.

4.3 Power On Adjustments — Once all the preliminary power-off static adjustments have been performed with acceptable results, the a-cline power is to be applied to the controller, but the load is **not** connected. It is important to follow these steps closely. Observe all cautions and warnings.

DANGER

WITH A-C POWER APPLIED AND WITH THE POWER ON/OFF SWITCH IN THE ON POSITION, HAZARDOUS VOLTAGE EXISTS IN THE CON-TROLLER. EXERCISE EXTREME CAUTION WHEN PERFORMING THESE TESTS. PERSONAL INJURY CAN RESULT.

DANGER

IF CIRCUIT BREAKER HAS TRIPPED OR FUSES HAVE CLEARED, USER MUST DETERMINE IF A FIELD SUPPLY KIT IS PRESENT. (SEE FIGURE 5.10.) IF FIELD SUPPLY KIT IS PRESENT, THE FIELD SUPPLY KIT AND ITS WIRING MUST BE INSPECTED FOR DAMAGE. RE-APPLYING POWER TO THE DRIVE, THE FIELD VOLTAGE MUST BE RE-CHECKED FOR PROPER VOLTAGE AT MOTOR TERMINALS F1, F2. IF THIS VOLTAGE IS BELOW 90% OF THE FIELD VOLTAGE SPECI-FIED ON THE MOTOR NAMEPLATE, THE DRIVE MUST NOT BE STARTED UNTIL PROPER VOLT-AGE IS OBTAINED. FAILURE TO FOLLOW THIS PROCEDURE COULD RESULT IN OVERSPEED-ING THE MOTOR AND/OR THE MACHINERY COUPLED TO THE MOTOR SHAFT AND POSSI-**BLE FATAL INJURY. REFER TO TROUBLESHOOT-**ING SYMPTOM 1 IN TABLES 6.B AND 6.C.

4.3.1 Regulator Module Potentiometers — The Regulator Module has six adjustable potentiometers mounted on it. (Refer to Figure 4.1.) They control the following functions:

- Maximum speed (full CCW: 50% speed)
- Minimum speed (full CCW: nearly zero speed)
- Rate 1 (FORWARD acceleration, REVERSE deceleration)
- Rate 2 (REVERSE acceleration, FORWARD deceleration)
- Current limit 1(+) (factory-set at 150%)
- Current limit 2(-) (factory-set at 150%)

The potentiometers are factory preset for the safest or most conservative operation.

4.3.2 Maximum Speed (Voltage) — The Maximum Speed Potentiometer on the Regulator Module has been factory preset for 50% of a typical motor base speed of about 1750 rpm. By means of adjustment, the maximum speed may be raised to suit the application. The result is the highest speed that can be set by the operator on the SPEED dial. The control range is 50 to 100% of rated speed.

There are two methods for determining if the motor and driven equipment are operating at an acceptable maximum speed for the application.

- Tachometer
- Visual inspection of machine operation

Locate the Maximum Speed Potentiometer on the Regulator Module. (Refer to Figure 4.1.) The letters MAX SPD are printed on the Module. Note that CW rotation represents an **increase** in speed. CC\W represents a **decrease**.




Figure 4.1 — Regulator Module Potentiometers

DANGER

WHEN PERFORMING THIS ADJUSTMENT PRO-CEDURE, DO NOT ALLOW THE DRIVE MOTOR TO EXCEED ITS RATED MAXIMUM SPEED AS LISTED ON THE NAMEPLATE. EQUIPMENT DAMAGE AND SERIOUS PERSONAL INJURY COULD RESULT.

On the Operator Station, increase the SPEED dial slowly in the direction of 10, which is 100% of full travel. If, as the SPEED dial is turned toward the 10 setting, the speed exceeds the maximum acceptable speed, **immediately** decrease the maximum speed on the SPEED dial. Use a small insulated slot screwdriver.

In some cases, to avoid exceeding the maximum operating speed, it may be necessary to turn the Maximum Speed Potentiometer completely CCW before turning the SPEED dial completely CW.

If the 10 setting on the SPEED dial is lower than the desired speed, increase the setting on the Maximum Speed Potentiometer to the necessary speed. To increase the maximum speed, turn the potentiometer CW.

DANGER

USE ONLY ONE HAND TO HOLD THE SCREW-DRIVER. KEEP YOUR OTHER HAND BEHIND YOU: DO NOT USE YOUR OTHER HAND TO BRACE YOURSELF AGAINST THE CONTROLLER, PANEL OR ENCLOSURE. PERSONAL INJURY COULD RESULT IF YOU ACCIDENTALLY TOUCH A COMPONENT AT LINE VOLTAGE.

NOTE: A further adjustment may be needed, but it should be performed after completing Paragraph 4.3.3. Note that the maximum and minimum speed adjustments are interactive; a change in one affects the other.

4.3.3 Minimum Speed (Voltage) — The Minimum Speed Potentiometer on the Regulator has been factory preset for nearly zero speed. By means of adjustment, minimum speed may be raised or lowered. The result is the lowest moving speed the operator can set on the SPEED dial. The control range is up to 50% of rated speed.

Again, the motor speed can be determined by a tachometer or by visual inspection of machine operation.

With the SPEED dial at zero position and using a small, insulated slot screwdriver, carefully turn the Minimum Speed Potentiometer until the desired minimum is reached. Note that CW represents an **increase**; CCW represents a **decrease**.

NOTE: Carefully recheck the maximum speed adjustment for desired setting. Since the maximum and minimum speed adjustments are interactive, a change in one affects the other. At times, it may be necessary to work back and forth for precise adjustments.

4.3.4 Acceleration/Deceleration Rates — The RATE 1 and RATE 2 Potentiometers on the Regulator Module are provided to adjust FORWARD and REVERSE acceleration rates, respectively. RATE 1 also controls the deceleration rate when in the REVERSE mode, and RATE 2 controls the deceleration rate when in the FORWARD mode.

These potentiometers have been factory preset for a typical linear acceleration rate of 6 seconds to maximum speed. This time can be adjusted over a range of 0.5 to 30 seconds from a fully stopped condition.

Step 1 — Place the SPEED dial in the 10 position.

Step 2 — Put the START/STOP rocker switch in the START position.

Step 3 — Have a hand-held tachometer or stopwatch held by a helper. Alternately, have an oscilloscope or chart recorder set up. On the Operator Control Station, press the START switch. Determine if the rate of acceleration is acceptable. If it is, proceed to Step 8. If not, continue with these steps.

Step 4 — Locate the RATE 1 potentiometer on the Regulator Module. (Refer to Figure 4.1.)

Step 5 — Using a small insulated slot screwdriver, carefully turn the RATE 1 Potentiometer a quarter turn. (CW represents an **increase**; CCW represents a **decrease**.)

Step 6 — Repeat Step 3. If the rate is acceptable, move on to Step 9. If the rate needs more adjustment, repeat Step 5.

Step 7 — Press the STOP rocker switch.

Step 8 — Repeat Steps 1 thru 7 with the FORWARD/ REVERSE selector switch in the REVERSE position. Use the RATE 2 Potentiometer on the Regulator Module.

NOTE: RATE 1 and RATE 2 also control deceleration in REVERSE and FORWARD modes, respectively. The rate of deceleration can be timed with a tachometer and stopwatch for slower rates. An oscilloscope or chart recorder can be used for faster rates.

4.3.5 Current Limit 1 and 2 — Current Limit #1 and Current Limit #2 Potentiometers are provided for separate adjustment of the forward (+) and reverse (-) current limits, respectively. Although it will probably not be necessary to make any adjustment in the factory-set current limit values of 150% of rated load, it is possible to change this governing value. (Individual application speed changes or load changes on sustained overloads may require readjustment. Also, applications requiring torque limiting or accelerating of high inertia loads may require a change from this value.)

To reduce the torque output of the drive, turn the Current Limit Potentiometers CCW. Note, however, that turning CCW too far may prevent the drive accelerating to the desired speed.

Section 5 MODIFICATION KITS

5.0 General — A number of optional features in the form of Modification Kits are offered with the Regenerative FlexPak Plus controller. Each of these Kits extends the control of the unit and tailors its operation to specific application needs.

This Section describes the procedures that must be followed to install the Kits. Refer to Table 5.A for an informational listing.

DANGER

INSTALLATION OF MODIFICATION KITS IS TO BE DONE ONLY AFTER A-C LINE VOLTAGE IS DIS-CONNECTED AND LOCKED OUT AT THE MAIN DISCONNECT SWITCH. DO NOT INSTALL KITS WHEN POWER IS APPLIED TO THE REGENERA-TIVE FLEXPAK PLUS CONTROLLER. SERIOUS PERSONAL INJURY AND EQUIPMENT DAMAGE COULD RESULT.

CAUTION: Installation of the Modification Kits should be performed only by qualified electrical maintenance personnel familiar with the design and operation of this equipment. Damage could result thru unfamiliarity.

Many of the Modification Kits are designed to make electrical connection with the Regulator Module by means of pin-type connectors. These slide up through matching holes in the Modules that form part of the Kit. (Refer to Figure 5.1.)




Figure 5.1 — Pin Alignment

A common installation problem is caused by bent, broken or incorrectly placed pins. Since improper operation results, care must be taken. Exact alignment is critical. Visually check that only **one** pin extends to the top of **each** slot once the connection is made.

Many of the Modification Kits require the removal of one or more jumpers from the Regulator Module. In such cases, carefully clip the leads on **both** sides of each jumper and discard it. Use a sharp pair of dykes (diagonal cutters) to assure a quick, clean cut. Do not twist the tool, since damage may result. In cases where the Kit is secured by a mounting screw, be sure to tighten it firmly but **do not overtighten**. Excessive force can strip the threads.

5.1 Auxiliary Panel — The Auxiliary Panel contains a-c line fuses, an M contactor, an Auxiliary Mounting Bracket and four screws for use with the Basic Regenerative Flex-Pak Plus. The Auxiliary Mounting Bracket provides a mounting surface for the Auxiliary M Contactor Kit.

To install the Auxiliary Panel, follow these procedures.

NOTE: If the Contactor Adapter Kit with a user-supplied M contactor has been installed, it must be disconnected and removed.

Step 1 — Orient the Auxiliary Panel over the Basic Controller aligning the mounting holes. Secure the Panel with the provided screws. (Refer to Figure 5.2.)

Step 2 — Connect leads 51 and 52 to terminals 51 and 52, respectively, on 1TB of the Basic Regenerative FlexPak Plus. Connect leads 45 and 47 to terminals 45 and 47, respectively, on the Basic Regenerative FlexPak Plus. Make sure connections are tight and well made.

Step 3 — Place the relay control harness connector over the Regulator pins marked RELAY. (Refer to Figure 5.2.) Orientation is important: connect the blue wire with the pin called out as BLU. (Refer to Figure 6.3.)




Figure 5.2 — Auxiliary Panel Mounting

5.2 Dynamic Braking — The standard Regenerative Flex-Pak Plus controller allows a drive motor to coast to rest after the STOP switch is pressed. Optionally, a user may install a Dynamic Braking Kit. (Refer to Figure 5.3.) Its use allows a rapid, shockless stopping of the drive motor.

Dynamic Braking is **not** a mechanical holding brake. It will **not** hold the shaft in place, nor will it prevent the motor from turning once motion has stopped.

The Dynamic Braking option is actually a resistor connected across the motor armature. It allows a motor to act as a generator; the rotating mechanical (kinetic) energy is converted into electrical energy that is dissipated in the form of heat by the Dynamic Braking resistor. Note that the resistor is sized for infrequent stops. Thus, users must allow time between stops for heat dissipation.




Figure 5.3 — Dynamic Braking Kit

Table 5.A

MODIFICATION KIT QUICK REFERENCE LIST

КІТ	MANUAL PARAGRAPH NUMBER	MODEL NO.	CONTROLLER MODIFICATION 71	ADDITIONAL OPTIONS REQUIRED ?	OPTIONS REQUIRED	ADDITIONAL USER- SUPPLIED PARTS?
Auxiliary M Contact	5.6	14C219	no	yes	Auxiliary Panel	wire ② ④
Auxiliary Panel	5.1	14C84 thru 87	yes	no	None	no
Contactor Adapter Kit	5.10	14C277	no	no	None	M contactor wire ④
Dancer Follower	5.8	14C230	yes	yes	Dancer Potentiometer or Dancer Position Potentiometer	wire ②
Dynamic Braking ⑦	5.2	14C214 thru 16	no	yes	Auxiliary Panel	no
Field Supply 3	5.5	14C237	no	no	None	wire 🕥
Instrument Interface/ Preset Speed	5.4	14C222	yes	no/yes	 If preset speed only, may need AUTO/MANUAL switch. 	no
				no/yes	 If follows process con- troller, may need AUTO/ MANUAL switch. 	wire ②
Master Isolated Reference Receiver 6	5.9	14C229	yes	yes	Master Isolated Reference Transmitter	wire ④
Test Meter Adapter	5.7	14C225	no	no	None	no
Voltage/ Tachometer Follower	5.3	14C223	yes	no/yes	May need AUTO/MANUAL selector switch	wire

① Modification here means that some work such as jumper placement, resistor clipping, or wiring reconnection, must be performed.

Refer to Table 5.B.

③ Supplied as standard with 2, 3 and 5 hp Regenerative FlexPak Plus controllers.

Not to exceed AWG No. 14.

③ Refer to Paragraph 5.5 for specific sizes.

⑤ Special order only.

⑦ Special order Model No. for the 7-1/2 HP drive. Contact Reliance Electric Sales Office for assistance.

When ordering the Kit, it is necessary to specify Model Numbers according to horsepower and voltage ratings. (Refer to Table 7.A.)

The Dynamic Braking Kit contains the resistor and two mounting screws. Mount the Kit in the upper right-hand corner of the Auxiliary Panel as shown in Figure 5.4. Wire the Dynamic Braking Kit according to Figure 5.5.

DB Resistor

Figure 5.4 - Dynamic Braking Kit Installed




Figure 5.5 — Dynamic Braking Connections

5.3 Voltage/Tachometer Follower — The Voltage/ Tachometer Follower Kit allows the Regenerative FlexPak Plus to be controlled **automatically** in response to a speed reference generated by a tachometer connected to an entirely separate machine unit. Ideal applications include automatic control systems where a "second" slave drive must closely follow the speed of a master drive, or machine. (Refer to Figure 5.6.)

The Kit is designed to accept an input signal of 25 to 250 VDC to obtain maximum speed. (The maximum permissible input voltage is 250 VDC.) The input impedance between terminals is approximately 80,000 ohms. Therefore, 100 VDC draw approximately 1.25 mA current from the voltage source.

The Kit contains the Module and a mounting screw. Although the Regenerative FlexPak Plus can use the Kit for exclusive automatic speed control, if manual override control is needed, an AUTO/MANUAL selector switch must be used on the Operator Control Station. In the MANUAL position, the drive responds to the SPEED Potentiometer setting. In AUTO, it follows **only** the external signal and does not respond to manually input speed change commands.




Figure 5.6 — Voltage/Tachometer Follower

The user must also supply required lengths of the specified signal wire. (Refer to Table 5.B.) No other equipment is necessary although some changes may be necessary on the Module.

Step 1 — Orient the Voltage/Tachometer Follower Module over the REFERENCE area on the Regulator Module, just over the five pins. (Refer to Figure 6.3.) Lower it so that the pins pass through the guides on the Module. (It may be necessary to remove a protective plastic cap from the pins.) Secure the Module with the screw.

Step 2 — Connect the wires from the tachometer to the terminal strip on the Module. Plus (+) is on the left, minus (-) on the right. Do not strip more than $\frac{1}{8}$ inch (3 mm) of insulation off since shorts occur at exposed points. Maintain the twisted character as long as possible.

Step 3—IF an AUTO/MANUAL selector switch is used, it is necessary to remove jumper J1 on the Voltage/Tachometer Follower Module (refer to Figures 5.7 and 6.3) and jumper J4 on the Regulator Module.

If, however, the Controller will run automatically only, without manual control, remove jumper J1 on the Module and jumper J4 on the Regulator Module and add a wire jumper between terminals 326 and 126 on the Remote Operator Buffer.




Figure 5.7 — Jumper J1

Step 4 — This Step assumes that the complete drive system, including the controller, has been successfully started up and debugged according to Section 4. It is now necessary to carry out a power-on test. Start the drive and place it in the AUTO mode, if so equipped.

With a small, insulated screwdriver, adjust the Auto Speed Calibration Potentiometer on the Tachometer/Follower Module until the drive reaches the desired speed in relation to the reference input signal being received.

DANGER APPLICATION MUST NOT RELY ON ZERO SPEED/INPUT SETTING FOR SAFETY. SERIOUS OR FATAL INJURY MAY RESULT.

5.4 Instrument Interface/Preset Speed — The Regenerative FlexPak Plus can **automatically** follow a milliampere signal from a process control instrument if the optional Instrument Interface/Preset Speed Kit is installed. (Refer to Figure 5.8.) Alternately, the Kit also permits the drive to run continuously at a preselected speed.




Figure 5.8 — Instrument Interface Kit

The Instrument Interface Module accepts a 0 to 5, 1 to 5, 4 to 20 or 10 to 50 mA signal, which may be grounded or ungrounded. The maximum input is 50 mA.

Typical applications include cases where the drive motor's speed must be controlled and varied as a function of such process variables as temperature, weight, fluid flow and pressure.

The Auto Minimum Speed Potentiometer on the Module can be set so that the drive runs at a preset minimum speed (zero to 50%) with a minimum output signal from the process instrument. The Auto Maximum Speed Potentiometer on the Module can be set so that the drive runs at 50% to base speed with a maximum output signal from the instrument. Other relationships within these parameters are also possible, and they allow operation over a larger speed range than the 5:1 range provided by the process controller.

The Kit contains a Module that has a jumper that must be connected by the user to select one of two maximum input

signals: 5 mA or 50 mA. There is also a mounting screw. The Kit may be used alone to provide full, automatic drive control, or it may be used with an optional AUTO/MANUAL selector switch on the Operator Control Station. This switch may be used to manually override the external d-c signal. (In the MANUAL position, the drive follows the SPEED Potentiometer on the Station.) The user supplies the required lengths of specified signal wire. (Refer to Table 5.B.) A process instrument controller, or other transducer with a d-c milliampere output, is also required.

NOTE: If an AUTO/MANUAL selector switch is used, it is necessary to remove jumper J1 on the Instrument Interface/Preset Speed Module (refer to Figures 5.9 and 6.3) and jumper J4 on the Regulator Module.

If, however, the Controller will run automatically only, **without** manual control, remove jumper J1 on the Module and jumper J4 on the Regulator Module **and** add a wire jumper between terminals 326 and 126 on the Remote Operator Buffer.

DANGER APPLICATION MUST NOT RELY ON ZERO SPEED SETTING FOR SAFETY. SERIOUS OR FATAL INJURY MAY OCCUR.




Figure 5.9 — Jumper J1, mA Pins

To install the Kit, follow these procedures. The following explanation assumes that the initial wiring was carried out.

Step 1 — Orient the Module over the dedicated area marked REFERENCE on the Regulator Module, just over the five pins. (Refer to Figure 6.3.) Lower it so that the pins pass through the guides on the Module. Use the screw to secure it.

Step 2 — Connect the external reference signal wires to the terminal strip on the Module. Plus (+) is on the left, minus (-) on the right. Do not strip more than $\frac{1}{8}$ inch (3 mm) of insulation off since shorts could occur at exposed points. Maintain the twisted character as long as possible.

Step 3 — At this point refer to Paragraph **5.4.1** if the Regenerative FlexPak Plus is to follow a **process instrument** controller signal. Refer to Paragraph **5.4.2** if the Regenerative FlexPak Plus is to be set at a **preset speed** for continuous operation. The procedures differ.

5.4.1 Installing Instrument Interface — When the Kit is to be used as an instrument interface, follow these Steps.

Step 1 — Determine whether the maximum input signal is between 0 to 5 mA or 5 to 50 mA. Locate the black pig-tail jumper on the Module. (Refer to Figure 5.9.) Carefully place it on the directly corresponding pin, both of which are clearly marked.

Step 2 — This Step assumes that the complete drive system, including the controller, has been successfully started up and debugged according to Section 4. It is now necessary to carry out a power-on test. Place the controller in the AUTO mode, if it is so equipped. Set the process instrument controller for minimum output. Locate the Auto Minimum Speed Potentiometer on the Interface Module. Using a small insulated screwdriver, adjust it for the desired minimum motor speed. (CCW decreases speed.)

Step 3 — Set the process instrument controller for maximum output. Locate the Auto Maximum Speed Potentiometer. Adjust it for the desired maximum motor speed. (CW increases speed.)

Step 4 — Since there is some interaction between these two potentiometers, at times it may be necessary to work back and forth to achieve precise adjustments.

5.4.2 Installing Preset Speed — When the Kit is to be used as a simple preset speed device, follow these Steps.

Step 1 — Make the same assumption as in Paragraph 5.4.1, Step 2.

Step 2 — Connect the black pig-tail jumper on the Interface Module to the 50 mA pin. (Refer to Figure 5.9.)

Step 3 — Locate the Auto Minimum Speed Potentiometer on the Interface Module. Turn it CW to the third dot which represents a one-third turn.

Step 4 — Place the controller in the AUTO mode, if so equipped. Locate the Auto Maximum Speed Potentiometer. Adjust it to obtain the desired preset speed. (CW increases speed, CCW decreases it.)

5.5 Field Supply — The Field Supply Kit provides fullwave field excitation for shunt-wound d-c motors. (Refer to Figure 5.10.) It may be optionally applied to controllers from $\frac{1}{4}$ thru $\frac{1}{2}$ hp. (It is a standard feature for 3 and 5 hp Regenerative FlexPak Plus controllers.)

D-c field supply voltage and maximum field amperes are listed in Table 2.D.

Table 5.B

USE IN CONTROLLER	TYPE CONDUCTOR	REQUIRED CHARACTERISTICS	ACCEPTABLE TYPES
	CONTRO	L WIRES	
Remote Operator Control Station: • AUTO/MANUAL • JOG/RUN • FORWARD/REVERSE • START/STOP	 Single conductor and/or multi-conductor 	 Stranded copper AWG No. 16 600 VAC rating Insulation: poly- vinyl chloride (PVC) Temperature range: 40°-105°C (104°-221°F) Unshielded 	• Any single conductor meeting N.E.C. required characteristics
	SIGNA	WIRE	
Remote Operator Control Station: • SPEED pot • TORQUE pot	 Three-conductor Twisted with two twists per inch 	 Stranded copper (19 x 29) AWG No. 16 600 VAC rating 	 User may twist single conductors of re- quired specifications Reliance Part No. 417900-79X
 Tachometer Feedback Instrument Interface Voltage/Tachometer Follower 	 Two-conductor Twisted pair with two twists per inch 	 Twist per foot: 24 (1/2-inch lay) Insulation: poly- vinyl chloride (PVC) Temperature range: 40°-105°C (104°1-221°F) 	 User may twist single conductors of re- quired specifications Reliance Part No. 417900-76EAD

WIRE SPECIFICATIONS




Figure 5.10 — Field Supply Kit


The Kit is assembly "A" (See Drawing 705385-72S supplied with Kit.) consisting of a terminal block, a Field Supply Power Cube, two wire harnesses, and two screws. The user provides the F1/F2 conductors to the drive motor. No other equipment is required.

To install the Kit, follow these procedures.

Step 1 — Mount the Field Supply Power Cube on the U-shaped support bracket behind the Regulator Module of the Basic Controller. (Refer to Figure 2.2.) Use the long taptite screw and nylon washer provided. Attach the F1, F2 terminal board to the terminal board labeled 32, 132.

Step 2 — Wire from the Field Supply Power Cube to terminals 51 and 52 on 1TB, as shown in Figure 5.11.

Step 3 — The user-supplied field wiring conductors should be drawn into the Chassis. Route them as indicated in Figure 3.4. Move them to the upper screws on 2TB and connect F1/F2 according to the label or Figure 5.11.





5.6 Auxiliary M Contacts — With the optional Auxiliary M Contactor Kit, the ON/OFF status of the Regenerative FlexPak Plus is able to be interlocked with user-supplied devices. (Refer to Figure 5.12.) Typical applications include pilot/indicator lights, alarms, and interlocking with other control circuits dependent on the drive system.




Figure 5.12 — Auxiliary M Contactor Kit

The Kit provides a single pair of Form C contacts, one normally open (NO) and one normally closed (NC). Both share a common terminal. (Refer to Figure 5.13.) These contacts function when the M contactor is energized. The Kit contains only a Module that has a wire harness attached. However, the Auxiliary Panel is also required.




Figure 5.13 — External Wiring, Auxiliary M

Users supply the wiring to external devices. Size is dependent on the specific application. It should not exceed AWG No. 14.

The maximum rating of each contact is 1 ampere at 30 VDC (resistive) or 0.5 ampere at 120 VAC (resistive).

Under **no** circumstances should these contacts be used to control brakes or other power loads.

To install the Kit, follow these procedures.

Step 1 — Fit the Auxiliary Panel onto the Basic Controller according to Paragraph 5.1.

Step 2 — Mount the Auxiliary M Contactor Module on the center of the Auxiliary Mounting Bracket. (Refer to Figure 2.2.) Note that orientation is important. The overhanging edge of the assembly **must** hang over the Regulator Module. Then snap the assembly into the Bracket.

Step 3 — Connect the three-wire harness to the Regulator Module. Locate the letters AUX. M printed on the Module near a three-pin connector. (Refer to Figure 6.3.) The connector fits on the bayonet pins. Note that the yellow (39) wire **must** connect with the pin marked YEL 39 on the Regulator Module.

Step 4 — Route external wiring to the Module's terminal block. Do not strip more than $\frac{1}{4}$ inch (6 mm) of insulation from the wires since shorts could occur at exposed points.

5.7 Test Meter Adapter — Measuring and monitoring of Regenerative FlexPak Plus regulator voltages can be safely and conveniently carried out with the optional Test Meter Adapter Kit. (Refer to Figure 5.14.) It acts as an interface between the Regulator Module and a user's voltmeter.

CAUTION: Under no circumstances should the probes of a meter be connected directly to the pins on the Regulator Module. Permanent damage to the solid state components can occur.




Figure 5.14 — Test Meter Adapter

The Kit contains a Module and a mounting screw. Except for the voltmeter, no other equipment is necessary. The meter should be a multimeter having a sensitivity of 20,000 ohms per volt, minimum. (Simpson Model 260, Triplett Model 630, or equivalent is acceptable.)

To install and use the Kit, follow these procedures.

Step 1 — Orient the Test Meter Adapter Module over the area on the Regulator Module marked TEST, just over the nine pins. (Refer to Figure 6.3.) Lower it so that the pins pass through the guides on the Module. Use the screw to secure it.

Step 2 — For use, refer to Table 5.C where the function is shown in relation to the test terminals to be used. The normal operating voltages are also shown.

5.8 Dancer Follower — The Dancer Follower Kit allows the Regenerative FlexPak Plus to be controlled **automatically** in response to a speed reference generated by a line speed signal and trimmed by a Dancer Potentiometer. Applications include web process lines where a drive must closely follow or maintain the position of a dancer.

Table 5.C

TEST ADAPTER TERMINALS, READINGS

FOR FUNCTION:	USE TERMINALS:	NORMAL INDICATION (VDC):
Unregulated +20 VDC Power Supply	+456 -357	16-28
Unregulated -20 VDC Power Supply	-471 +357	16-28
Regulated +11.2 VDC Power Supply	+356 -357	10.8-11.5
Regulated 	-371 +357	10.8-11.5
LVTU (linear voltage time unit) Input	+826 357	0-8.0
Major Loop Feedback	819 +357	0-4.0
Forward/Reverse Driver Outputs	-816, -817 +356	On 10 VDC scale, increase of approx. 1 VDC occurs when drive is started.

The Kit contains the Dancer Follower Module and a mounting screw. (Refer to Figure 5.15.) Although the Regenerative FlexPak Plus can use the Kit for exclusive automatic speed control, if manual override control is needed, an AUTO/MANUAL selector switch must be used on the Remote Operator Control Station. In the MANUAL position, the drive responds to the SPEED Potentiometer setting. In AUTO, it follows **only** the external signals and does not respond to manually input speed change commands.




Figure 5.15 — Dancer Follower Module

between the line speed input terminals 57 and 726 is approximately 25,000 ohms. The Dancer Potentiometer will provide up to a 20% trim to the line speed signal. The user must supply the required lengths of the specified signal wire. (Refer to Table 5.B.) A Dancer Potentiometer and an optional Dancer Position Potentiometer are also to be supplied by the user.

To install the Kit, follow these procedures.

Step 1 — Refer to Figure 6.3 and note the heavy border area in the center of the Regulator Module marked REFER-ENCE. This is the area where the Dancer Follower Module is to be mounted. Place the Dancer Follower Module in the proper orientation so the pin guides on the Module are aligned over the set of five pins on the Regulator Module. Lower the Dancer Follower Module so the pins pass through the pin guides and the mounting spacer seats in the mounting hole. (It may be necessary to remove a protective plastic cap from the pins.) Secure the Module with the supplied screw.

Step 2 — Connect the black pig-tail jumper of the Dancer Follower Module to pin 319 on the Regulator Module. (Pin 319 is the top pin of a group of two pins along the righthand edge.)

Step 3 — Using a twisted pair, connect the external line speed input to the terminal strip of the Dancer Follower Module. The plus (+) wire is connected to terminal 726 and the minus (-) wire is connected to terminal 57.

NOTE: Do not strip more than $\frac{1}{8}$ inch (3 mm) of insulation off the ends of the wires because a short circuit could occur at any point where the bare wire is exposed. Maintain the twisted configuration of the two wires as long as possible.

Step 4 — Using three twisted wires, connect the user supplied 5K ohm Dancer Potentiometer 10 the terminal strip of the Dancer Follower Module. The speed increase side of the potentiometer connects to terminal 556 and the speed decrease side connects to terminal 571. The potentiometer wiper is connected to terminal 919.

Step 5 — If an optional Dancer Position Potentiometer is used (supplied by user), connect the "up" side of the potentiometer to terminal 726 of the Dancer Follower Module and the "down" side to terminal 557. Connect the potentiometer wiper to terminal 926. Also cut and remove jumper J2 and the 26.7K resistor (R6) on the Dancer Follower Module. (Refer to Figure 5.16.)

Step 6 — If an AUTO/MANUAL selector switch is used, it is necessary to remove jumper J1 on the Dancer Follower Module (refer to Figures 5.16 and 6.3) and jumper J4 on the Regulator Module.

If, however, the Controller will run automatically only, without manual control, remove jumper J1 on the Module and jumper J4 on the Regulator Module and add a wire jumper between terminals 326 and 126 on the Remote Operator Buffer.

Step 7 — This Step assumes that the complete drive system, including the controller, has been successfully started and debugged according to Section 4. It is now necessary to conduct a power-on test.

Start the drive and place it in the AUTO mode, if so equipped. With the line speed reference at maximum value, adjust the MAX SPEED TRIM Potentiometer on the Dancer Follower Module for maximum motor speed. If the optional Dancer Position Potentiometer is installed, place it in the mid-range.




Figure 5.16 — Jumpers J1, J2 and Resistor (R6)

Turn the GAIN Potentiometer of the Dancer Follower Module fully counterclockwise for minimum Dancer Potentiometer response. Turn the GAIN Potentiometer clockwise in small increments to increase the Dancer Potentiometer response.

DANGER APPLICATION MUST NOT RELY ON ZERO SET/ INPUT SETTING FOR SAFETY. SERIOUS OR FATAL INJURY MAY RESULT.

5.9 Master Isolated Reference Receiver — The Master Isolated Reference Receiver Kit may be added to special order Regenerative FlexPak Plus controllers. This Kit allows the Regenerative FlexPak Plus to receive and decode a PWM speed reference signal from the Master Isolated Reference Transmitter. The Receiver Kit consists of two printed circuit boards: a Switch Receiver Module and a Reference Receiver Module which are mounted on the Regenerative FlexPak Plus Regulator Module. (Refer to Figure 5.17.)




Figure 5.17 - Master Isolated Reference Receiver Kit

The Operator Control Station AUTO/MANUAL selector switch is used to obtain local control or master reference control of the individual drive. When the selector switch is placed in the AUTO mode, the individual drive SPEED Potentiometer automatically is converted into a draw pot adjustment for precise trim control between drives. The only adjustment requirement is a zero set adjustment on the Reference Receiver Module. Should the speed reference wires become disconnected, the Regenerative Flex-Pak Plus will go to zero speed.

Regenerative FlexPak Plus controllers controlled by Master Isolated Reference are ideally suited for non-reversing multiple conveyor drives, proportional pumps, feeder drives, web lines or other similar operations which require multiple drives to follow a common reference signal and provide hold back torque.

To install the Kit, follow these procedures.

Step 1 — Refer to Figure 6.3 and note the heavy border area at the extreme left-hand side of the Regulator Module. This is the area where the Switch Receiver Module is to be mounted. First, remove the Remote Operator Adapter Module. Then, place the Switch Receiver Module in the proper orientation so the two connectors are aligned over the two sets of pins (marked GRN 28 and RED 32). Carefully, slowly and gently press the connectors down on the pins until they bottom. Then, connect the black pig-tail jumper of the Switch Receiver Module to pin 40 on the Regulator Module.

Step 2—Fold the PC board over the top of the two connectors so the mounting spacers fit into the mounting holes.

Step 3 — Connect the external start-stop wires (wires 189 and 288) from the external Master Isolated Reference Transmitter to the terminal block on the Switch Receiver Module in the controller cabinet.

Step 4 — Mount the Remote Operator Adapter Module on top of the Switch Receiver Module and secure the two PC boards with the two long screws provided.

NOTE: The external start-stop wires from the Master Isolated Reference Transmitter (wires 189 and 288) must be connected to the Switch Receiver Module (Refer to Step 3.) before mounting the Remote Operator Adapter Module on the Switch Receiver Module. Jumpers J1 and J2 on the Switch Receiver Module(Refer to Figure 5.18.)must be cut when Remote Operator Stations are used. These jumpers are left connected when only control from the Master Isolated Reference Transmitter is desired.

Step 5 — Refer to Figure 6.3 and note the heavy border area in the center of the Regulator Module marked REFER-ENCE. This is the area where the Reference Receiver Module is to be mounted. Place the Reference Receiver Module in the proper orientation so the pin guides on the Module are aligned over the set of five pins on the Regulator Module. Lower the Reference Receiver Module so the pins pass through the pin guides and the mounting spacer seats in the mounting hole. (It may be necessary to remove a protective plastic cap from the pins.) Secure the Module with the supplied screw.

Step 6 — Using a twisted pair, connect the external reference wires (wires 1 and 2) from the external Master Isolated Reference Transmitter to the terminal block on the Reference Receiver Module in the controller cabinet. Connect wire 1 to terminal 1 and wire 2 to terminal 2.

NOTE: Do not strip more than $\frac{1}{8}$ inch (3 mm) of insulation off the ends of the wires because a short circuit could occur

at any point where the bare wire is exposed. Maintain the twisted configuration of the two wires as long as possible. **Step 7**—If an AUTO/MANUAL selector switch is used, it is necessary to remove jumper J1 on the Master Isolated Reference Receiver Module (refer to Figures 5.19 and 6.3) and jumper J4 on the Regulator Module.

If, however, the Controller will run automatically only, without manual control, remove jumper J1 on the Module and jumper J4 on the Regulator Module and add a wire jumper between terminals 326 and 126 on the Remote Operator Buffer.

Step 8 — With the MASTER Speed Potentiometer on the Master Isolated Reference Transmitter set at zero, depress the START pushbutton on the Master Isolated Reference Transmitter. Adjust the ZERO SET Potentiometer on the Reference Receiver Module to obtain zero speed of the drive motor.

DANGER

ALTHOUGH ZERO SET ADJUSTMENT ON THIS KIT ALLOWS FOR ADJUSTMENT DOWN TO ZERO SPEED, THIS ZERO SPEED SETTING MUST NOT BE USED WHERE THE OPERATOR MAY RELY ON A MAINTAINED ZERO SPEED. ELECTRICAL NOISE, IMPROPER WIRING, POWER LINE, OR MALFUNCTIONING COMPONENTS MAY CAUSE THE DRIVE TO TURN ON WHILE AT THE ZERO SPEED SETTING. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN FATAL INJURY.




Figure 5.18 — Jumpers J1 and J2 on Switch Receiver Module




Figure 5.19 — Jumper J1 on Reference Receiver Module

5.10 Contactor Adapter — The Contactor Adapter Kit provides a means of connecting the user-supplied M contactor to the Basic Regenerative FlexPak Plus Controller. Refer to Paragraph 2.4.4 for M contactor specifications.

The Kit is an assembly consisting of an Auxiliary Mounting Bracket, a power terminal strip, a wire harness and four screws.

To install the Kit, follow these procedures.

Step 1 — Orient the Auxiliary Mounting Bracket (Refer to Figure 5.2.) over the Basic Controller aligning the mounting holes. Secure the Bracket with the provided washers and screws. Make sure the washer teeth are firmly embedded in the Chassis to provide proper ground.

Step 2 — Orientation of the harness connectors is important. Place the left harness connector over the Regulator pins marked RELAY with the blue wire with the pin called out as BLU.

Step 3 — Wire the user-supplied M contactor to the kit terminal strip according to Figure 5.20.




Figure 5.20 — Connecting User-supplied M Contactor

Section 6 TROUBLESHOOTING

<u>6.0 General</u> — This Section details troubleshooting information for the Regenerative FlexPak Plus controller. Its organization is as follows:

- General troubleshooting concepts (Paragraphs 6.1, 6.2, 6.3 and 6.4)
- Specific symptom/probable cause/recommended procedures (Paragraph 6.5)
- Reference schematics of the controller (Paragraph 6.6)

DANGER

CONTROLLER EQUIPMENT IS AT LINE VOLTAGE WHEN A-C POWER IS CONNECTED TO THE POWER UNIT IN THE REGENERATIVE FLEXPAK PLUS CONTROLLER. THUS, A-C POWER MUST BE REMOVED FROM THE UNIT BEFORE IT IS SAFE TO TOUCH THE INTERNAL PARTS OF THE REGENERATIVE FLEXPAK PLUS. PERSONAL INJURY MAY RESULT UNLESS POWER IS REMOVED.

DANGER

THE REGENERATIVE FLEXPAK PLUS CONTROL-LER SHOULD BE SERVICED ONLY BY QUALIFIED ELECTRICAL MAINTENANCE PERSONNEL FA-MILIAR WITH THE CONSTRUCTION AND OPER-ATION OF ALL APPLICATION EQUIPMENT IN THE SYSTEM. PERSONAL INJURY AND/OR EQUIP-MENT DAMAGE MAY OCCUR IF INDIVIDUALS ARE NOT FAMILIAR WITH THE HAZARDS RE-SULTING FROM IMPROPER OPERATION.

In addition to step-by-step troubleshooting procedures, there are some generalized comments that should be kept in mind at all times. These may be divided into wiring errors (Paragraph 6.1), incoming a-c line problems (Paragraph 6.2), motor problems (Paragraph 6.3) and mechanical problems (Paragraph 6.4).

6.1 Wiring Errors — The single most common problem preventing normal d-c drive operation is incorrect wiring within a system. A maintenance person should spend at least five minutes carefully looking over the wiring before taking active steps involving tests and replacement. Remember that a loose or grounded wire can occur in a controller that had previously been functioning correctly if initial wiring techniques were poorly performed.

For those not familiar with proper Regenerative FlexPak Plus controller wiring, other Sections in this manual may be consulted. For more complex problems, Section 5 may be used to uncover wiring problems in the optional Modification Kits.

6.2 A-C Line Problems — The following are typical problems located on the incoming a-c line:

• A-c line voltage incorrect for the specific controller, which may operate on 115 or 230 VAC.

- Main disconnect switch contains fuses improperly rated for the drive. (The fuses must be large enough to prevent nuisance tripping yet small enough to protect the circuit and equipment on the circuit.) Refer to Table 3.A.
- A-c conductors must be of adequate size for the application. Refer to Table 3.A.
- If an isolation transformer is used, it must be sized according to the requirements of the drive system. The transformer itself must be wired for the correct output voltage (115/230 VAC) in relation to the Regenerative FlexPak Plus controller.

6.3 Motor Problems — Do not overlook the possibility that the malfunction may be located in the drive motor. The following steps should become part of a troubleshooting routine:

- Recheck all motor connections for firmness and correct identification.
- Check that no obvious grounds have occurred on any of the wires. However, **do not** use a megger when checking for grounds unless the motor wiring to the Regenerative FlexPak Plus controller is **completely** disconnected.
- A volt-ohmmeter (VOM) may be used for ground checking without disconnecting conductors to the Regenerative FlexPak Plus controller.
- Check the field windings for open or short conditions.
- Check continuity through the armature and brushes. Use terminals A1 and A2 at the Complete Controller (terminals 45 and 47 at the Basic Controller) as test points.

6.4 Mechanical — It may be that the malfunction is a simple mechanical problem. The load on the drive motor may be too large, or it may have too high an inertia. The results are long stopping times and current-limit starting demands. Thus, the freedom of motion of the load device should be considered.

6.5 Controller Malfunctions — Tables 6.B and 6.C present an organized troubleshooting sequence based on a symptom/probable cause/suggested procedure approach. They develop from the most simple, obvious malfunction to more complex ones.

Note that Reliance Electric color codes the wires to aid the identification of pin numbers, that is, locations. Table 6.A is a listing of these number-color combinations. These colors will be helpful in the following troubleshooting procedures.

6.6 Schematics, Diagrams — In order to aid with the troubleshooting process, various schematics and diagrams are included. Note that these drawings are the latest revisions as of the date of publication of this manual. The manufacturer cannot guarantee that subsequent changes will not occur; although, if any do, they should be minor. In cases of doubt, contact your local Reliance Electric Sales Office or Distributor.

Included are the following drawings:

- Figure 6.1 which is a simplified control circuit schematic for a controller.
- Figure 6.2 which is a timing chart for the relay control sequencing used with this controller.
- Figure 6.3 which is a copy of the screen used to mark the Regulator Module. It is useful in identifying locations on the board. Note that areas where optional Modification Kits fit are marked with heavy lines.
- Figure 6.4 which is a schematic for the controller.
- Figure 6.5 which is a schematic for the Modification Kits.
- Figure 6.6 which may be used to locate major assemblies in the controller. It also lists various technical data although all of this information is included in other parts of the manual.




Figure 6.1 — Control Circuit

Table 6.A

COLOR CODING SYSTEM

COMPONENTS	NO. (1)	COLOR		
Wire Harness	_	BLUE		
M Contactor	38	GRAY		
	38	BROWN		
	40	ORANGE		
	36	GREEN		
Thermostat Harness	32	RED		
	132	ORANGE		
	232	BLACK		
Auxiliary M	-39(38)	YELLOW		
① Numbers in parentheses are for the Regenerative FlexPak Plus when they are different from the FlexPak Plus.				




Figure 6.2 — Relay Control Sequencing




Figure 6.3 — Regulator Module Screen

Table 6.B

TROUBLESHOOTING SUGGESTIONS FOR THE BASIC CONTROLLER

SYMPTOM	PROBABLE CAUSE	RECOMMENDED PROCEDURES
 POWER ON/OFF circuit breaker trips or fuses clear when power is applied. 	Incorrect wiring con- nections to controller; from controller to motor; in motor.	DANGER IF CIRCUIT BREAKER HAS TRIPPED OR FUSES HAVE CLEARED, USER MUST DETERMINE IF A FIELD SUPPLY KIT IS PRESENT. (SEE FIGURE 5.10.) IF FIELD SUPPLY KIT IS PRESENT. THE FIELD SUPPLY KIT AND ITS WIRING MUST BE INSPECTED FOR DAMAGE. AFTER RE-APPLYING POWER TO THE DRIVE, THE FIELD VOLTAGE MUST BE RE-CHECKED FOR PROPER VOLTAGE AT MOTOR TERMINALS F1, F2. IF THIS VOLTAGE IS BELOW 90% OF THE FIELD VOLTAGE SPECIFIED ON THE MOTOR NAMEPLATE, THE DRIVE MUST NOT BE STARTED UNTIL PROPER VOLTAGE IS OBTAINED. FAILURE TO FOLLOW THIS PROCE- DURE COULD RESULT IN OVERSPEEDING THE MOTOR AND/OR THE MA- CHINERY COUPLED TO THE MOTOR SHAFT AND POSSIBLE FATAL INJURY.
	-	 Remove a-c power at the disconnect. Remove leads to L1, L2, 45, 47 and, if used, F1, F2, on incoming side of controller's 1TB and 2TB. (Refer to Figure 3.4.) Open the power disconnect switch. Check for a ground condition at L1/181, L2/182, 45, 47, F1 and F2. Do this at controller (internal) side of 1TB and 2TB. If a ground is discovered, check wiring connections on POWER ON/OFF circuit breaker or fuse block and power disconnect. Also check connection to Power Cube and motor field terminals F1 and F2. If no ground exists, examine the controller Chassis for loose wires and/or foreign objects. If no ground exists and if no foreign objects are discovered, reconnect the incoming conductors 45, 47 and, it used, F1 and F2. Then check for grounds at these terminals. If a ground is found, it is in the conductors to the motor or in the motor itself. Disconnect the motor from the conductors for a ground. (If one exists, examine connections and insulation for areas where shorts could occur.) If no grounds are found in the conductors, check the motor for a ground condition. If a ground is located here, examine and/or replace the motor, as necessary.
<u>.</u>	Short in Power Cube.	Replace Power Cube.
	Short in Field Supply Kit.	Replace Diode Bridge in Field Supply Kit. Inspect wires and connections to Field Supply Kit. Replace all damaged wires and connectors.
2. Drive motor does not start.	Main a-c line discon- nect not closed; or fuse blown; or no power applied ahead of disconnect.	Check disconnect switch, fuses in it, and voltage on line.
	Drive interlocks pre- venting operation.	Verify that all user-installed interlocks are in a state (physical condition and wiring connections) to allow a start.
	Drive motor thermostat wires not connected on controller terminals 32 and 132 on 2TB.	 Check connections to thermostat: at drive motor P1, P2; at controller 32, 132. Check for open thermostat inside motor. Make a resistance check of thermostat. (It should read a short, or low resistance, if it is closed.)
	External overload wires not connected on controller terminals 32 and 132 on 2TB.	 Check connections to external overload. Check for open overload. Make a resistance check to overload. (It should read a short, or low resistance, if it is closed.)
	D-c circuit breaker open.	Check for motor ground conditions before resetting.
 Drive motor does not run, but CR pulls up. (Use this proce- dure only if con- troller does not have optional Test Meter Adapter Kit.) 	No input signal from SPEED potentiometer on Control Station.	 If the controller does not have an optional AUTO/MANUAL switch, inspect the Regulator Module to determine that jumper J4 is in place. (The jumper is removed when the AUTO/ MANUAL switch is installed.) Check the SPEED potentiometer on the Control Station. First, open the power disconnect switch. Connect a volt-ohmmeter to the Regulator Module Remote Operator Adapter inputs. Connect one lead to terminal 28. Connect the other to terminal 20. (Refer to Figure 3.4 for a Remote Station.) For proper operation, the reading should be 5K ohms. Disconnect the VOM lead from terminal 20. Connect it to terminal 426. Turn the SPEED potentiometer.

Table 6.B

TROUBLESHOOTING SUGGESTIONS FOR THE BASIC CONTROLLER (continued)

SYMPTOM	PROBABLE CAUSE	RECOMMENDED PROCEDURES
 Drive motor does not run, but CR pulls up. 	No input signal from SPEED pot.	First check the main power supplies. This must be done with power applied to the Regenerative FlexPak Plus controller.
(Use this proce- dure only if controller has optional Test Meter Adapter Kit.)		DANGER THE PROCEDURE DESCRIBED HERE IS PERFORMED WITH LIVE A-C VOLTAGE APPLIED TO THE CONTROLLER. USE ONLY ONE HAND TO APPLY VOM LEADS/ PROBES. KEEP YOUR OTHER HAND BEHIND YOU AT ALL TIMES. DO NOT HOLD ONTO THE CONTROLLER FOR SUPPORT. PERSONAL INJURY MAY RESULT IF THESE PRECAUTIONS ARE NOT TAKEN.
		 Connect one lead of volt-ohmmeter to test pin 357 on the Test Meter Adapter Module. Connect the second lead to test pin 356 on the Module. The reading should be within the range of 10.8 to 11.5 VDC for normal operation. Next, remove the lead from pin 356. Place it on pin 456. The reading should be within the range of +16 to +28 VDC for normal operation. Next, remove the lead from pin 456. Place it on pin 471. The reading should be within the range of -16 to -28 VDC for normal operation. If the proper readings are obtained, the power supplies may be assumed to be operating correctly. If incorrect readings are obtained, replace the Regulator Module. Next, check the reference voltage input signal. (This changes in direct proportion to an increase of SPEED potentiometer voltage caused by a turning of the dial.) Connect the other lead to pin 826. Readings vary from 0 to +8.2 VDC, depending on the set point of the SPEED potentiometer dial. If no voltage is noted between pins 357 and 826, check to see if jumper J4 on the Regulator Module is properly placed/removed for the specific controller. (It is to be in place, as factory-shipped, if there is no AUTO/MANUAL switch.) It is to be removed if there is an AUTO/MANUAL switch.)
5. Drive motor does	No output from Power Cube.	 If the SPEED potentiometer is functioning normally, and if the J4 jumper is placed/removed, as necessary, replace the Regulator Module. Examine armature wiring. First, open the power disconnect switch. Check armature wiring for loose connections.
relay picked up and SPEED poten- tiometer properly operating. (Use this proce- dure only if con- troller does not have optional Test		□ Turn a-c power on again. DANGER THE PROCEDURE DESCRIBED HERE IS PERFORMED WITH LIVE A-C VOLTAGE APPLIED TO THE CONTROLLER. USE ONLY ONE HAND TO APPLY VOM LEADS/ PROBES. KEEP YOUR OTHER HAND BEHIND YOU AT ALL TIMES. DO NOT HOLD ONTO THE CONTROLLER FOR SUPPORT. PERSONAL INJURY MAY RESULT IF THESE PRECAUTIONS ARE NOT TAKEN.
Meter Adapter Kit.)		 Connect a volt-ohmmeter to terminals 45 and 47 on 1TB. (Refer to Figure 3.4.) Place the START/STOP switch in the START position. Increase the speed reference by turning the SPEED dial in the direction of 10. The reading across 45 and 47 should be 0 to 90 VDC for 115 VAC controllers. It should be 0 to 180 for 230 VAC controllers. If no reading is obtained across 45 and 47, it may be necessary to replace the Power Cube and/or the Result to Module.
	Regulator Module sus- pected because no out- put reading at 45, 47.	 the Regulator Module. In order to determine which, read on. Test the Regulator Module for firing pulses. Open the power disconnect switch. Locate the 50µf capacitor at R27-43 and put the voltmeter (-) lead to R27. Locate the four diodes on the Gate Coupling board near the words "Gate Coupling Card." Connect the (+) meter lead to the anode of the left-most diode (D1). (The anodes are the leads nearest the pulse transformers and without the I.D. white circle.) Put the voltmeter on a low a-c volt scale. Restore a-c power to the controller. Put FORWARD/REVERSE switch in REVERSE.
• •		 Place the START/STOP switch in the START position. Turn the SPEED pot up to about 5. The reading on the VOM should be about -0.7 VAC. Turn the START/STOP switch to STOP and remove a-c power. Repeat this test with (+) meter lead on the next diode to the right (D2). Repeat the test with FORWARD/REVERSE in the FORWARD position and the (+) meter lead on each of the two right-most diodes (D3 and D4). If any of the four readings cannot be obtained, replace the Regulator Module.
	Power Cubes suspected because no output reading at 45, 47.	 Establish that the Power Cubes are receiving pulse inputs at the connector on the Regulator Module. (Refer to "Regulator Module suspected," Symptom 5.) If the Power Cubes are receiving pulses yet there is no reading across 45 and 47, determine that the main contacts on the CR relay are closing. In order to check the contacts, replace the drive motor with a light bulb on the armature wiring at
e		ITB. (On 230 VAC controllers use two light bulbs in series.) If the light does not light, replace the Power Cubes.

Table 6.B

TROUBLESHOOTING SUGGESTIONS FOR THE BASIC CONTROLLER (continued)

SYMPTOM	PROBABLE CAUSE	RECOMMENDED PROCEDURES
 Drive motor does not run with CR relay picked up and SPEED poten- tiometer properly operating. (Use this proce- dure only if controller has optional Test Meter Adapter Kit.) 	No gate firing pulses.	 Turn off power to the controller at the main disconnect. Connect a volt-ohmmeter lead to test pin 356 on the Test Meter Module. Connect the second lead to test pin 817. Put the FORWARD/REVERSE switch in the REVERSE position. Restore power to the controller. DANGER THE PROCEDURE DESCRIBED HERE IS PERFORMED WITH LIVE A-C VOLTAGE APPLIED TO THE CONTROLLER. USE ONLY ONE HAND TO APPLY VOM LEADS/PROBES. KEEP YOUR OTHER HAND BEHIND YOU AT ALL TIMES. DO NOT HOLD ONTO THE CONTROLLER FOR SUPPORT. PERSONAL INJURY MAY RESULT IF THESE PRECAUTIONS ARE NOT TAKEN.
		 Place the START/STOP switch in the START position. On the +10 VDC scale of the volt-ohmmeter, an increase of approximately +1 VDC should be noted. Turn off power to the controller. Reconnect the volt-ohmmeter to test pins 356 and 816. Put the FORWARD/REVERSE switch in the FORWARD position. Put the START/STOP switch in the START position. On the +10 VDC scale of the volt-ohmmeter, an increase of approximately +1 VDC should be noted. If voltage readings increase, the Power Cubes are receiving pulses to its SCRs. If wiring is correct, replace the Power Cubes.
 Motor runs but current peaks too high. 	One phase not firing.	Perform the procedure for "Regulator Module suspected," Symptom 5, because no output reading at 45, 47. If all pulses are present, one or more Power Cubes are faulty.
8. Remote Operator Control Station functions not operating.	Malfunctioning switches.	 Check START/STOP switch, but first remove a-c line power at main disconnect. Connect ohmmeter to terminal 32 on the Remote Operator Adapter. Touch probe to terminal 38 on the Remote Operator Adapter. Place switch in the START (closed) position. If the switch is properly functioning, a short will be seen on the meter. Check the STOP function. Place the RUN/JOG switch in the RUN position. Connect the ohmmeter to terminals 32 and 35. Place the switch in the STOP position, which should open it if it is functioning correctly. If there is a short, it will be seen on the meter. If there is no short, the circuit is opened, and the switch is functioning correctly. Using similar techniques, test the RUN/JOG switch in the RUN position at terminals 32 and 35. When the switch is in the RUN position, a short should be read.

TROUBLESHOOTING SUGGESTIONS FOR THE COMPLETE CONTROLLER

SYMPTOM	PROBABLE CAUSE	RECOMMENDED PROCEDURES
 POWER ON/OFF circuit breaker trips or fuses clear when power is applied. 	Incorrect wiring con- nections to controller; from controller to motor; in motor.	DANGER IF CIRCUIT BREAKER HAS TRIPPED OR FUSES HAVE CLEARED, USER MUST DETERMINE IF A FIELD SUPPLY KIT IS PRESENT. (SEE FIGURE 5.10.) IF FIELD SUPPLY KIT IS PRESENT, THE FIELD SUPPLY KIT AND ITS WIRING MUST BE INSPECTED FOR DAMAGE. AFTER RE-APPLYING POWER TO THE DRIVE, THE FIELD VOLTAGE MUST BE RE-CHECKED FOR PROPER VOLTAGE AT MOTOR TERMINALS F1, F2. IF THIS VOLTAGE IS BELOW 90% OF THE FIELD VOLTAGE SPECIFIED ON THE MOTOR NAMEPLATE, THE DRIVE MUST NOT BE STARTED UNTIL PROPER VOLTAGE IS OBTAINED. FAILURE TO FOLLOW THIS PROCE- DURE COULD RESULT IN OVERSPEEDING THE MOTOR AND/OR THE MA- CHINERY COUPLED TO THE MOTOR SHAFT AND POSSIBLE FATAL INJURY.
	1	 Remove a-c power at the disconnect. Remove leads to L1, L2, A1, A2 and, if used, F1, F2, on incoming side of controller's 1TB and 2TB. (Refer to Figure 3.4.) Open the power disconnect switch. Check for a ground condition at L1/181, L2/182, A1, A2, F1 and F2. Do this at controller (internal) side of 1TB and 2TB. If a ground is discovered, check wiring connections on POWER ON/OFF circuit breaker or fuse block and power disconnect. Also check connection to Power Cube and motor field terminals F1 and F2. If no ground exists, examine the controller Chassis for loose wires and/or foreign objects. If no ground exists and if no foreign objects are discovered, reconnect the incoming conductors A1, A2 and, if used, F1 and F2. Then check for grounds at these terminals. If a ground is found, it is in the conductors to the motor or in the motor itself. Disconnect the motor from the conductors at the drive motor. Test A1, A2, F1 and F2 conductors for a ground. (If one exists, examine connections and insulation for areas where shorts could occur.) If no grounds are found in the conductors, check the motor for a ground condition. If a ground is located here, examine and/or replace the motor, as necessary.
	Short in Power Cube.	□ Replace Power Cube.
	Short in Field Supply Kit.	Replace Diode Bridge in Field Supply Kit. Inspect wires and connections to Field Supply Kit. Replace all damaged wires and connectors.
2. Drive motor does not start.	Main a-c line discon- nect not closed or fuse blown or no power applied ahead of disconnect.	Check disconnect switch, fuses in it, and voltage on line.
	Drive interlocks pre- venting operation.	Verify that all user-installed interlocks are in a state (physical condition and wiring connections) to allow a start.
	Drive motor thermostat wires not connected on controller terminals 32 and 132 on 2TB.	 Check connections to thermostat: at drive motor P1, P2; at controller 32, 132. Check for open thermostat inside motor. Make a resistance check of thermostat. (It should read a short, or low resistance, if it is closed.)
	External overload wires not connected on controller terminals 32 and 132 on 2TB.	 Check connections to external overload. Check for open overload. Make a resistance check to overload. (It should read a short, or low resistance, if it is closed.)
	D-c circuit breaker open.	Check for motor ground conditions before resetting.
3. Controller's M contactor not picking up when START switch is pressed (closed).	M contactor malfunctioning.	 Open the power disconnect switch Examine M contactor for firm seating. On the M contactor, connect an ohmmeter on the brown (location 38) and black (location 65) wires. A short should be read. Connect the ohmmeter on the blue wire and the yellow (39) wire. The reading should be approximately 230 ohms. If these readings cannot be obtained, replace the M contactor. (Refer to Table 7.A.)
Continue this symptom on next page.	FORWARD/REVERSE switch malfunction.	 Examine Remote Operator Adapter on Regulator Module for firm seating and proper wiring and pin connections. (Refer to Figure 6.3.) Test FORWARD/REVERSE switch. With an ohmmeter, test 67 (purple) against 56 (blue) and 71 (white) against 67 (gray). Meter should indicate 0 ohms.

TROUBLESHOOTING SUGGESTIONS FOR THE COMPLETE CONTROLLER (continued)

SYMPTOM	PROBABLE CAUSE	
 Controller's M contactor not picking up when START switch is pressed (closed). (Continued) 	M contactor malfunctioning.	 On the Auxiliary M pins located on the Regulator Module, connect an ohmmeter. Place it on the pin 39 and pin 67. Place the FORWARD/REVERSE switch in the FORWARD position. The reading should be approximately 500 ohms if it is operating properly. Without changing test points, place the switch in the REVERSE position. The reading should be about 500 ohms if it is operating properly. If a short is observed, remove jumper J9 and repeat the test. If a 500-ohm resistance reading cannot be obtained when the switches are open, the M contactor is malfunctioning and must be replaced.
 M contactor picks up but remains in only when START pushbut- ton is pressed and held in. 	RUN∕JOG switch is	DANGER THE PROCEDURE DESCRIBED HERE IS PERFORMED WITH LIVE A-C VOLTAGE APPLIED TO THE CONTROLLER. USE ONLY ONE HAND TO APPLY VOM LEADS/ PROBES. KEEP YOUR OTHER HAND BEHIND YOU AT ALL TIMES. DO NOT HOLD ONTO THE CONTROLLER FOR SUPPORT. PERSONAL INJURY MAY RESULT IF THESE PRECAUTIONS ARE NOT TAKEN.
	in JOG position. CR relay not picking up.	 Apply a clower to the content. Place the RUN/JOG switch in the RUN position. Connect a volt-ohmmeter on the Remote Operator Adapter. Place it on terminal 35. Connect the second probe to the blue wire connected to the Regenerative FlexPak Plus M contactor. The reading should be +24 VDC for normal operation. (Refer to Figure 6.4 to see the logic of this test.) Next, shift the probe from terminal 35 to terminal 38 on the same terminal board. However, leave the second probe where it is. Press the START switch. The reading should be approximately 24 VDC for normal operation. (Refer to Figure 6.4 to see the logic of this test.) Press the START/STOP switch to STOP, and then START. A 24 VDC (approximate) reading should continue to appear. If it does not, the CR relay is not picking up. In this case, replace the Regulator Module.
 Drive motor does not run, but M contactor and CR pull up. (Use this proce- dure only if con- troller does not have optional Test Meter Adapter Kit.) 	No input signal from SPEED potentiometer on Control Station.	 If the controller does not have an optional AUTO/MANUAL switch, inspect the Regulator Module to determine that jumper J4 is in place. (The jumper is removed when the AUTO/ MANUAL switch is installed.) Check the SPEED potentiometer on the Control Station. First, open the power disconnect switch. Connect a volt-ohmmeter to the Regulator Module Remote Operator Adapter inputs. Connect one lead to terminal 28. Connect the other to terminal 20. (Refer to Figure 3.4 for a Remote Station.) For proper operation, the reading should be 5K ohms. Disconnect the VOM lead from terminal 20. Connect it to terminal 426. Turn the SPEED potentiometer from 10 to 0. The resistance should vary from 5K to 0 ohms. If it does not, replace the potentiometer.
 6. Drive motor does not run, but M contactor and CR pull up. (Use this proce- dure only if controller has optional Test Meter Adapter Kit.) 	No input signal from SPEED pot.	 First check the main power supplies. This must be done with power applied to the Regenerative FiexPak Plus controller. DANGER THE PROCEDURE DESCRIBED HERE IS PERFORMED WITH LIVE A-C VOLTAGE APPLIED TO THE CONTROLLER. USE ONLY ONE HAND TO APPLY VOM LEADS/ PROBES. KEEP YOUR OTHER HAND BEHIND YOU AT ALL TIMES. DO NOT HOLD ONTO THE CONTROLLER FOR SUPPORT. PERSONAL INJURY MAY RESULT IF THESE PRECAUTIONS ARE NOT TAKEN. Connect one lead of volt-ohmmeter to test pin 357 on the Test Meter Adapter Module. Che eading should be within the range of 10.8 to 11.5 VDC for normal operation. Next, remove the lead from pin 356. Place it on pin 456. The reading should be within the range of +16 to +28 VDC for normal operation. Next, remove the lead from pin 456. Place it on pin 471. The reading should be within the range of -16 to -28 VDC for normal operation. If the proper readings are obtained, replace the Regulator Module. Next, check the reference voltage input signal. (This changes in direct proportion to an increase of SPEED potentiometer voltage caused by a turning of the dial.) Connect one lead of a volt-ohmmeter to pin 357 on the Test Meter Adapter Module. In the reading since obtained, replace the Regulator Module. Connect one lead of a volt-ohmmeter to pin 357 on the Test Meter Adapter Module. Connect the other lead to pin 826. Readings vary from 0to +8.2 VDC, depending on the set point of the SPEED potentiometer dial. If no voltage is noted between pins 357 and 826, check to see if jumper J4 on the Regulator Module is properly placed/removed for the specific controller. (It is to be in place, as factory-shipped, if there is no AUTO/MANUAL switch.) It is to be removed if there is an AUTO/MANUAL switch.) If the SPEED potentiometer is functioning normally, and if the J4 jumper is placed/removed, as

TROUBLESHOOTING SUGGESTIONS FOR THE COMPLETE CONTROLLER (continued)

SYMPTOM	PROBABLE CAUSE	RECOMMENDED PROCEDURES
 Drive motor does not run with M contactor picked up and SPEED potentiometer properly operating. (Use this proce- dure only if con- troller does not have optional Test 	No output from Power Cube.	 Examine armature wiring. First, open the power disconnect switch. Check armature wiring for loose connections. Turn a-c power on again.
		DANGER THE PROCEDURE DESCRIBED HERE IS PERFORMED WITH LIVE A-C VOLTAGE APPLIED TO THE CONTROLLER. USE ONLY ONE HAND TO APPLY VOM LEADS/ PROBES. KEEP YOUR OTHER HAND BEHIND YOU AT ALL TIMES. DO NOT HOLD ONTO THE CONTROLLER FOR SUPPORT. PERSONAL INJURY MAY RESULT IF THESE PRECAUTIONS ARE NOT TAKEN.
Meter Adapter Kit.)		 Connect a volt-ohmmeter to terminals A1 and A2 on 1TB. (Refer to Figure 3.4.) Place the START/STOP switch in the START position. Increase the speed reference by turning the SPEED dial in the direction of 10. The reading across A1 and A2 should be 0 to 90 VDC for 115 VAC controllers. It should be 0 to 180 for 230 VAC controllers. If no reading is obtained across A1 and A2, it may be necessary to replace the Power Cube and/or the Regulator Module. In order to determine which, read on.
	Regulator Module sus- pected because no out- put reading at A1, A2.	 Test the Regulator Module for firing pulses. Open the power disconnect switch. Locate the 50µf capacitor at R27-43 and put the voltmeter (-) lead to R27. Locate the four diodes on the Gate Coupling board near the words "Gate Coupling Card." Connect the (+) meter lead to the anode of the left-most diode (D1). (The anodes are the leads nearest the pulse transformers and without the I.D. white circle.) Put the voltmeter on a low a-c volt scale. Restore a-c power to the controller. Put FORWARD/REVERSE switch in REVERSE. Place the START/STOP switch in the START position. Turn the SPEED pot up to about 5. The reading on the VOM should be about -0.7 VAC. Turn the START/STOP switch to STOP and remove a-c power. Repeat this test with (+) meter lead on the next diode to the right (D2). Repeat the two right-most diodes (D3 and D4). If any of the four readings cannot be obtained, replace the Regulator Module.
	Power Cubes suspected because no output reading at A1, A2.	 Establish that the Power Cubes are receiving pulse inputs at the connector on the Regulator Module. (Refer to "Regulator Module suspected," Symptom 7.) If the Power Cubes are receiving pulses yet there is no reading across A1 and A2, determine that the main contacts on the M contactor are closing. In order to check the contacts, replace the drive motor with a light bulb on the armature wiring at 1TB. (On 230 VAC controllers use two light bulbs in series.) If the light does not light, replace the Power Cubes.
 8. Drive motor does not run with M contactor picked up and SPEED potentiometer properly operat- ing. (Use this proce- dure only if controller has optional Test Meter Adapter Kit.) 	No gate firing pulses.	 Turn off power to the controller at the main disconnect. Connect a volt-ohmmeter lead to test pin 356 on the Test Meter Module. Connect the second lead to test pin 817. Put the FORWARD/REVERSE switch in the REVERSE position. Restore power to the controller.
		DANGER THE PROCEDURE DESCRIBED HERE IS PERFORMED WITH LIVE A-C VOLTAGE APPLIED TO THE CONTROLLER. USE ONLY ONE HAND TO APPLY VOM LEADS/ PROBES. KEEP YOUR OTHER HAND BEHIND YOU AT ALL TIMES. DO NOT HOLD ONTO THE CONTROLLER FOR SUPPORT. PERSONAL INJURY MAY RESULT IF THESE PRECAUTIONS ARE NOT TAKEN.
		 Place the START/STOP switch in the START position. On the +10 VDC scale of the volt-ohmmeter, an increase of approximately +1 VDC should be noted. Turn off power to the controller.
		 Reconnect the volt-ohmmeter to test pins 356 and 816. Put the FORWARD/REVERSE switch in the FORWARD position. Put the START/STOP switch in the START position. On the +10 VDC scale of the volt-ohmmeter, an increase of approximately +1 VDC should be noted.
		 If voltage readings increase, the Power Cubes are receiving pulses to its SCRs. Make a last check of wiring to the Power Cubes. If wiring is correct, replace the Power Cubes.

TROUBLESHOOTING SUGGESTIONS FOR THE COMPLETE CONTROLLER (continued)

SYMPTOM	PROBABLE CAUSE	RECOMMENDED PROCEDURES
9. Remote Operator Control Station functions not operating.	Malfunctioning switches.	 Check START/STOP switch, but first remove a-c line power at main disconnect. Connect ohmmeter to terminal 32 on the Remote Operator Adapter. Touch probe to terminal 38 on the Remote Operator Adapter. Place switch in the START (closed) position. If the switch is properly functioning, a short will be seen on the meter. Check the STOP function. Place the RUN/JOG switch in the RUN position. Connect the ohmmeter to terminals 32 and 35. Place the switch in the STOP position, which should open it if it is functioning correctly. If there is a short, it will be seen on the meter. If there is no short, the circuit is opened, and the switch is functioning correctly. Using similar techniques, test the RUN/JOG switch in the RUN position at terminals 32 and 35. When the switch is in the RUN position, a short should be read.
10. Motor runs but current peaks too high.	One phase not firing.	Perform the procedure for "Regulator Module suspected," Symptom 7, because no output reading at A1, A2. If all pulses are present, one or more Power Cubes are faulty.





Figure 6.4 — Controller Schematic

4



.....




Figure 6.5 — Modification Kits Schematics (continued from prior page)

43




Figure 6.6 – Controller Technical Data

44

Section 7 REPLACEMENT PARTS

.

<u>7.0 General</u> — Users should consider maintaining a stock of spare parts. Refer to Figure 6.6, Controller Technical Data, for all replacement parts.

Forward To: Reliance Electric – RGA Technical Publications 25001 Tungsten Road Cleveland, OH 44117



Technical Writing Internal Use:	

DIF #__

V★S DRIVES & INDUSTRIAL CONTROLS DOCUMENTATION IMPROVEMENT FORM

Document Number:

Page Number(s):_____

Comments: (Please give chapters, page numbers or specific paragraphs that the change will affect. Include markups from the document or attach additional pages if necessary.)

What will this improvement suggestion provide?_____

Originator:	City:	State:	ZIP:
Company:	Phone: ()		
Address:	Date:		
Technical Writing Internal Use:	Follow-Up Action:		
Writer:	Date:		
		DEU	

Thank you for your comments . . .

RE 1857LC1 Printed in U.S.A.

D-C DRIVES TRAINING AND AUDIO/VISUAL PRODUCTS

Reliance Electric offers a wide variety of Industrial Training courses for electricians, electronic technicians and engineers who are responsible for the installation, repair and maintenance of production equipment and systems.

Professional quality A/V Programs are also available. These programs have been designed to provide years of efficient in-house training. Available for playback at the user's convenience, these videotape programs allow individual or groups to learn or review subjects at any time.

Printed reference materials come with all diagnostic and troubleshooting programs.

Training Courses

No.	Title
	D-C DRIVE COURSES
1-1	Principles of Industrial Electricity and Electronics
1-2	Maintenance and Troubleshooting of Standard D-C Drives
1-3	Maintenance and Troubleshooting of Engineered D-C Drives and Systems
1-4	D-C Drives Hands-On Troubleshooting Lab
1-11	Maintenance and Troubleshooting of MaxPak® Plus Drives
1-15	Regional Class – Maintenance and Troubleshooting of D-C Drives and Systems
1-16	Maintenance and Troubleshooting of MaxPak III Drives

Audio/Visual Products

Order No.	Title	Format	Price
TM2107 TM2185 TM2186 TM2200 TM2201 TM2202 TM2203 TM2239 TM2243 TM2276	D-C DRIVES PROGRAMS Troubleshooting 3-Phase, Full Wave, Half Control Power Modules using the Oscilloscope Introduction to the MaxPak Plus Drive Troubleshooting the MaxPak Plus S-6 Power Module Troubleshooting the S-6 Power Module Troubleshooting the MaxLine® S-3R Power Module Concepts of Regulation Troubleshooting the MaxLine S-6 Regulator Troubleshooting the S-6R Power Module Principles of Field Weakened Motor Speed Control D-C Machine Theory	35mm Slides/ Audiotape Videotape Videotape Videotape Videotape Videotape Videotape Videotape Videotape Videotape Videotape	\$325 995 725 425 725 725 725 725 725 725 725
	VIDEO TRAINING PROGRAMS		
VMBA001 VMBV001 VWVS001 VWVS002 VWVS005	Fundamentals of A-C Motors Concepts of Digital Controls GP2000 Video Training HR2000 Video Training Basics of A-C Drives	Videotape Videotape Videotape Videotape Videotape	\$495 495 495 495 495

For details and prices on these courses, audio/visual products and FREE Training Schedule Brochure, HD-405 contact:

Industrial Training Department Reliance Electric 35000 Curtis Boulevard Eastlake, Ohio 44095

Call Toll Free:

800-RELIANCE (800-735-4262)



Data or Prices subject to change without notice.

Reliance Electric / 24703 Euclid Avenue / Cleveland, Ohio 44117 / 216-266-7000

