

Installing and Operating the Three-Phase Input Three-Phase Output GV30000 AC Drive

1/4 to 20 HP @ 380-460 VAC



For proper GV3000 operation, a pulse tachometer must be properly installed.
See Chapter 3 of this instruction manual for terminal wiring connections.

The information in the user's manual is subject to change without notice.

DANGER

ONLY QUALIFIED ELECTRICAL PERSONNEL FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THIS EQUIPMENT AND THE HAZARDS INVOLVED SHOULD INSTALL, ADJUST, OPERATE, AND/OR SERVICE THIS EQUIPMENT. READ AND UNDERSTAND THIS MANUAL IN ITS ENTIRETY BEFORE PROCEEDING. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

GV3000®, AutoMax®, and Reliance® are registered trademarks of Reliance Electric Company or its subsidiaries.

© Copyright Reliance Electric Industrial Company 1995.

Table of Contents

1.0	Receiving the Equipment	1-1
1.1	Identify the Drive by Model Number	1-1
1.2	Receive And Accept The Shipment	1-1
1.3	File a Return Request	1-2
1.4	Store the Drive until Installation	1-2
1.5	GV3000 Drive General Description	1-2
1.6	Standard Features	1-2
1.7	GV3000 Programmable Features	1-3
1.8	GV3000 Parameters	1-4
1.9	Drive Options	1-5
1.9.1	Additional drive options	1-6
1.10	Dangers, Warnings and Cautions	1-6
2.0	Drive Specifications	2-1
2.1	Drive Ratings	2-1
2.2	Drive Input/Output Specifications	2-2
2.3	Motor Applications	2-4
3.0	Installation and Wiring	3-1
3.1	Planning and Location	3-1
3.2	Mounting the Drive	3-1
3.3	Install an External Input Disconnect	3-4
3.4	Install A-C Branch Circuit Protection	3-5
3.5	Transformer and Reactor Installation (If Needed)	3-6
3.5.1	Input Transformers	3-6
3.5.2	Output Reactors	3-6
3.6	Grounding the Drive	3-6
3.7	Wiring the Drive	3-7
3.7.1	Power Wiring	3-9
3.7.2	Control and Signal Wiring	3-11
3.8	Analog Input Speed Reference and Analog Output Jumper Setting	3-19
3.8.1	Changing the Analog Input Speed Reference Jumper (J4)	3-19
3.8.2	Change the Analog Output Jumper (J17)	3-20
3.9	Optional Snubber Braking Wiring	3-20
3.10	RS-232 Wiring (NEMA 1)	3-20
3.11	Motor Preparation	3-21
4.0	Using the GV3000 Keypad	4-1
4.1	Viewing or Changing Parameters in the First Menu List (Parameters P.000 - P.006):	4-2
4.2	Viewing or Changing Parameters in the Second Menu List (Parameters P.007 - P.065 and U.000 - U.013):	4-3
4.3	Display Modes	4-4
4.3.1	Viewing a Display Mode	4-5
4.3.2	Viewing the SPEED REFERENCE Display Mode	4-5
4.4	Program Lockout	4-5
4.5	Viewing Fault Codes, Clearing the Error Log, or Viewing the Error Log Time Stamp	4-6

5.0	Starting the Drive	5-1
5.1	Startup CheckList	5-1
5.2	Starting the Drive	5-2
5.2.1	Preparations for Self-Tuning	5-2
5.2.2	How to Stop the Self-Tuning Procedure	5-2
5.2.3	What Happens if a Fault Occurs During Self-Tuning?	5-2
5.2.4	Starting Self-Tuning	5-3
5.3	Basic Drive Checks	5-3
5.4	Tuning the Speed Regulator	5-3
5.5	Final Adjustments	5-4
5.6	Cover Installation, NEMA 4X (Indoor Only)/12 or NEMA 12 Only	5-4
6.0	Adjusting Parameters	6-1
6.1	Introduction to Parameters	6-1
6.2	Parameter Menus and Password Entry	6-1
6.3	Configuring the Drive	6-2
6.4	General Parameters - First Menu List	6-4
6.5	General Parameters - Second Menu List	6-8
6.6	Vector Operation Parameters	6-31
7.0	Troubleshooting and Fault Codes	7-1
7.1	Drive Operation	7-1
7.1.1	Power Circuit Operation	7-1
7.1.2	Drive Regulator Operation	7-3
7.2	Fault Codes	7-5
7.2.1	How to Access and Read the Error Log and Time Stamp	7-5
7.2.1.1	Accessing the Error Logs	7-7
7.2.1.2	Accessing the Error Log Time Stamp	7-7
7.2.2	How to Access and Read the Results from Torque Self-Tuning	7-8
7.2.2.1	Accessing the Self-Tuning Result Code (displayed in Parameter U.009)	7-8
7.3	Verifying D-C Bus Voltage	7-12
8.0	Parameter Quick Reference Guide	8-1

List of Figures

Figure 3.1 - GV3000 Drive Physical Dimensions (460 VAC 1,2,3 and 5 HP)	3-2
Figure 3.2 - GV3000 Drive Physical Dimensions (460 VAC 7.5 and 10 HP)	3-3
Figure 3.3 - GV3000 Drive Physical Dimensions (460 VAC 15 and 20 HP)	3-4
Figure 3.4 - GV3000 Wiring Locations (460 VAC 1,2,3 and 5 HP)	3-8
Figure 3.5 - GV3000 Wiring Locations (460 VAC 7.5 and 10 HP)	3-8
Figure 3.6 - GV3000 Wiring Locations (460 VAC 15 and 20 HP)	3-9
Figure 3.7 - Power Terminal Strip Wiring (460 VAC 1-10 HP)	3-10
Figure 3.8 - Power Terminal Strip Wiring (460 VAC 15 and 20 HP)	3-10
Figure 3.9 - Control Terminal Wiring Locations	3-12
Figure 3.10 - Analog Input Speed Reference Jumper Setting (J4)	3-19
Figure 3.11 - Analog Output Jumper Setting (J17)	3-20
Figure 4.1 - GV3000 Front Panel Keypad/Display	4-1
Figure 4.2 - First Menu List Parameter Displays	4-2
Figure 4.3 - Second Menu List Parameter Displays	4-3
Figure 4.4 - Error Log and Time Stamp Displays	4-6
Figure 6.1 - Configuring the Drive	6-2
Figure 6.2 - Relationship of Analog Input Speed Reference to Minimum and Maximum Speed	6-11
Figure 6.3 - Trim Reference Source Selection	6-14
Figure 6.4 - Draw and Trim Gain	6-15
Figure 6.5 - S-Curve Acceleration	6-17
Figure 6.6 - S-Curve Deceleration	6-17
Figure 6.7 - Typical Multi-Speed Preset Operation	6-23
Figure 7.1 - Block Diagram of the GV3000 Vector Control	7-2
Figure 7.2 - Typical System Block Diagram	7-4
Figure 7.3 - Error Log Displays	7-6
Figure 7.4 - D-C Bus Identification	7-12
Figure 7.5 - GV3000 Replacement Parts Locations (460 VAC 1,2,3, and 5 HP)	7-14
Figure 7.6 - GV3000 Replacement Parts Locations (460 VAC 7.5 and 10 HP)	7-15
Figure 7.7 - GV3000 Replacement Parts Locations (460 VAC 15 and 20 HP)	7-16

List of Tables

Table 1.1 - GV3000 Kits	1-5
Table 2.1 - Drive Application Data	2-1
Table 2.2 - GV3000 Drive Input and Output Specifications	2-3
Table 3.1 - Three-Phase A-C Input Line Branch Circuit Protection	3-5
Table 3.2 - Control Terminal Wiring	3-13
Table 6.1 - Digital Input Limits Matrix Selection	6-10
Table 6.2 - Speed Feedback Analog Output Values	6-13
Table 6.3 - Torque/Current Feedback Analog Output Values	6-13
Table 6.4 - Multi-Speed Preset Digital Input Matrix	6-22
Table 7.1 - Troubleshooting IET Fault Codes	7-9
Table 7.2 - Replacement Parts List For GV3000 Drive	7-13
Table 8.1 - First Menu Parameters (P---) - Short List	8-1
Table 8.2 - Second Menu Parameters (P---)	8-2
Table 8.3 - Vector Control Parameters (U---)	8-7

1.0 RECEIVING THE EQUIPMENT

DANGER


ONLY QUALIFIED ELECTRICAL PERSONNEL FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THIS EQUIPMENT AND THE HAZARDS INVOLVED SHOULD INSTALL, ADJUST, OPERATE, AND/OR SERVICE THIS EQUIPMENT. READ AND UNDERSTAND THIS MANUAL IN ITS ENTIRETY BEFORE PROCEEDING. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

The products described in this instruction manual are manufactured by Reliance® Electric Industrial Company.

1.1 Identify the Drive by Model Number

Each Reliance Electric GV3000 A-C drive can be positively identified by its model number (standard drive) or sales order number (customer specified drive). This number appears on the shipping label and is stamped on the drive nameplate. Refer to this number whenever discussing the equipment with Reliance Electric personnel.

The standard model number matrix describes the drive as follows:



1.2 Receive And Accept The Shipment

Reliance Electric’s terms of sale, in all instances, are F.O.B. point of origin. The user is responsible for thoroughly inspecting the equipment before accepting shipment from the transportation company.

If all the items called for on the bill of lading or on the express receipt are not included or if any items are obviously damaged, do not accept the shipment until the freight or express agent makes an appropriate notation on your freight bill or express receipt. If any concealed loss or damage is discovered later, notify your freight or express agent within 15 days of receipt and request that he make an inspection of the shipment. Keep the entire shipment intact in its original shipping container.

The user is responsible for making claim against the Carrier for any shortage or damage occurring in transit. Claims for loss or damage in shipment must not be deducted from the Reliance Electric invoice, nor should payment of the invoice be withheld while awaiting adjustment of such claims since the Carrier guarantees safe delivery.

1.3 File a Return Request

1. To return equipment, send a written request to Reliance Electric within ten days of receipt.
2. Do not return equipment without a numbered Equipment Return Authorization (ERA) from Reliance Electric.
3. Reliance Electric reserves the right to inspect the equipment on site.

1.4 Store the Drive until Installation

After receipt inspections, repack the drive in its original shipping container until installation. If a period of storage is expected, store in the original shipping container with its internal packing. To ensure satisfactory operation at startup and to maintain warranty coverage, store the equipment:

- in its original shipping container in a clean, dry, safe place.
- within an ambient temperature range of -10°C to 65°C
- within a relative humidity range of 5 to 95% without condensation.
- away from a highly corrosive atmosphere. In harsh environments, cover the shipping/storage container.

1.5 GV3000 Drive General Description

The GV3000 drive is a high performance, variable speed, A-C drive. It provides closed loop flux-vector operation with speed feedback provided by a pulse tachometer. The GV3000 provides high performance regulation of motor speed, torque and direction. The torque reference selected can be either speed control (speed loop output or terminal block analog input) or torque control. The GV3000 performs a torque control self-tuning procedure in vector mode with a proper parameter selection. (Refer to *section 5, Starting self-tuning*, or *section 6, Parameter U.008*.)

The GV3000 is available in NEMA 1, NEMA 4X(Indoor Only) and 12 (watertight/dust-tight), or NEMA 12 only enclosures in horsepower ranges of 1, 2, 3, 5, 7.5, 10, 15 and 20 HP at nominal A-C input voltage of 460 VAC.

The drive is controlled from one of three possible sources - from the front panel/keypad, remote devices wired to the GV3000's control terminal block, or with the use of AutoMax Network Communications Option Board. All GV3000 control parameter settings are accomplished by either entry through the keypad while in the PROGRAM mode or when using a personal computer. Using a personal computer to configure the GV3000 requires a specified minimum level of personal computer hardware and software. It also requires the use of Reliance configuration software and a communications cable (See Drive Options).

Meter-like displays of drive RPM, volts, amps, hertz, kilowatt, torque, and speed reference are available by selecting the desired DISPLAY mode. Keypad operation is defined in section 4.

(For drive operation theory, refer to section 7, "Drive Operation".)

1.6 Standard Features

- NEMA 1, NEMA 4X(Indoor Only) and 12 enclosure, or NEMA 12 only
- Programmable closed-loop flux vector operation

- Keypad and display:
 - start/stop
 - speed adjustment
 - forward/reverse
 - run/jog reference
 - parameter adjustments
 - automatic speed adjustment (AUTO mode) or manual speed reference (MANUAL mode)
 - monitor and display of; (RPM, volts, amps, hertz, kilowatts, torque, or speed)
 - diagnostic fault monitoring
- Non-volatile elapsed time meter function (parameter setting)
- Ability to follow a 0-20 mA or ± 10 VDC analog input signal for AUTO mode speed control. Accuracy of input is ± 10 bit resolution. Parameter adjustments for software gain and offset of the input.
- Carrier frequency selection for reduced motor acoustic noise
- Reduced susceptibility to nuisance trips
- U.L., C of U.L., IEC classified
- 15 Hz speed loop response bandwidth
- 8 isolated digital inputs (three inputs are configurable)
- Pulse tachometer feedback
- Self-tuning to determine pulse tach PPR and no load current of torque control loop

1.7 GV3000 Programmable Features

There are many programmable features offered by the GV3000 drive that are accessible by enabling or “turning on” certain parameters, or a by enabling a combination of parameters.

Some of them are:

- IGBT switching
2,4 or 8 kHz (carrier frequency selection)
- Speed reference input
0 to ± 10 VDC, 0 to 20 mA, or 4 to 20 mA
- Isolated digital inputs for
start/stop, reset, run/jog, function loss, forward/reverse,
multispeed, MOP increment/decrement, and second ramp change.
- Pulse tachometer feedback (512, 1024, 2048, or 4096 PPR)
- Fault indication and faultlog
- U.L., C of U.L./IEC listed
electronic motor overload (meets NEC/CEC requirements)
- Programming lockout
- Terminal block input configuration
- Analog reference input gain and offset
- Inverse analog reference
- Reverse disable
- S-curve functionality
- RPM display scaling
- Elapsed time meter
- Vector torque control self-tuning

1.8 GV3000 Parameters

Parameters are arranged and numbered according to their specific task in the GV3000 drive's software configuration. Two (2) parameter subject list configurations and a fault error log are accessible by the user:

- **First Menu List:**
General drive parameters (P.--):
P.000 - P.006 (1st menu short list)
- Error log entries (Err):
9.xxx - 0.xxx, Clr (Error log can hold 10 entries)
- **Second Menu List (Password Enabled):**
General drive parameters (P.--):
 - P.000 - P.065 (P.000 - P.006 from the 1st menu and P.007 - P.065 after password enabling)
 - Error log entries (Err):
9.xxx - 0.xxx, Clr (Error log can hold 10 entries)
 - Vector parameters (U.--):
U.000 - U.013 (Vector parameters only)
 - Factory Settings (F.--):
(**Not** adjustable by the user)

1.9 Drive Options

The following kit options are available for use with GV3000 drives. See table 1.1.

Table 1.1 - GV3000 Kits

Kit Description	Model Number	Maximum Continuous Watt Dissipation	Maximum Amps	Factory or Field Installed	Instruction Manual
Snubber Resistor Braking	2SR40400 ⁽¹⁾	400		Both	D2-3291
	2SR40600 ⁽²⁾	600			
	2SR41200 ⁽²⁾	1200			
	2SR41800 ⁽³⁾	1800			
Low Energy Snubber Resistor Braking	2DB4010	800 ⁽⁶⁾		Both	D2-3179
	2DB4020	1600 ⁽⁶⁾			
Snubber Transistor Only	2ST40027	user-supplied	27	Both	D2-3291
Line Regeneration Unit	1RG42008		8	Both	N/A
	1RG42015		15		
	1RG42045		45		
Motor Encoder Cable	2TC4025 ⁽⁴⁾			Field	D2-3305
	2TC4075 ⁽⁴⁾				
	2TC4100 ⁽⁵⁾				
	2TC4300 ⁽⁵⁾				
AutoMax Network Communication Board w/10 foot cable	2AX3000				D2-3308

(1) Cabinet Style A. Refer to Instruction Manual D2-3291.

(2) Cabinet Style B. Refer to Instruction Manual D2-3291.

(3) Cabinet Style C. Refer to Instruction Manual D2-3291.

(4) For use with Reliance NEMA Vector Inverter Duty Motors (tachometer connector and exposed wire pairs). Refer to Instruction Manual D2-3305.

(5) For use with Reliance NEMA Vector Inverter Duty Motors (exposed wire pairs on both ends). Refer to Instruction Manual D2-3305.

(6) Ratings are given as instantaneous resistor wattage, not continuous ratings. Refer to Instruction Manual D2-3179.

1.9.1 Additional drive options

The following cables and software are also available for personal computer communications with the drive.

Drive Option	Part Number	Description
Software Configuration Executive 3000	2CE3000	<ul style="list-style-type: none">● Create, store, upload, and download drive configurations● Monitor and change drive parameters on-line● Compare configuration file on the computer to the configuration of the drive● Read and reset faults
Interface Cable 25-pin to 9-pin	61C127	<ul style="list-style-type: none">● Used to connect the personal computer to the drive
Interface Cable 9-pin to 9-pin	2CA3000	<ul style="list-style-type: none">● Used to connect the personal computer to the drive
Interface Cable 25-pin to 9-pin	2CA3001	<ul style="list-style-type: none">● Short 25-pin to 9-pin adapter cable

1.10 Dangers, Warnings and Cautions

Dangers, Warnings, and Cautions point out potential trouble areas. All three of these precautions are enclosed in a box to call attention to them.

DANGER

A *DANGER* ALERTS A PERSON OF A CONDITION WHICH COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

WARNING

A *WARNING* ALERTS A PERSON OF A CONDITION WHICH COULD RESULT IN POTENTIAL BODILY INJURY IF PROCEDURES ARE NOT FOLLOWED.

CAUTION: A *caution* alerts a person of a condition which could result in damage to, or destruction of the equipment.

2.0 DRIVE SPECIFICATIONS

2.1 Drive Ratings

The GV3000 drive is intended to operate from a three-phase A-C power source at the rated voltage listed on the drive nameplate. It can operate on a 50 or 60 Hz line frequency. The drive provides three-phase variable voltage and variable frequency to the motor. NEMA 1, 4X(Indoor Only) and 12, and NEMA 12 only drive current ratings, power loss and operating specifications are listed in table 2.1.

Table 2.1 - GV3000 Drive Application Data

Three-Phase Input Power Ratings								
Model NEMA 1 NEMA 4X/12 NEMA 12	1V4122 1V4422 –	2V4122 2V4422 –	3V4122 3V4422 –	5V4122 5V4422 –	7V4122 7V4422 –	10V4122 10V4422 –	15V4122 – 15V4222	20V4122 – 20V4222
Horsepower HP	1 HP	2 HP	3HP	5HP	7.5 HP	10 HP	15 HP	20 HP
Input Voltage	380–460 VAC ± 10%							
Input KVA	2.0	3.3	5.1	7.9	10.7	13.4	20.2	26.1
Input Amps [maximum]	2.5	4.2	6.4	9.9	13.4	16.8	25.4	32.7
Output Amps [maximum]	2.1	3.4	5.3	8.2	11.1	13.9	21.0	27.0
Power loss Watts [Full Load]	60	100	140	180	210	250	375	600
Operating Specifications								
A-C Line Distribution System Capacity (maximum): For 460 VAC Units -	1000 KVA , three-phase with 25,000 amps symmetrical fault current capacity with a line impedance of less than 8%.							
Acceleration Adjustment Range:	0.1 to 999.9 seconds (within the capability of current)							
Atmosphere:	5 to 95% non-condensing humidity							
Analog Speed Reference Accuracy	0.5%							
Carrier Frequency:	2 kHz, 4 kHz, or 8 kHz, software-selectable							
Current Limit Adjustment:	U.006 to 150% (based on drive nameplate rating)							
Control Method:	All Digital Flux Vector, Sinusoidal Pulse Width Modulated (PWM)							
Displacement Power Factor:	0.96							
Elevation:	To 3000 feet (1000 meters) above sea level without derating. For every 300 feet (91.4 meters) from 3300 to 10,000 feet (1001 to 3033 meters), derate the current by 1%. Consult your Reliance Electric sales office for operation above 10,000 feet (3033 meters).							
Line Frequency:	50 +/- 5 Hz or 60 +/- 5 Hz							
Line Voltage Variation:	–10% to + 10%							
Line Dip Ride Through:	Maximum 500 milliseconds (8 kHz with 100% load, 2 kHz or 4 kHz with 80% load; See parameter P.047 in section 6 for more information)							

Table 2.1 - GV3000 Drive Application Data (continued)

Maximum Pulse Tach Input Frequency:	125 kHz
Motor Poles	2, 4, 6, or 8 poles
Overcurrent IET:	200% load (based on drive nameplate rating)
Overload Current Rating:	150% for one minute (based on drive nameplate rating)
Service Factor:	1.0
Speed Control Range:	1:600 with 1024 PPR
Speed Control Response:	15 Hz (typical)
Speed Feedback:	15 V differential quadrature, pulse tachometer incremental (512 PPR, 1024 PPR, 2048 PPR, 4096 PPR)
WARNING	
<p>THIS DRIVE IS CAPABLE OF OPERATING AT AND MAINTAINING ZERO SPEED. THE USER IS RESPONSIBLE FOR ASSURING SAFE CONDITIONS FOR OPERATING PERSONNEL BY PROVIDING SUITABLE GUARDS, AUDIBLE OR VISUAL ALARMS, OR OTHER DEVICES TO INDICATE THAT THE DRIVE IS OPERATING OR MAY OPERATE AT OR NEAR ZERO SPEED. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.</p>	
Speed Adjustable Range:	From 0 RPM to Maximum Speed
Speed Regulation:	0.1% for a 20 millisecond period (typical)
Speed Setpoint Resolution:	+/-1 RPM, with local keypad +/-4095 of rated RPM with personal computer
Temperature : Ambient - Storage -	0° C to 40° C (32° F to 104° F) for enclosed drives 0° C to 40° C (32° F to 104° F) for open chassis drives -40° C to 65° C (-40° F to 149° F)
Torque Control Response:	180–220 Hz (typical)
Torque Linearity:	+/- 3% with optimal parameter setting (typical) (see parameter U.005 in section 6)
Zero Speed Control with:	0 - +/- 150% torque generation capability

2.2 Drive Input/Output Specifications

The drive input/output specifications are subject to some of the parameter settings which can be adjusted for user specified applications. The drive contains an internal isolated 24 VDC power supply to provide the required voltage for control signals. Enabling or disabling a control signal requires applying 24 VDC into an 8 mA input load. All of control signals (except Function Loss and Digital Input RAMP1/2) are *only* active when the control source is the terminal block (REMOTE mode). Function Loss and digital input for RAMP1/2 are *always* active in LOCAL or REMOTE modes (Refer to *section 6, Adjusting Parameters* for information on all drive parameters. Refer to *section 3, Installation and Wiring* for all drive installation information.)

The drive requires pulse tachometer feedback from the motor shaft for proper operation. The drive's pulse tachometer inputs require either a 512, 1024, 2048, or 4096 PPR (pulse per revolution) quadrature tachometer with differential channel A and B outputs.

Drive configuration and monitoring can also performed with a personal computer using Configuration Executive 3000 software. (Refer to manual D2-3303, Configuration Executive 3000, for more information.)

Drive input and output specifications are listed in table 2.2.

Table 2.2 - GV3000 Drive Input and Output Specifications

Drive Inputs	
Speed Reference Input	<p>5 KΩ potentiometer (0 to +/- 10 VDC @ 50 KΩ input impedance) or 0-20 mA (@ 250 Ω input impedance) with 10-bit resolution. (Jumper-selectable by jumper J4; refer to section 3, table 3.6, terminals 12 - 15 on the control terminal block.)</p> <p>NOTE: The drive provides +15 VDC buffered through a 1.875 Kohm resistor.</p>
Stop	<p>Open Contact</p> <p>(Contact must be closed when drive is running. An open contact turns the drive "off". The drive will remain and/or be held off as long as contact is open.)</p>
Start	<p>Open to Closed Contact Transition - momentary or fixed contact closure</p> <p>(Edge-sensitive control input signal which must see an open to closed transition.)</p>
IET Reset	<p>Closed Contact = No Function Loss</p> <p>(Contact must be closed when drive is running. An open contact turns the drive "off", and causes a "FL" fault. The drive will remain and/or be held off as long as the contact is open.)</p>
Function Loss	
Run/Jog	<p>Closed Contact - Jog</p> <p>START contact must remain closed (or maintained) for JOG.</p>
Programmable Inputs (Qty 3) [Forward/Reverse] [Ramp 1 and 2] [Remote/Local] [MOP] [Multi-speed Presets]	<p>Depending on parameters P.007 and P.008, terminals 17 (Input 8), 18 (Input 7) and 19 (Input 6) can be a combination of the control signals listed.</p> <p>Refer to Parameter P.007 and P.008 for programmable combinations.</p>
Pulse Tachometer	<p>Pulses per revolution: 512, 1024, 2048, or 4096 PPR.</p> <p>Differential inputs: A, A not, B, B not</p> <p>Input impedance: 10K to common</p> <p style="padding-left: 40px;">Series 100 ohm, 3900 pF RC termination A to A not and B to B not</p> <p>Quadrature Phasing: 90° +/- 45°</p> <p>The drive provides a 15 VDC (Internally limited for 240 mA) power supply for pulse tachometer operation.</p>
Drive Outputs	
Analog Output	0 to 10 VDC or 4-20 mA scaled signal selected in Parameter P.012 as speed or torque feedback
Dynamic Braking Signal	Dynamic braking control signal which can be used with some types of optional Dynamic Braking kits.
Relay Output	250 VAC/ 30 VDC, 5 amp resistive relay output (1 Form A and 1 Form B contact specified by P.013.)
Drive Communications	
RS-232 Interface	<p>A single RS-232-C port for serial communications : RECV, XMIT, COMMON.</p> <p>Requires: Configuration Executive 3000 software</p> <p>These signals are accessible at the terminal block or through the 9-pin D-shell connector. Refer to figure 3.4 for terminal block locations.</p>

2.3 Motor Applications

The drive and motor must be sized for the load and speed requirements of the specific application. To obtain Motor Nameplate Horsepower, the drive's (sine wave) output ampere rating at the carrier frequency selected should be equal to or greater than the motor nameplate current. If the Motor Nameplate Amperes are HIGHER than the drive's (sine wave) output ampere rating, the motor HORSEPOWER should be DERATED by the ratio of drive (sine wave) output ampere rating to the motor nameplate current.

Per NEC, a motor thermostat, internal to the motor, must be installed; or, a motor overload relay, sized to protect the motor, must be connected between the motor and the drive output. The *electronic* motor overload parameter can be used and must be enabled to provide this protection. Refer to P.040 in section 6.

If the motor will be operated at speeds below one-half the motor's base speed, the motor overload relay will not protect the motor. A motor thermostat, internal to the motor, is required because it monitors the actual temperature of the motor windings.

3.0 INSTALLATION AND WIRING

DANGER

ONLY QUALIFIED ELECTRICAL PERSONNEL FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THIS EQUIPMENT AND THE HAZARDS INVOLVED SHOULD INSTALL, ADJUST, OPERATE, AND/OR SERVICE THIS EQUIPMENT. READ AND UNDERSTAND THIS MANUAL IN ITS ENTIRETY BEFORE PROCEEDING. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

DANGER

THE USER IS RESPONSIBLE FOR CONFORMING TO THE NATIONAL ELECTRICAL CODE (NEC) AND ALL OTHER APPLICABLE LOCAL CODES. WIRING, GROUNDING, DISCONNECTS, AND OVERCURRENT PROTECTION ARE OF PARTICULAR IMPORTANCE. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

CAUTION: Use of power correction capacitors on the output of the drive can result in erratic operation of the motor, nuisance tripping, and/or permanent damage to the drive. Remove power factor capacitors before proceeding. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

3.1 Planning and Location

Planning before installation is necessary to ensure that the drive environment and operation conditions are satisfactory. Read and follow the recommendations advised in this section before proceeding with the installation.

1. Verify that the drive can be kept clean and cool.
2. Check that the drive will be away from oil, coolants, or other airborne contaminants.
3. Check that the temperatures within the vicinity of the drive are between 0° to 40°C (32° to 104°F).
4. Check that the relative humidity is between 5 and 95% noncondensing.
5. Do not install above 3300 feet (1000 meters) without derating. For every 300 feet (91.4 meters) above 3300 feet, derate the current rating by 1%. Consult Reliance Electric Sales for operation above 10,000 feet.
6. Check that the area chosen will allow the space required for air flow around the drive.

3.2 Mounting the Drive

The dimensional size of GV3000 drive models will vary depending horsepower rating (HP). Refer to figures 3.1-3.3 to determine the appropriate dimensional size for a given GV3000 drive model. When mounting a drive, adhere to the guidelines and physical diagrams for the specific horsepower type.

1. In the location selected, mount the drive vertically using the four (4) mounting holes provided on the drive base. See figures 3.1, 3.2, and 3.3 for the mounting dimensions of the drive.
2. Use the following as reference to provide adequate clearances for ventilation:
 - At least 4 inches from the sides and 4 inches from the top and bottom of the drive to adjacent non-heat producing equipment, such as a cabinet wall.
 - At least 4 inches from the sides and 10 inches from the top and bottom of adjacent drives. For best air movement with three or more drives, do not mount the drives in a vertical stack (i.e., offset (stagger) the drives).




Figure 3.1 - GV3000 Drive Physical Dimensions (460 VAC 1,2,3 and 5 HP)




Figure 3.2 - GV3000 Drive Physical Dimensions (460 VAC 7.5 and 10 HP)




Figure 3.3 - GV3000 Drive Physical Dimensions (460 VAC 15 and 20 HP)

3.3 Install an External Input Disconnect

DANGER

THE NEC/CEC REQUIRES THAT UPSTREAM BRANCH PROTECTION BE PROVIDED TO PROTECT INPUT POWER WIRING. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

1. Install an input disconnect in the incoming power line according to the NEC/CEC guidelines.
2. Size the disconnect according to the in-rush current as well as any additional loads the disconnect may supply.

NOTE: Coordinate the trip rating for the in-rush current (10-12 times full load current) with that of a transformer (if used). See section 3.5, Transformer and Reactor Installation (If Needed).

3.4 Install A-C Branch Circuit Protection

DANGER

THE NEC/CEC REQUIRES THAT UPSTREAM BRANCH PROTECTION BE PROVIDED TO PROTECT INPUT POWER WIRING. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

NOTE: *The input fuse ratings listed in table 3.1 are applicable for one drive per branch circuit. No other load can be applied to that fused branch circuit.*

1. Install user-supplied branch circuit protection according to the NEC/CEC guidelines.
2. Size the branch circuit protection for the specific drive model according to the values given in table 3.1.

Table 3.1 - Three-Phase A-C Input Line Branch Circuit Protection

Model Number	Horsepower (HP)	Input Voltage (VAC)	Input A-C Fuse Rating (A) ⁽¹⁾
1V4122 1V4422	1	380-460	6
2V4122 2V4422	2		8
3V4122 3V4422	3		12
5V4122 5V4422	5		25
7V4122 7V4422	7.5		25
10V4122 10V4422	10		35
15V4122 15V4222	15		45
20V4122 20V4222	20		55

(1) The recommended fuse type is UL Class J, 600V, time-delay.

3.5 Transformer and Reactor Installation (If Needed)

Transformers can be either autotransformers or isolation transformers. Isolation transformers help eliminate the following:

- Damaging A-C line voltage transients from reaching the drive.
- Line noise from the drive back to the incoming power.
- Damaging currents which could develop if a point inside the drive becomes grounded.

3.5.1 Input Transformers

If an input transformer is installed ahead of the drive, adhere to the following:

1. A power disconnecting device must be installed between the power line and the primary of the transformer.
2. If the power disconnecting device is a circuit breaker, the circuit breaker trip rating must be coordinated with the in-rush of current (10 to 12 times full load current) of the transformer.
3. An input transformer rated more than 1000 KVA for 460 VAC with less than 5% impedance should NOT be used directly ahead of the drive without additional impedance between the drive and the transformer.

CAUTION: Distribution system capacity above the maximum recommended system KVA (1000 KVA for 460 VAC) requires using an isolation transformer, a line reactor, or other means of adding similar impedance to the drive power input. Failure to observe these precautions could result in damage to, or destruction of, the equipment.

CAUTION: When the A-C line is shared directly with other SCR-rectified drives, a line reactor or optional DB kit may be required to alleviate excess D-C bus voltage. Failure to observe these precautions could result in damage to, or destruction of, the equipment.

3.5.2 Output Reactors

In applications requiring the use of an output reactor on the drive, contact your Reliance Electric sales office for assistance.

3.6 Grounding the Drive

Use the following steps to ground the drive.

DANGER

THE USER IS RESPONSIBLE FOR CONFORMING TO THE NEC/CEC AND ALL OTHER APPLICABLE CODES. WIRING, GROUNDING, DISCONNECTS, AND OVERCURRENT PROTECTION ARE OF PARTICULAR IMPORTANCE. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

1. Loosen the four (4) captive screws and remove the cover. When installing the cover on the drive, refer to *section 5: Cover Installation for Nema 4X(Indoor Only)/12 Drive*.
2. Run a suitable equipment grounding conductor unbroken from the drive ground terminal (See figure 3.2) to the earth ground conductor.
3. Connect a suitable equipment grounding conductor to the motor frame, the remote control station (if used), and the transformer. Run each conductor **unbroken** to the earth ground.

3.7 Wiring the Drive

Size and install all wiring in conformance with the NEC/CEC and all other applicable local codes. If not already done, loosen the four (4) captive screws on the cover and remove the cover from the drive base. Refer to figures 3.4-3.6 for jumper and wiring locations on GV3000 drives. Follow all recommended wire sizes and tightening torque specifications.

CAUTION: Do not route signal and control wiring with power wiring in the same conduit. This may cause interference with drive operation. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

NOTE: As a general rule, route the signal wiring and control wiring in separate conduits to prevent interference with drive operation.

WARNING

THE GV3000 DRIVE IS NOT EQUIPPED WITH A COAST-STOP PUSHBUTTON. THE USER MUST INSTALL A HARDWIRED, OPERATOR-ACCESSIBLE PUSHBUTTON THAT PROVIDES A POSITIVE INTERRUPT AND SHUTS DOWN THE DRIVE. (USE TERMINALS 16 AND 20. SEE FIGURE 3.9). FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.

Figure 3.5 - GV3000 Wiring Locations (460 VAC 7.5 and 10 HP)





Figure 3.4 - GV3000 Wiring Locations (460 VAC 1,2,3, and 5 HP)






Figure 3.6 - GV3000 Wiring Locations (460 VAC 15 and 20 HP)

3.7.1 Power Wiring

Size and install all wiring in conformance with the NEC/CEC and all other applicable local codes. Refer to figure 3.7 or 3.8 when making wire connections to the power terminal strip.

- Verify that the input power to the drive corresponds to the drive nameplate voltage and frequency and that the plant supply is of sufficient capacity to support the input current requirements. (Refer to section 2.2.)
- Provide a transformer between the plant power supply and the drive if the correct input line voltage is not available. (Refer to section 3.5.)
- Size upstream branch circuit protection (fuses) according to table 3.1.




Figure 3.7 - Power Terminal Strip Wiring (460 VAC 1-10 HP)




Figure 3.8 - Power Terminal Strip Wiring (460 VAC 15 and 20 HP)

- Size the input and output wiring to handle the rated current. (Refer to table 2.1 for maximum drive current.) The power terminal block accepts 12-18 AWG wire for 1-10 HP drives and 6-14 AWG wire for 15 and 20 HP drives.
- Tighten all wire connections to the power terminal to 9-12 in-lbs.

CAUTION: Do not route signal wiring with power wiring in the same conduit. This may cause interference with drive operation. Failure to observe this precaution could result in damage to, or destruction of the equipment.

- Wire the power input leads. Route A-C input power leads through the bottom right (far right) opening of the drive base, as indicated in figures 3.4-3.6, to the input terminals R(L1), S(L2), and T(L3).

3.7.2 Control and Signal Wiring

For proper GV3000 drive operation, a pulse tachometer must be properly installed. See table 3.6 for terminal wiring connections.


Size and install all wiring in conformance with the NEC/CEC and all other applicable local codes. Refer to figure 3.9 and table 3.2 when making wire connections to the control terminal strip.

NOTE: Asserted contact or switch means that it's closed while an unasserted contact or switch means that it's open.

CAUTION: Make sure electrical commons are not intermixed in the drive. Failure to observe this precaution could result in damage to, or destruction of the equipment.

- For all signal/pulsetach wiring, use twisted pair wire having two or three twists per inch.
NOTE: If using shielded twisted pair wire rather than twisted wire, the shields should not attach to any ground point; they should "float".
- For distances of up to 1000 feet, use a minimum of #20 AWG wire. For distances of more than 1000 feet, contact your Reliance Electric Sales Office.
- Use 14–20 AWG wire for all control and signal wiring.
- Tighten all wire connections to the control and signal terminal block to 7 in-lbs maximum torque.
- Route the signal wiring (RS-232, Pulse Tach, Analog Output, and Analog Speed Reference) and control wiring (Digital Inputs, Dynamic Braking Control, and Status Relays) to the drive as shown in figures 3.4-3.6.
- Refer to table 3.2 for all signal and control wiring connections.


NOTE: The factory-installed jumper between terminals 16 and 20 (Refer to figure 3.9) must be removed when installing a coast-stop pushbutton as shown in table 3.2.



GV3000 460V 15-20HP. ONLY

NOTES:

- <1. CONNECTIONS TO THE RS-232 SHOULD ONLY BE MADE WHEN NOT USING PC COM PORT (J8) AND AN OPERATOR INTERFACE MODULE (OIM). THE CONTROL TERMINAL, PC COM PORT, AND THE OIM USE THE SAME TRANSMIT AND RECEIVE LINES.
- <2. PROPER JUMPING OF J17 IS REQUIRED TO SELECT A VOLTAGE SOURCE (0-10 VDC) OR A SINKING CURRENT (0-20 mA) AT THE ANALOG OUTPUT. THE OUTPUT MUST ALSO BE CONFIGURED, VIA PARAMETER P.024, FOR AN INDICATION OF SPEED AND DIRECTION OR PERCENT TORQUE.
- <3. PROPER JUMPING OF J4 IS REQUIRED TO SELECT A VOLTAGE (+/- 0-10 VDC) OR CURRENT (+/- 0-20 mA) SOURCE FOR THE ANALOG SPEED REFERENCE.
- <4. A FACTORY JUMPER CONNECTED TO TERMINALS 16 AND 20 (OR 16A AND 20A) MUST BE REMOVED WHEN A USER-INSTALLED FUNCTION LOSS INPUT, A COAST-TO-STOP PUSHBUTTON, OR OTHER INTERLOCK IS INSTALLED SO THAT THE CONTACT WILL OPEN TO STOP THE CONTROLLER.
- <5. TERMINALS 19, 18 AND, 17 (DIGITAL INPUTS 6, 7 AND 8) ARE CONFIGURABLE USING PARAMETERS P.007, P.008 AND P.031 THRU P.037. FACTORY DEFAULT SETTINGS SHOWN IN PARENTHESES.
- <6. RELAY CONTACT CLOSURE IS CONFIGURABLE VIA PARAMETER P.013. SEE SECTION 6.5 FOR MORE INFORMATION.



ALL CUSTOMER WIRING COMES IN AT THE BOTTOM OF THE CONTROL TERMINAL STRIP

Figure 3.9 - Control Terminal Wiring Locations

Table 3.2 - Control Terminal Wiring







Terminal Number	Description	See Parameters/Remarks						
	RS-232 Connections	<p>Notes: <i>RS-232 communication between the GV3000 drive and a personal computer requires the use of Configuration Executive 3000 software. Refer to Instruction manual D2-3303, Configuration Executive 3000, for additional hardware and software requirements.</i></p>						
<p>1 2 3</p>	<p>RS-232 Transmit RS-232 Receive RS-232 Signal Common (Regulator common)</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; padding: 5px;"> <p>GV3000 DRIVE CONTROL TERMINAL</p>  </td> <td style="width: 50%; padding: 5px;"> <p>PERSONAL COMPUTER 25 PIN D-SHELL, MALE -OR- 9 PIN D-SHELL, PLUG</p>  </td> </tr> <tr> <td colspan="2" style="text-align: center; padding: 10px;">  </td> </tr> <tr> <td colspan="2" style="text-align: center; padding: 5px;"> <p>WIRE LENGTH - 50 FEET [MAX]</p> </td> </tr> </table>	<p>GV3000 DRIVE CONTROL TERMINAL</p> 	<p>PERSONAL COMPUTER 25 PIN D-SHELL, MALE -OR- 9 PIN D-SHELL, PLUG</p> 			<p>WIRE LENGTH - 50 FEET [MAX]</p>	
<p>GV3000 DRIVE CONTROL TERMINAL</p> 	<p>PERSONAL COMPUTER 25 PIN D-SHELL, MALE -OR- 9 PIN D-SHELL, PLUG</p> 							
								
<p>WIRE LENGTH - 50 FEET [MAX]</p>								

Table 3.2 - Control Terminal Wiring (Continued)





Terminal Number	Description	See Parameters/Remarks														
	Pulse Tach Connections	<div style="border: 1px solid black; padding: 5px; text-align: center; margin-bottom: 10px;">WARNING</div> <p>THE SETTING OF THE VARIABLES U.001 (PULSE TACHOMETER SELECTION), U.002 (MOTOR POLE NUMBER), U.003 (MOTOR BASE FREQUENCY) AND U.005 (MOTOR RATED SPEED) DETERMINE MOTOR MAXIMUM SPEED. THESE VARIABLES MUST BE SET BY A QUALIFIED PERSON WHO UNDERSTANDS THE SIGNIFICANCE OF SETTING THEM ACCURATELY. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.</p> <p>P.050 - Restore Default Settings U.001 - (Pulse tachometer selection), U.002 - (Motor pole number) U.003 - (Motor base frequency) U.005 - (Motor rated speed)</p>														
4 5 6 7 8 9	Pulse Tach Supply +15 VDC Pulse Tach Phase A Differential Input Pulse Tach Phase A Not Differential Input Pulse Tach Phase B Differential Input Pulse Tach Phase B Not Differential Input Pulse Tach Common (Regulator Common)	<div style="border: 1px solid black; padding: 10px;"> <p style="text-align: center;">REAR OF PULSE TACH CONNECTOR</p>  <table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">TERMINAL</th> <th style="text-align: right;">CONNECTOR</th> </tr> </thead> <tbody> <tr> <td>TERMINAL 6</td> <td style="text-align: right;">PIN 1 PHASE A</td> </tr> <tr> <td>TERMINAL 5</td> <td style="text-align: right;">PIN 2 PHASE A NOT</td> </tr> <tr> <td>TERMINAL 4</td> <td style="text-align: right;">PIN 6 0 VDC</td> </tr> <tr> <td>TERMINAL 9</td> <td style="text-align: right;">PIN 12 +15 VDC</td> </tr> <tr> <td>TERMINAL 7</td> <td style="text-align: right;">PIN 8 PHASE B</td> </tr> <tr> <td>TERMINAL 8</td> <td style="text-align: right;">PIN 9 PHASE B NOT</td> </tr> </tbody> </table> <p style="text-align: center; margin-top: 20px;">MOTOR ENCODER CABLE KITS</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>TO MOTOR ENCODER</p>  <p>MODEL NUMBER 2TC4025 - LENGTH 25 FEET 2TC4075 - LENGTH 75 FEET</p> </div> <div style="text-align: center;"> <p>TO GV3000 DRIVE CONTROL TERMINAL STRIP</p>  </div> </div> <div style="text-align: center; margin-top: 20px;"> <p>MODEL NUMBER 2TC4100 - LENGTH 100 FEET 2TC4300 - LENGTH 300 FEET</p>  </div> <p style="font-size: small; margin-top: 10px;">NOTE: REFER TO SECTION 1.9, DRIVE OPTIONS, FOR MORE INFORMATION.</p> </div>	TERMINAL	CONNECTOR	TERMINAL 6	PIN 1 PHASE A	TERMINAL 5	PIN 2 PHASE A NOT	TERMINAL 4	PIN 6 0 VDC	TERMINAL 9	PIN 12 +15 VDC	TERMINAL 7	PIN 8 PHASE B	TERMINAL 8	PIN 9 PHASE B NOT
TERMINAL	CONNECTOR															
TERMINAL 6	PIN 1 PHASE A															
TERMINAL 5	PIN 2 PHASE A NOT															
TERMINAL 4	PIN 6 0 VDC															
TERMINAL 9	PIN 12 +15 VDC															
TERMINAL 7	PIN 8 PHASE B															
TERMINAL 8	PIN 9 PHASE B NOT															

Table 3.2 - Control Terminal Wiring (Continued)


Terminal Number	Description	See Parameters/Remarks
	Analog Output	P.012 - Terminal Block Analog Output Source selection (Speed or Torque) Proper jumpering of J17 (Refer to analog input and output jumper settings following this table.)
10 11	(0-10 VDC) -or- (4-20 mA) Analog output reference (Regulator common)	
	Analog Speed Reference	P.000 - Operation Control P.009 - Terminal Block Analog Speed Reference Offset P.010 - Terminal Block Analog Speed Reference Gain P.011 - Terminal Block Analog Speed Reference Invert Selection Proper jumpering of J4 (Refer to analog input and output jumper settings following this table.)
12 13 14 15	Isolated Reference Voltage (Isolated +15 VDC) +/- 10 VDC Analog Speed Reference Input Voltage 0 - 20 mA Analog Speed Reference Input Current Isolated Speed Reference common (Voltage/Current)	 <p style="text-align: center;">INPUT SPEED REFERENCE</p>

Table 3.2 - Control Terminal Wiring (Continued)




Terminal Number	Description	See Parameters/Remarks
	<p>Digital Inputs (6, 7, and 8) (Digital Inputs 6,7 and 8 are configurable.) The diagrams provided below reflect the factory settings only for digital inputs 6,7 and 8.</p>	<p>P.000 - Operation Control P.006 - Expand to Second Menu List (requires password) P.007 - Terminal Block Digital Input Configure (Selects and assigns control function to Digital input 6, Digital input 7, and Digital input 8.) P.008 - Terminal Block Speed Reference Selection (Analog, MOP, or Multi-speed presets) NOTES: <i>Based on the selections made in P.000, P.007 and P.008, the following parameters can also affect digital inputs 6,7, and 8:</i> P.023 - MOP Reference Rate for Increment/Decrement P.024 - MOP Reset P.031 through P.038 - Multi-Speed Presets 1 through 8</p>
<p>16 17</p>	<p>+24 VDC isolated supply Digital Input (8) - REMOTE/LOCAL</p>	<p>P.000 - Operation Control Source. Only active when P.000 = rE</p>  <p>Terminal 17 Asserted = Local control</p>
<p>18</p>	<p>Digital Input (7) - RAMP1/RAMP2</p>	<p>P.001 - Acceleration Time (Ramp1) P.002 - Deceleration Time (Ramp1) P.017 - Acceleration Time (Ramp2) P.018 - Deceleration Time (Ramp2)</p>  <p>Terminal 18 Asserted = Ramp2</p>
<p>19</p>	<p>Digital Input (6) - FORWARD/REVERSE</p>	<p>P.027 - Reverse Disable</p>  <p>P.027 = ON (ENABLED) FORWARD DIRECTION ONLY</p> <p>Terminal 19 asserted = Reverse Direction NOTE: <i>From the Pulse Tach end of the motor, a clockwise rotation indicates a Forward motor direction.</i></p>

Table 3.2 - Control Terminal Wiring (Continued)






Terminal Number	Description	See Parameters/Remarks
20	<p>Digital Inputs (1,2,3,4,5)</p> <p>Digital Input (5) - FUNCTION LOSS</p>	<p>P.000 - Operation Control</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <p>WARNING</p> <p>THE DRIVE IS NOT EQUIPPED WITH A COAST-STOP PUSHBUTTON. THE USER MUST INSTALL A HARDWIRED OPERATOR ACCESSIBLE PUSHBUTTON THAT PROVIDES A POSITIVE INTERRUPT AND SHUTS DOWN THE DRIVE. (USE TERMINALS 16 AND 20 FOR THE FUNCTION LOSS INTERRUPT.) FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.</p> </div> <p>P.026 - Function Loss Selection</p>  <p>Terminal 20 Asserted = No Function Loss</p>
21	<p>Digital Input (4) - RUN/JOG</p>	<p>P.020 - Jog Speed Reference P.021 - Jog Ramp Acceleration Time P.022 - Jog Ramp Deceleration Time</p>  <p>Terminal 21 Asserted = Jog Operation</p>
22	<p>Digital Input (3) - RESET</p>	 <p>Terminal 22 Asserted Transition = Reset</p>

Table 3.2 - Control Terminal Wiring (Continued)

Terminal Number	Description	See Parameters/Remarks
23 24	Digital Input (2) - STOP Digital Input (1) - START	<p>P.025 - Stop Type Selection (coast or ramp)</p>  <p>Terminal 23 Unasserted = Stop Terminal 24 Assert Transition = Start</p>
25	24 VDC Isolated common	
Dynamic Braking		
26 27	Dynamic Braking control signal Dynamic Braking control common	Used with Dynamic Braking Kit model number 2DB4010. Refer to the kit instruction manual for proper installation with drive.
Relay Output		
<p>Both Form A and B contacts rated for 250 VAC/30 VDC at 5 amps resistive or 2 amps inductive load.</p> <p>P.013 - Output Relay Configuration</p> <p><i>NOTE: Depending on the setting of P.013, the relay coil will energize (normally open contact CLOSES and the normally closed contact OPENS). See section 6.5 for a description of the P.013 options.</i></p>		
28 29 30 31	Form B - Normally Closed Contact Form B - Normally Closed Contact common Form A - Normally Open Contact Form A - Normally Open Contact common	 <p>PARAMETER P.013 SELECTS OUTPUT INDICATION</p>

3.8 Analog Input Speed Reference and Analog Output Jumper Setting

Located on the regulator board (refer to figures 3.3 and 3.4) are the analog speed reference jumper (J4) and the analog output jumper (J17). The analog speed reference jumper provides for a jumper-selectable +/- 10 VDC or 0 - 20 mA speed input with software programmable gain (P.010), offset adjustment (P.009), and signal inversion (P.011). The analog output jumper provides for a jumper-selectable 0-10 VDC or 4-20 mA scaled output signal software selectable (P.012) for either speed or torque. (Refer to section 6 for more information on parameters P.009, P.010, P.011, and P.012.)

NOTE: If the position of the analog speed reference jumper (J4) is changed, the software does not recognize that the input reference has been changed from 10 VDC to 20 mA, or vice versa. The software also will not recognize a polarity change for either voltage or current input reference. Verify the input reference polarity (P.011), and that calculations for the reference gain (P.010) and offset (P.009) parameters are correct before starting the drive.

The position of the analog output jumper (J17) does not have to be recognized by the software. The jumper is used only to select a scaled 0-10 VDC source voltage or 4-20 mA sink current to represent speed or torque.

3.8.1 Changing the Analog Input Speed Reference Jumper (J4)

DANGER

AFTER DISCONNECTING INPUT POWER, WAIT FIVE MINUTES AND CHECK WITH A VOLTMETER TO INSURE THAT D-C BUS VOLTAGE CAPACITORS ARE DISCHARGED. THE VOLTMETER SHOULD READ ZERO VOLTS D-C. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

1. Turn off power supplied to the drive.
2. If not already done, loosen the four (4) attaching screws and remove the cover from the drive.
3. Verify at the + and - power terminals that the D-C Bus voltage is zero (0) VDC. (Refer to figure 3.7 or 3.8.)
4. Locate jumper J4 on the drive's regulator board. Refer to figures 3.4-3.6.
5. Locate pin 1 of jumper J4 on the regulator board.

Move the jumper to the desired setting as shown in figure 3.10.




Figure 3.10 - Analog Input Speed Reference Jumper Setting (J4)

6. After moving jumper J4, verify (with each move) that parameters P.011 (reference polarity), P.009 (reference offset), and P.010 (reference gain) are correctly set.

3.8.2 Change the Analog Output Jumper (J17)

DANGER

AFTER DISCONNECTING INPUT POWER, WAIT FIVE MINUTES AND CHECK WITH A VOLTMETER TO INSURE THAT D-C BUS VOLTAGE CAPACITORS ARE DISCHARGED. THE VOLTMETER SHOULD READ ZERO VOLTS D-C. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

1. Turn off power supplied to the drive.
2. If not already done, loosen the four (4) attaching screws and remove the cover from the drive.
3. Verify at the + and - power terminals that the D-C bus voltage is zero (0) VDC. (Refer to figure 3.7 or 3.8.)
4. Locate jumper J17 on the drive's regulator board. Refer to figures 3.4 - 3.6.
5. Locate pin 1 of jumper J17 on the regulator board.
6. Move the jumper to the desired setting as shown in figure 3.10.




Figure 3.11 - Analog Output Jumper Setting (J17)

7. After moving jumper J17, verify (with each move) that parameter (P.012) is correctly set for either speed or torque.

3.9 Optional Snubber Braking Wiring

1. Route the snubber braking power and control signal wiring (if required) through the opening at the bottom center opening of the drive.
2. Install the snubber braking kit according to the kit instruction manual.

3.10 RS-232 Wiring (NEMA 1)

Located on the regulator board (refer to figures 3.4-3.6) is the drive's RS-232 communications connector (J8). NEMA 1 drive covers contain an access door for easy cable installation. Simply raise the access door in the cover and attach the communication cable to the drive's RS-232 connector (J8). Two communications cables are available; a 12 foot D-shell 9-pin to 9-pin cable (615184 - 1A) and a 1 foot D-shell 9-pin to 25-pin adaptor cable (615184 - 2A). RS-232 communication between the GV3000 drive and a personal computer also requires the use of Configuration Executive 3000 software. Refer to instruction manual D2-3303, Configuration Executive 3000, for additional information.

3.11 Motor Preparation

1. Install the motor according to the motor instruction manual.
2. Verify that the motor is the appropriate size to use with the drive.
3. Verify that the total lead lengths on each phase does not exceed 250 feet per phase.
4. Verify that the motor is properly aligned with the driven machine to minimize unnecessary motor loading from shaft misalignment.
5. If the motor is accessible while running, install a protective guard around all exposed rotating parts.

NOTE: In applications requiring the use of an output reactor on the drive, contact your Reliance Electric sales office for assistance.

4.0 USING THE GV3000 KEYPAD

The GV3000 front panel keypad/display is used to program and operate the drive. It can display seven different output displays, along with parameter numbers and their values by switching from "Display Mode" to "Program Mode". Figure 4.1 shows the keypad and gives a description of each key and indicator.




Figure 4.1 - GV3000 Front Panel Keypad/Display

4.1 Viewing or Changing Parameters in the First Menu List (Parameters P.000 - P.006):

Displays and keypad actions for changing parameters in the first menu list are shown in figure 4.2.




Figure 4.2 - First Menu List Parameter Displays

Action	Display/Notes
1. Press the PROGRAM key.	Display shows "P.---" and the PROGRAM LED goes on.
2. If the display does not show "P.---", press the ▲ or ▼ key until it does.	
3. Press the ENTER key.	Display shows "P.000", the first parameter number in the first menu General Parameter list, or the last parameter number already accessed.
4. Press the ▲ key to move up through the first menu list containing parameters P.000 through P.006.	▲ key: Display shows "P.000", "P.001", etc.
5. Once the desired parameter is displayed, press the ENTER key.	Display shows the parameter "value".
6. Press the ▲ key to increase the value, or the ▼ key to decrease the value.	
7. Press the ENTER key to enter the value.	<i>Note: The value will not be written into memory unless the ENTER key has been pressed.</i>
8. Go to the next parameter number, and so on.	
9. Press the PROGRAM key twice to exit the PROGRAM mode.	The PROGRAM LED goes OFF.

4.2 Viewing or Changing Parameters in the Second Menu List (Parameters P.007 - P.065 and U.000 - U.013):

Displays and keypad actions for changing parameters in the second menu list are shown in figure 4.3.




Figure 4.3 - Second Menu List Parameter Displays

1. The password must be entered into P.006 before access to the second menu list is allowed. Follow the instructions below to enter the password for the second menu list.
2. Change parameters the same way as for the First Menu List Parameters.

WARNING

IT IS THE USER MANAGEMENT'S RESPONSIBILITY TO DISTRIBUTE THE SECURITY ACCESS CODES WITH DISCRETION WITHIN THEIR ORGANIZATIONAL LEVELS. RELIANCE ELECTRIC IS NOT RESPONSIBLE FOR UNAUTHORIZED PASSWORD ACCESS VIOLATIONS WITHIN THE USER'S ORGANIZATION. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

Action	Display/Notes
1. Press the PROGRAM key.	Display shows "P.---" and the PROGRAM LED goes on.
2. If the display does not show "P.---", press the ▲ or ▼ key until it does.	
3. Press the ENTER key.	Display shows "P.000", first parameter number in First Menu General Parameter List, or the last parameter number already accessed.
4. Press the ▲ key to move up through the first menu list until P.006 is displayed.	Display shows "P.006".
5. Press the ENTER key.	Display shows "0".
6. Press the ▲ key to increase the value until "607" is displayed. This is the password number.	(Holding down the key ▲ will increase the scroll speed). Display shows "607".
7. Press the ENTER key to enter the value.	The password has been entered. You can now access parameters in the second menu list, P.000 through P.065, or vector parameters U.000 through U.013.

4.3 Display Modes

Press the PROGRAM key until the PROGRAM LED goes out. The following display modes can be accessed as instructed below:

- | | |
|----------------------------------|--|
| 1. RPM Display Mode: | Displays the motor speed in RPM. |
| 2. VOLTS Display Mode: | Displays the drive output volts |
| 3. AMPS Display Mode: | Displays the drive output amps. |
| 4. HZ Display Mode: | Displays the drive output frequency. |
| 5. KW Display Mode: | Displays the drive output KW. |
| 6. TORQUE Display Mode: | Displays the motor output torque. |
| 7. Speed Reference Display Mode: | Displays the speed reference from the selected control source. |

4.3.1 Viewing a Display Mode

If you have just powered up, you are already in the default display mode, RPM. The RPM LED is ON, and the PROGRAM LED is OFF. Press the ENTER key to move from display mode to display mode. Each display mode LED will light -- RPM, VOLTS, AMPS, etc.--- when you have entered that mode.

If you are in PROGRAM mode (the PROGRAM LED is ON), press the PROGRAM key to exit the PROGRAM mode and enter the Display Mode. Then press the ENTER key to move from Display Mode to Display Mode.

4.3.2 Viewing the SPEED REFERENCE Display Mode

The SPEED REFERENCE from the selected control source can be viewed as follows:

Action	Display/Notes
1. Enter the Display Mode.	NOTE: <i>If the speed reference is positive, then all six LEDs are ON. If the speed reference is negative, the RPM LED remains OFF, and the other five display mode LEDs are ON.</i>
2. Press the ENTER key until you move through all display modes, and all six display mode LEDs are lit.	

4.4 Program Lockout

Programming of parameters can be disabled by accessing Parameter P.051, "Program Lockout".

Note: Similar to a hardware ON/OFF switch, you need to repeat the following steps to then "re-enable" programming.

WARNING	
IT IS THE USER MANAGEMENT'S RESPONSIBILITY TO DISTRIBUTE THE SECURITY ACCESS CODES WITH DISCRETION WITHIN THEIR ORGANIZATIONAL LEVELS. RELIANCE IS NOT RESPONSIBLE FOR UNAUTHORIZED PASSWORD ACCESS VIOLATIONS WITHIN THE USER'S ORGANIZATION. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.	

Action	Display/Notes
1. Follow instructions in section 4.2 to access the second menu list.	Parameter P.051 is in the second menu list. The password for Parameter P.006 must first be entered to access P.051. If the password has already been entered for P.006, bring up P.051 on the display.
2. Access P.051 on the display.	Display shows "P.051".
3. Press the ENTER key.	Display shows "0".
4. Press the  key until the number "1044" is displayed.	Display shows "1044".
5. Press the ENTER key.	Display shows "P.051". If the PASSWORD LED is lit, the ability to change parameter values has been disabled.

4.5 Viewing Fault Codes, Clearing the Error Log, or Viewing the Error Log Time Stamp

If a fault code is flashing on the display, (for example, "FL"), press the STOP/RESET key . If the fault occurs again, remove the cause of the fault. The fault log only stores the first ten faults. Any faults to occur after ten will not be logged. Make sure the error log is cleared often.

The error log contains the first ten (10) faults generated by the drive. They will be listed in the order of last-error-first to first-error-last, and will look like "2.FL", "1.DC", etc. Errors stored in the log can also be cleared from the log.

Displays and keypad actions for viewing faults codes, error log, and time stamp is shown in figure 4.4.




Figure 4.4 - Error Log and Time Stamp Displays

Action	Display/Notes
1. Press the PROGRAM key.	Example: Display shows "P.---". The PROGRAM LED goes ON.
2. Press the \blacktriangledown key until "ERR" is displayed.	Example: Display shows "ERR".
3. Press the ENTER key.	Example: Display shows the last fault to have occurred.
4. Scroll through the fault code list by pressing the \blacktriangle or \blacktriangledown key.	Note: When "CLR" is displayed, pressing the ENTER key will clear the error log. When a fault code is displayed, pressing the ENTER key will display the number of days since the last powerup, and then pressing the \blacktriangle or \blacktriangledown key will show HRS.MIN.

5.0 STARTING THE DRIVE

DANGER

ONLY QUALIFIED ELECTRICAL PERSONNEL FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THIS EQUIPMENT AND THE HAZARDS INVOLVED SHOULD START AND ADJUST IT. READ AND UNDERSTAND THIS MANUAL IN ITS ENTIRETY BEFORE PROCEEDING. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

5.1 Startup CheckList

1. Turn OFF, lockout or tag input power to the drive.

DANGER

AFTER DISCONNECTING INPUT POWER, WAIT FIVE MINUTES AND CHECK WITH A VOLTMETER AT TERMINALS (+) AND (-) TO INSURE THAT D-C BUS CAPACITORS ARE DISCHARGED. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

2. Verify that D-C bus volts is zero at terminals (+) and (-).

WARNING

THE GV3000 DRIVE IS NOT EQUIPPED WITH A COAST-STOP PUSHBUTTON. THE USER MUST INSTALL A HARDWIRED, OPERATOR-ACCESSIBLE PUSHBUTTON THAT PROVIDES A POSITIVE INTERRUPT AND SHUTS DOWN THE DRIVE. (USE TERMINALS 16 AND 20.) FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

3. Verify that the user-installed COAST-STOP pushbutton is installed. You must remove the factory installed jumper at terminals 16 and 20 for the COAST-STOP pushbutton to work.
4. Remove any debris from around the drive.
5. Check that there is adequate clearance around the drive.
6. Check and verify that the wiring to the control terminal strip and power terminals is correct.
7. Check that the wire size is within terminal specification and are tightened properly.
8. Check that user-supplied branch circuit protection is installed and correctly rated.
9. Check that the incoming A-C power is rated correctly.
10. Check the motor installation and length of motor leads.
11. Disconnect any power correction capacitors connected to the motor.
12. Uncouple the motor from any driven machinery to initially start the drive.
13. Check that the rating of the transformer (if used) matches the drive requirements, and is connected for the proper voltage.
14. Verify that a properly sized ground wire is installed and that a suitable earth ground is used. Check for and eliminate any grounds between the motor frame and the motor power leads. Verify that all ground leads are run unbroken.

5.2 Starting the Drive

5.2.1 Preparations for Self-Tuning

Self-tuning is a procedure required for vector operation and run by the drive that determines the proper no load current value for parameter U.006 and determines the pulse tach PPR value for U.001. These values are necessary so that rated motor torque, speed, and horsepower can be developed in the vector mode.

NOTE: *Self-tuning can only be run on motors with a base frequency of less than or equal to 60 Hz.*

DANGER

THE SUBSEQUENT STEPS REQUIRE ROTATING PARTS AND/OR ELECTRICAL CIRCUITS TO BE EXPOSED. STAY CLEAR IF UNIT MUST BE RUNNING OR DISCONNECT AND LOCKOUT OR TAG POWER SOURCE IF CONTACT MUST BE MADE. FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

1. Turn power ON.
2. Check all general parameter settings (P.000 - P.065 as applicable) and verify that they are set correctly.
3. Check that the following vector parameter values are correct before initiating self-tuning:

WARNING

THE USER IS RESPONSIBLE FOR ENSURING THAT DRIVEN MACHINERY, ALL DRIVE-TRAIN MECHANISMS, AND PROCESS LINE MATERIAL ARE CAPABLE OF SAFE OPERATION AT THE MAXIMUM OPERATING SPEED OF THE DRIVE. OVERSPEED DETECTION IN THE DRIVE DETERMINES WHEN THE DRIVE SHUTS DOWN AND IS FACTORY SET TO 130% OF MAXIMUM SPEED. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

- a. U.002 (motor pole number)
 - b. U.003 (motor base speed)
 - c. U.004 (motor rated amps)
 - d. U.005 (motor rated speed)
4. Verify that the motor is unloaded.
 5. The drive must not be running. Press the STOP/RESET key.
 6. Clear the error log of all errors. (Refer to "To View Fault Codes, Clear the Error Log, or View the Error Log Time Stamp", in section 4.5.)
 7. Set P.000 = 0 for Local operation, or =1 for Remote operation.

5.2.2 How to Stop the Self-Tuning Procedure

When self-tuning is enabled (parameter U.008 is turned ON), you can abort it by setting U.008 to OFF. If self-tuning is STARTED (display shows "S_AC"), press the STOP/RESET key.

5.2.3 What Happens if a Fault Occurs During Self-Tuning?

1. If a stop is commanded and self-tuning is aborted, the drive will shut off and coast to stop. An error message ("SF") is displayed.
2. Once self-tuning is stopped, parameter U.008 will be updated to OFF and the drive is taken out of the self-tuning mode.

5.2.4 Starting Self-Tuning

1. Enable the Self-Tuning parameter. Set U.008 = ON.
2. Exit the PROGRAM mode and enter the DISPLAY mode. (Press the PROGRAM key twice when in the parameter list. The display should show “S_EN” when the PROGRAM mode is exited, and the DISPLAY mode is entered.)

WARNING

THE MOTOR WILL ROTATE DURING THE SELF-TUNING PROCEDURE. STAY CLEAR OF ROTATING MACHINERY. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

3. Press the START key on the keypad. The display will show “S_AC” when self-tuning is running. The drive will ramp up to 90% of the motor base frequency and perform self-tuning calculations.

NOTE: *If self-tuning aborts, and “SF” is displayed during self-tuning, refer to section 7 for a complete action chart for troubleshooting.*

4. Once self-tuning is completed, the motor will ramp down to a stop, and parameters U.001 (Pulse Tachometer Selection) and U.006 (Percent Motor Magnetizing Amps) will be automatically updated. The display will return to the normal display mode. The self-tuning enable parameter, U.008, will be updated to “OFF”.
5. Parameter U.009 will indicate the self-tuning result. Refer to section 6, U.009 for a list of result codes.

5.3 Basic Drive Checks

1. Make sure that the drive interlocks installed around the driven machine are operational.
2. Check that any installed motor thermal overload switch and the drive’s electronic motor thermal overload parameter (P.040) is enabled (“ON”).
3. Press the START key. The motor should ramp to the preset speed at the acceleration rate set by P.001. The acceleration rate is the number of seconds from zero to rated RPM (U.005).
4. While the drive is in the RUN mode (the RUNNING LED is lit), check the display modes RPM, VOLTS, and AMPS and verify that they are reading correctly.

For REMOTE MODE: If using a remote speed reference, check using the SPEED REFERENCE DISPLAY MODE that the speed reference is correct (+/– 10VDC, or 0-20mA).

Take into account any values set into P.010 (Analog Reference Gain) and P.009 (Analog Reference Offset) that have scaled the speed reference.

5.4 Tuning the Speed Regulator

NOTE: *Tuning the speed regulator may not be required for the application.*

1. Turn OFF, lock out or tag input power to the drive.
2. Connect the application load to the motor.
3. Turn power ON.
4. Press the START key.
5. Adjust U.012 (Speed Regulator Proportional Gain) or U.013 (Speed Regulator Integral Gain) if necessary.

U.012 is the proportional gain of the speed regulator, which determines how smoothly and quickly the drive responds to request for speed changes. A typical value is 2.0. Larger values result in faster response, but may show less stability. If the motor speed “overshoots” the speed setpoint when changes to the speed reference are made, or if the motor speed is unstable, reduce the value of U.012.

5.5 Final Adjustments

When operation is satisfactory:

1. Turn OFF, lock out and tag power to the drive. Verify that the D-C bus has discharged to 0 VDC at terminals (+) and (–).
2. Replace the drive cover (if removed) and secure.
3. Make a note of final parameter settings in tables 8.1, 8.2 and 8.3.

5.6 Cover Installation, NEMA 4X (Indoor Only)/12 or NEMA 12 Only

In order to maintain integrity of the NEMA 4X/12 and NEMA 12 only enclosure, some care must be taken when re-installing the cover:

1. Before installing the cover, check to see that the gaskets on the cover are flat and within the gasket channels provided.
2. Position the cover and tighten the (4) captive screws, sequentially, to ensure even compression of the gaskets. Do not exceed 20 inch-pounds of torque on these screws.

6.0 ADJUSTING PARAMETERS

DANGER

ONLY QUALIFIED ELECTRICAL PERSONNEL FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THIS EQUIPMENT AND THE HAZARDS INVOLVED SHOULD START AND ADJUST IT. READ AND UNDERSTAND THIS MANUAL IN ITS ENTIRETY BEFORE PROCEEDING. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

6.1 Introduction to Parameters

The GV3000 software allows access to many parameters that are adjustable by using the keypad. The factory preset values will suit a wide range of applications. To configure the drive for a specific application, you can bring up each appropriate parameter on the display and adjust as necessary. The value of any drive parameter can be adjusted or changed while the drive is stopped. When the drive is running, the values of only certain drive parameters can be changed. These parameters are called “tunables.” The value of a tunable parameter can be changed at any time; the drive can be running or stopped. In the parameter descriptions that follow, the names of tunable parameters are followed by the word “tunable” in parentheses. Tables 8.1 through 8.3 give a complete list of all available parameters and their factory preset values. It also provides a space to check off or enter values as they are modified for recordkeeping.

6.2 Parameter Menus and Password Entry

To simplify the configuration process, the drive software parameter list is divided into two menu lists. The first menu contains seven parameters (P.000 through P.006). Parameters P.000 through P.006 are most commonly used for simple applications.

WARNING

IT IS THE USER MANAGEMENT’S RESPONSIBILITY TO DISTRIBUTE THE SECURITY ACCESS CODES WITH DISCRETION WITHIN THEIR ORGANIZATIONAL LEVELS. RELIANCE IS NOT RESPONSIBLE FOR UNAUTHORIZED PASSWORD ACCESS VIOLATIONS WITHIN THE USER’S ORGANIZATION. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

P.006 permits access to the second menu, and requires a password to be entered to get there. You cannot change or access general parameters P.007 through P.065 or any vector parameters U.000 through U.013 unless the correct password is entered into parameter P.006.

The second menu list (P.007 through P.065) allows access to more parameters to adjust the drive for more complex applications. These functions can be safety related and should be used only with a thorough understanding of how they may affect motor operation.

After entering the correct password into P.006, you can also obtain access to the vector parameters U.000 through U.013. This group of parameters is accessible by pressing the  key after “P.---” is displayed in PROGRAM mode, and then pressing the ENTER key.

The error log is located after the vector parameter group “U.---”, and is shown as “ERR” on the display. For more information on entering the error log or clearing errors, refer to section 4.5.

Factory set parameters (displayed as “F.---”) follow the error log, but cannot be accessed without a special service password. This password is not available to customers.

6.3 Configuring the Drive

Displays and keypad actions for configuring the drive are shown in figure 6.1.




Figure 6.1 - Configuring the Drive

Refer to figure 6.1.

1. Turn the power to the drive **ON** and wait for the drive to complete its self-diagnostic test.
2. Press the **STOP** key to confirm the drive is in the STOP mode.
3. Press the **PROGRAM** key: The display looks like: **[P.---**]
4. Press the **ENTER** key. The display looks like: **[P.000]**
5. *NOTE: Parameter P.051 (Program Lockout) will disable the PROGRAM mode if the correct password was entered. Program Lockout is indicated if the PASSWORD LED is lit. If you cannot modify any parameters, check that the Program Lockout is disabled, and if it is, re-enter the password and verify that the PASSWORD LED goes out.*
6. Using the **▲** and the **ENTER** keys, change parameters P.000 through P.005 if needed. Refer to section 4.5 if you need instructions.
7. If you need access to the second menu list to modify general parameters P.007 through P.065, and any vector parameters, U.000 through U.013, enter the password into parameter P.006:
 - a. Locate P.006 on the display: **[P.006]**
 - b. Press the **ENTER** key.
 - c. Using the **▲** key, scroll until the display shows: **[607]**
 - d. Press the **ENTER** key.
 - e. Display will show **[P.006]** again.
8. You can now scroll through parameters P.007 through P.065 and modify them as needed. Refer to section 4.5 if you need instructions.
9. To change any vector parameters:
 - a. Make sure the correct password has been entered into parameter P.006.
 - b. Press the **PROGRAM** key. The following is displayed:
 - c. Press the **▼** key one time until the following is displayed:
 - d. Press the **ENTER** key to access the vector parameters. Scroll through the list and change the vector parameters as necessary. Refer to section 4.5 if you need instructions.
10. To return to the display mode, press the **PROGRAM** key two times.

6.4 General Parameters - First Menu List

P.000 Operation Control Source

Parameter Selection:

LOCL = 0 = Local Front Panel/Keypad
rE = 1 = Terminal Block Remote Inputs
OP = 2 = Option Port
PC = 3 = Host PC

Initial Setting:

LOCL

Description:

P.000 selects the operation control source. If LOCL (0) is selected, all commands come directly from the front panel keypad. If rE (1) is selected, the drive will follow commands from the terminal strip remote inputs. The REMOTE LED on the keypad front panel will light. If OP (2) is selected, the drive will follow commands from the option port (e.g., the Network option). If PC (3) is selected, the drive will follow commands from a Host PC.

P.001 Acceleration Time (tunable) (RAMP 1)

Adjustment Range:

0.1 - 999.9 seconds

Initial Setting:

20.0 (20 seconds)

Description:

Acceleration time is the time in which the motor goes from zero speed to rated speed (U.005) after starting. The acceleration rate depends on the speed setting. If the motor load inertia is high or the current limit (P.005) setting is too low, actual motor acceleration time will be longer than the programmed time set in P.001. For Jog Acceleration Time, see P.021.

P.002

**Deceleration Time (tunable)
(RAMP 1)**

Adjustment Range:

0.1 - 999.9 seconds

Initial Setting:

20.0 (20 seconds)

Description:

Deceleration time is the time in which the motor decreases from rated speed (U.005) to zero speed when performing a ramp stop (P.025).

NOTE: Motor load inertia and input line conditions can extend the deceleration time to a value greater than the preset time. With very fast deceleration times, regenerative motor voltage may charge up the D-C bus voltage, causing a high bus voltage (HU) fault trip. To avoid a fault trip condition, reset the deceleration time for a longer period. If a deceleration time faster than the acceptable range is required, installing an optional Snubber Resistor Kit or regenerative braking module may prevent the trip.

P.003

Minimum Speed Setting (tunable)

Adjustment Range:

0 - P.004 Maximum Speed (RPM)

Initial Setting:

150

Description:

DANGER

THE DRIVE IS CAPABLE OF OPERATING AT AND MAINTAINING ZERO SPEED. THE USER IS RESPONSIBLE FOR ASSURING SAFE CONDITIONS FOR OPERATING PERSONNEL BY PROVIDING SUITABLE GUARDS, AUDIBLE OR VISUAL ALARMS, OR OTHER DEVICES TO INDICATE THAT THE DRIVE IS OPERATING OR MAY OPERATE AT OR NEAR ZERO SPEED. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

Minimum speed is the minimum allowed speed in RPM.

P.004**Maximum Speed Setting (tunable)****WARNING**

THE USER IS RESPONSIBLE FOR ENSURING THAT DRIVEN MACHINERY, ALL DRIVE-TRAIN MECHANISMS, AND PROCESS LINE MATERIAL ARE CAPABLE OF SAFE OPERATION AT THE MAXIMUM OPERATING SPEED OF THE DRIVE. OVERSPEED DETECTION IN THE DRIVE DETERMINES WHEN THE DRIVE SHUTS DOWN AND IS FACTORY SET TO 130%. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

Adjustment Range:

10 - U.005 Motor Rated Speed (RPM)

Initial Setting:

1722

Description:

Maximum speed is the maximum allowed speed in RPM.

NOTE: *It is recommended that when changing the maximum speed value (P.004), also rescale the RPM display mode parameter (P.028) to the same value so that when you look at the RPM display mode, it corresponds to the maximum speed.*

The drive is equipped with fixed overspeed protection at 130% of maximum speed.

P.005**Current Limit (tunable)****Adjustment Range:**

U.006 - 150%

Initial Setting:

150

Description:

P.005 represents current limit as the stator current limit in respect to the motor rated amps.

For vector operation, torque is not proportional to the stator current and, therefore, current limit is not linear to the amount of torque produced. The amount of torque produced is not only a function of the stator current limit, but also of the magnetizing current percent. Changing the current limit rating affects the maximum attainable torque the motor can produce. The following equation shows how maximum torque is reached:

$$\text{Max Torque} = \sqrt{\frac{I_{\text{limit}}^2 - I_{\text{mag}}^2}{10000 - I_{\text{mag}}^2}} \times 100$$

Where:

I_{limit} = Current limit percent

I_{mag} = Magnetizing current percent
 = $\frac{\text{no load current} \times 100}{\text{rated current}}$

P.006**Expand to Second Menu List****WARNING**

IT IS THE USER MANAGEMENT'S RESPONSIBILITY TO DISTRIBUTE THE SECURITY ACCESS CODES WITH DISCRETION WITHIN THEIR ORGANIZATIONAL LEVELS. RELIANCE ELECTRIC COMPANY IS NOT RESPONSIBLE FOR UNAUTHORIZED ACCESS VIOLATIONS WITHIN THE USER'S ORGANIZATION. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

Adjustment Range:

0 - 32767

Initial Setting:

0

Password: 607**Description:**

The first menu list (P.000 through P.005) contains most parameters needed to be viewed or adjusted on an operator's level. None of the second menu parameters can be changed or viewed unless the correct password is entered into P.006. If the password is not entered, when you scroll through the parameters, at P.006, the list will complete its cycle and return to P.000. Once the password is entered correctly at P.006, the list will now scroll up to P.065 and also allows access to the vector parameter group (U.--) as well.

To enter the password to expand to the second menu list:

1. Enter the PROGRAM mode.
2. Access P.006 on the display.
3. Press the ENTER key.
4. Using the  key, scroll the number from 0 until the number 607 is displayed.
5. Press the ENTER key. (The display will show "P.006" after pressing the ENTER key.)
6. Second Menu List parameters can now be accessed and modified. Entering the password again will disable the password.

NOTE: If you access P.006 after entering the password, the value will go back to showing zero, even though you can now access the second menu long list. The zero value is to prevent unauthorized password use. The last state when the drive is powered down will remain when powered back up.

6.5 General Parameters - Second Menu List

P.007

Terminal Block Digital Input Configure

Parameter Selection:

	Digital Input 6: Terminal 19	Digital Input 7: Terminal 18	Digital Input 8: Terminal 17
0 =	DIG6=FWD/REV	DIG7=RAMP1/2	DIG8=REM/LOC
1 =	Not used	DIG7=FWD/REV	DIG8=RAMP1/2
2 =	Not used	DIG7=FWD/REV	DIG8=REM/LOC
3 =	Not used	DIG7=RAMP1/2	DIG8=REM/LOC
4 =	Not used	Not used	DIG8=FWD/REV
5 =	Not used	Not used	DIG8=RAMP1/2
6 =	Not used	Not used	DIG8=REM/LOC
7 =	Not used	Not used	Not used

Refer to table 3.6 for Control Terminal block wiring.

Initial Setting:

(All inputs are assigned:)

0 =	DIG6=FWD/REV
	DIG7=RAMP1/2
	DIG8=REM/LOC

Description:

This parameter selects how digital inputs 6, 7, and 8 are to be used. Depending on what is selected for P.008, Terminal Block Speed Reference Selection, will limit the selection of P.007. This is because what is selected for P.008 may use one or more of digital inputs 6 through 8.

A negated (open) or asserted (closed) input will select the following for the three input choices:

	<u>Open (Unasserted)</u>	<u>Closed (Asserted)</u>
FWD/REV	Forward	Reverse
RAMP1/2	Ramp 1	Ramp 2
REM/LOC	Remote	Local

RAMP1/2 = Allows you to specify two separate accel(decel) rates, and instantly select between the two. Note that this is a remote switch between two separate (paired) rates. It does not select between one accel rate and a different decel rate. Ramp 1 uses accel or decel rates based on P.001/P.002. Ramp 2 uses accel or decel rates based on P.017/P.018. NOTE: The digital input for RAMP1/2 is *always* active in LOCAL or REMOTE modes.

FWD/REV = Allows you to select between open or closed digital input state. If the selected speed reference value is negative (<0), and the FWD/REV input is closed (which allows reverse direction), then the resulting speed reference will be positive, or forward.

REM/LOC = Allows you to temporarily switch from a remote running condition to local keypad operation without breaking the 2-wire control run signal. The following example shows how this input can be utilized.

WARNING

IF A MAINTAINED START CONTACT IS USED IN REMOTE MODE, SWITCHING FROM LOCAL TO REMOTE WILL CAUSE THE DRIVE TO START AND THE MOTOR WILL ROTATE IF THE REMOTE START CONTACT IS CLOSED. STAY CLEAR OF ROTATING MACHINERY. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

REM/LOC INPUT EXAMPLE:

The drive is stopped and started using an external 2-wire control signal. The drive is in "Remote" mode (P.000 = rE), and is being given a maintained start command. The REM/LOC option (2 is selected for P.007) so that an external "REM/LOC" switch mounted externally switch the drive from REMOTE to LOCAL or from LOCAL to REMOTE. This external switch is in the "REMOTE" position. The following happens:

1. The front panel STOP/RESET key is pressed, and the motor stops.
2. "LOCAL" is selected using the externally wired "REM/LOC" switch.
3. Control of the drive is done locally through the front panel. (This could be for troubleshooting purposes, or for looking at or changing parameter values).
4. The "REM/LOC" switch is switched back to the "REMOTE" position. The drive RUNS immediately because there is already an asserted remote start signal.
5. The drive is now running in the REMOTE mode.

NOTE: A default value of 0 for P.007 will limit P.008 to a parameter selection of 0. You must change P.007 to some value other than 0 in order to change P.008 to some value other than 0. See table 6.1 and the selection example in the P.008 description.

P.008**Terminal Block Speed Reference Selection****Parameter Selection:**

- 0 = Analog Reference (digital inputs 6, 7, and 8 are unused)
- 1 = MOP selection (uses terminal block digital input 6 for the MOP increment function, and digital input 7 for the MOP decrement function)
- 2 = Two (2) Multi-speed presets (uses terminal block digital input 6, but leaves inputs 7 and 8 free)
- 3 = Four (4) Multi-speed presets (uses terminal block digital inputs 6 and 7, but leaves input 8 free)
- 4 = Eight (8) Multi-speed presets (uses all terminal block digital inputs 6, 7, and 8)

Initial Setting:

0 = Analog Reference

Description:

This parameter selects the source of the terminal block speed reference. The parameter entry is also dependent on what is selected for parameter P.007. Selection of parameter P.007 determines what the configurable digital inputs 6, 7, and 8 are used for. The acceptable values for P.007 are based on what is selected for P.008 and are shown in table 6.1.

Table 6.1 - Digital Input Limits Matrix Selection

P.007 Selection Choices	P.008 Selection Choices				
	0	1	2	3	4
0	✓				
1	✓		✓		
2	✓		✓		
3	✓		✓		
4	✓	✓	✓	✓	
5	✓	✓	✓	✓	
6	✓	✓	✓	✓	
7	✓	✓	✓	✓	✓

Table 6.1 indicates the acceptable combinations for Parameters P.007 and P.008. A blank cell indicates that the combination is not acceptable due to conflicts where inputs are already assigned.

P.007 and P.008 Selection Example:

- You want to select the MOP as the speed reference source. From the *parameter selection* range shown for P.008, this means that the value for P.008 must be equal to 1.
- Now configure the value needed for P.007. Since the MOP uses digital inputs 6 and 7, this only leaves values for P.007 to be equal to 4, 5, 6, or 7.
- Go to the P.008 = 1 column, and notice that 0,1,2, or 3 selection choices for P.007 cannot be made. Following the column down, notice that 4,5,6, or 7 selection choices for P.007 CAN be made.

P.009**Terminal Block Analog Input Speed Reference Offset (tunable)****Adjustment Range:**

-250 to +250

NOTE: Units = 1023 counts = +10 V
 Approximately 102 = 1 V of offset

Initial Setting:

0

Description:

The analog input speed reference offset parameter is used to scale the zero speed reference input to match external equipment. Normally, the zero speed reference is either 0 VDC or 0 mA. The offset and gain parameters can be used to convert the 0-20 mA signal to a 4-20 mA signal usually used on equipment.

To adjust: Set P.000 = rE (1) or press the AUTO/MAN key until the AUTO LED is ON. Then use the Speed Reference Display Mode (see section 4.3.2) to display the speed reference (displayed as RPM) from the selected control source Local or Remote. P.008 must be 0 to select analog input as the speed reference.

Figure 6.2 shows an example of how the analog input saturates at minimum and maximum speed.




Figure 6.2 - Relationship of Analog Input Speed Reference to Minimum and Maximum Speed

P.010**Terminal Block Analog Input Speed Reference Gain (tunable)****Adjustment Range:**

-.750 - 1.250

Initial Setting:

1.000

Description:

The analog speed reference gain parameter is used to scale the speed reference input to match external equipment.

To adjust: Set P.000 = rE (1) or press the AUTO/MAN key until the AUTO LED is ON. Then use the Speed Reference Display Mode (see section 4.3.2) to display the speed reference (displayed as RPM) from the selected control source Local or Remote. P.008 must be 0 to select the analog input as the speed reference.

If you are using the remote analog speed reference input as the control source, and are using a 5K potentiometer connected to the terminal strip for speed control, you may encounter difficulty in attaining Maximum Speed. You can resolve this problem by increasing the value of P.010 from the default value of 1.0 to approximately 1.10. Another solution would be to supply an alternate voltage source (>10 V) for the speed potentiometer.

Figure 6.2 shows an example of how the analog input saturates at minimum and maximum speed.

P.011**Terminal Block Analog Input Speed Reference Invert Selection (tunable)****Parameter Selection:****OFF =**

0-20mA:	0 mA = 0
	20 mA = + Motor Rated RPM (U.005)
0-10VDC:	0 VDC = 0
	+10 VDC = + Motor Rated RPM (U.005)
-10VDC to 10VDC:	-10 VDC = - Motor Rated RPM (U.005)
	+10 VDC = + Motor Rated RPM (U.005)

ON = (Inverted)

0-20mA:	0 mA = 0
	20 mA = - Motor Rated RPM (U.005)
0-10VDC:	0 VDC = 0
	+10 VDC = - Motor Rated RPM (U.005)
-10VDC to 10VDC:	-10 VDC = + Motor Rated RPM (U.005)
	+10 VDC = - Motor Rated RPM (U.005)

Initial Setting:

OFF

Description:

When this parameter is enabled (ON), the analog speed reference input becomes inverted.

NOTE: If the terminal block analog input is selected as the torque reference (U.000 = 1), then substitute + or - 150% torque limit for + or - Motor Rated RPM.

P.012 Terminal Block Analog Output Source Selection (tunable)**Parameter Selection:**

- 0 = Speed Loop feedback
- 1 = Torque/Current feedback

Initial Setting:

0

Description:

0 = Speed Feedback:

This selection specifies the analog output source to be speed feedback. Refer to table 6.2:

Table 6.2 - Speed Feedback Analog Output Values

Speed Feedback	Analog Output (4-20 mA)	Analog Output (0-10 V)
-2 x (rated RPM)	4 mA	0.0 V
- rated RPM	8 mA	2.5 V
-1/2 rated RPM	10 mA	3.75 V
0	12 mA	5.0 V
+1/2 rated RPM	14 mA	6.25 V
+ rated RPM	16 mA	7.5 V
+2 x (rated RPM)	20 mA	10.0 V

NOTE: *Rated RPM is Motor Rated Speed (U.005).*

1 = Torque/Current Feedback:

This selection specifies the analog output source to be torque feedback. Refer to table 6.3.

Table 6.3 - Torque/Current Feedback Analog Output Values

Torque Feedback	Analog Output (4-20 mA)	Analog Output (0-10 V)
-300%	4 mA	0.0 V
-150%	8 mA	2.5 V
-75%	10 mA	3.75 V
0%	12 mA	5.0 V
+75%	14 mA	6.25 V
+150%	16 mA	7.5 V
+300%	20 mA	10.0 V

P.013 Output Relay Configuration

Parameter Selection:

- 0 = Output Relay is energized to show state of active fault (IET)
- 1 = Output Relay is energized to show state of drive running with 0.5 sec delay added between a START assertion and generation of motor voltage
- 2 = Output Relay is energized to show state of drive running but without 0.5 sec start delay
- 3 = Output Relay is energized to show state of Network communications active

Initial Setting:

0

Description:

This parameter specifies whether the output relay wired to the terminal block terminals 28, 29, 30 and 31 indicate the state of an active fault (0), that the drive is running (1 = includes a 0.5 second delay between START assertion and the generation of motor voltage; 2 = no delay between START assertion and motor voltage generation), or that Network communication is active (3).

Example: For an application using an M-contactor, you can obtain a 0.5 second delay between START assertion and the generation of motor voltage by setting this parameter equal to 1. The delay will provide time for the contactor to close before motor voltage is generated.

P.014 Trim Reference Source Selection

Parameter Selection:

- 0 = No Trim Reference Used
- 1 = Terminal Block Analog Input
- 2 = Options Port Trim Reference Register (Reserved for later versions)
- 3 = Maximum Speed
- 4 = Torque Current Feedback

Initial Setting:

0 = No trim reference

Description:

This parameter specifies the source for the trim reference. Trim reference offsets the speed reference. See figure 6.3.




Figure 6.3 - Trim Reference Source Selection

P.015 Trim Gain Percentage (tunable)

Adjustment Range:

– 99.9 to +99.9 (%)

Initial Setting:

0.0

Description:

Trim gain is a percentage of the selected trim reference entering the speed regulator. See figure 6.4. A value of 1.0 is an increment of 1% gain.




Figure 6.4 - Draw and Trim Gain

P.016 Draw Gain Percentage (tunable)

Adjustment Range:

– 99.9 to +99.9 (%)

Initial Setting:

0.0

Description:

Draw gain adds a percentage of the selected speed reference entering the speed regulator. See figure 6.5. This parameter will allow multiple drive sections with a common line reference, but with different values for draw gain, to run at different speeds depending on the percent draw. A value of 1.0 is an increment of 1% gain.

P.017 **Second Ramp Acceleration (RAMP 2)****Adjustment Range:**

0.1 to 999.9 seconds

Initial Setting:

20.0

Description:

This parameter sets the acceleration time when a second ramp selection is configured as a digital input. When RAMP 2 acceleration time digital input is asserted, the RAMP 2 deceleration rate also takes effect. Refer to P.007, Terminal Block Digital Input Configure, for digital input selection parameters.

P.018 **Second Ramp Deceleration (RAMP 2)****Adjustment Range:**

0.1 to 999.9 seconds

Initial Setting:

20.0

Description:

This parameter sets the deceleration time when a second ramp selection is configured as a digital input. When RAMP 2 deceleration time digital input is asserted, the RAMP 2 acceleration rate also takes effect. Refer to P.007, Terminal Block Digital Input Configure, for digital input selection parameters.

P.019 **S-Curve Selection**

NOTE: This parameter does not apply to the Jog Acceleration (P.021) or Deceleration (P.022) parameters.

Parameter Selection:

OFF = Use Linear Accel/Decel Function
ON = Use S-Curve Accel/Decel Function

Initial Setting:

OFF

Description:

When S-Curve accel/decel is selected, the accel or decel ramp times begins and ends slowly, creating an "S-Curve" function. The portion of the accel time which makes up the non-linear "S" portion will be a fixed 20% of the programmed accel time at the beginning (bottom), and 20% at the end (top) of the accel curve. The linear portion makes up 60% of the programmed accel time. The S-Curve accel/decel function is shown in figures 6.5 and 6.6.

NOTE: The accel and decel times must be set the same for the S-Curve ramp to function the same for accel as decel. If the decel rate is set lower than the accel rate, the decel time specified may not be met.




Figure 6.5 - S-Curve Acceleration




Figure 6.6 - S-Curve Deceleration

P.020 Jog Speed Reference (tunable)

Adjustment Range:

Minimum Speed (P.003) to Maximum Speed (P.004)

Initial Setting:

150 (RPM)

Description:

Jog speed is the setpoint while in jog mode. Jog reference is activated when the START key is maintained "ON" and the JOG mode has been selected.

P.021 Jog Ramp Acceleration Time (tunable)

Adjustment Range:

0.1 - 999.9 seconds

Initial Setting:

20.0

Description:

The jog acceleration time is the amount of time (seconds) it takes to go from zero speed to rated speed (U.005) while in JOG mode.

P.022**Jog Ramp Deceleration Time (tunable)****Adjustment Range:**

0.1 - 999.9 seconds

Initial Setting:

20.0

Description:

The jog deceleration time is the amount of time (seconds) it takes to go from rated speed (U.005) to zero speed while in JOG mode.

P.023**MOP Reference Rate****Adjustment Range:**

0.1 - 999.9 seconds

Initial Setting:

20.0

Description:

The MOP (electronic Motor Operated Pot) reference rate sets the amount of time (seconds) for the MOP to go from zero speed to rated speed (U.005), or from rated speed (U.005) to zero speed.

P.024**MOP Reset****Parameter Selection:**

- 0 = Reset MOP setpoint after IET (Instantaneous Electronic Trip)
- 1 = Reset MOP setpoint during each stop
- 2 = Do not Reset MOP setpoint

NOTE: When the speed reference selection (P.008) remains the MOP, if the drive is powered down and powered back up, the MOP function setpoint will always be reset to equal minimum speed (P.003). When the MOP function is set and then disabled by using parameter P.008 (Terminal Block Speed Reference Selection), the last value prior to being disabled will be retained.

Initial Setting:

0

Description:

This parameter determines when and if the MOP setpoint is reset to minimum speed (P.003). The MOP provides a digital speed reference which can be incremented and decremented using terminal block digital inputs.

P.025**STOP Type Selection (tunable)****WARNING**

THE DRIVE IS NOT EQUIPPED WITH A COAST-STOP PUSHBUTTON. THE USER MUST INSTALL A HARDWIRED, OPERATOR-ACCESSIBLE PUSHBUTTON THAT PROVIDES A POSITIVE INTERRUPT AND SHUTS DOWN THE DRIVE. USE TERMINALS 16 AND 20 OR THE JUMPER TERMINAL. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

Parameter Selection:

0 = Coast to Rest Stop

1 = Ramp to Rest Stop (If P.025 is = 1, then U.000 must be = 0.)

Initial Setting:

0

Description:

When parameter "0" is selected, pressing the STOP key or giving an external STOP command causes the motor to coast to rest. With parameter selection of "1", pressing the STOP key or sending an external STOP command causes the motor to ramp to rest within a time equal to or greater than the preset deceleration time (P.002).

Note that if the drive is configured as a torque regulator only (See U.000 = 1 or 2), then STOP type will always be a coast stop, regardless of the value of this parameter (P.025).

P.026**Function Loss Selection (tunable)****Parameter Selection:**

- 0 = Fault trip (IET) occurs at function loss
- 1 = Coast to Rest stop without an IET output at function loss

Initial Setting:

0

Description:**WARNING**

THE DRIVE IS NOT EQUIPPED WITH A COAST-STOP PUSHBUTTON. THE USER MUST INSTALL A HARDWIRED, OPERATOR-ACCESSIBLE PUSHBUTTON THAT PROVIDES A POSITIVE INTERRUPT AND SHUTS DOWN THE DRIVE. (USE TERMINALS 16 AND 20 FOR FUNCTION LOSS INTERRUPT). FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

If parameter “0” is selected, a function loss signal causes the drive to stop, resulting in the following:

- The motor will coast to rest.
- The function loss error code (“FL”) will be displayed.
- The internal speed reference will be reset to zero.
- The output relay will be asserted if P.013 is configured for IET output.
- The IET trip must be reset using the STOP/RESET key before the drive can be re-started.

If parameter “1” is selected, a function loss signal causes the drive to stop, resulting in the following:

- The motor will coast to rest.
- The internal speed reference will be reset to zero.
- The output relay will NOT be asserted.
- The drive can be re-started with the START button after the cause of the fault has been removed.

P.027**Reverse Disable (tunable)****Parameter Selection:**

- OFF = Forward/Reverse Enabled from Selected Control Source
- ON = Reverse Disabled from Selected Control Source

Initial Setting:

OFF

Description:

If “OFF” is selected, the forward/reverse input will allow forward or reverse rotation of the motor. When “ON” is selected, reverse rotation is not allowed. This is true from any selected control source.

P.028 RPM Display Mode Scaling (tunable)

NOTE: To enter the RPM Display Mode:

1. Press the PROGRAM key until ("P---") is displayed.
2. Press the PROGRAM key again (the PROGRAM LED will go out.)
3. The RPM LED is lit. The display is now in RPM Display Mode.

Adjustment Range:

10 - 9999

Initial Setting:

1722

Description:

This parameter defines the scaling value (speed or any engineering unit) to be used when in the "RPM" display mode.

Whatever value is set into this parameter will, in effect, become the maximum *displayed* value for the local setpoint, or become the maximum *displayed* value for the RPM display mode. The RPM value displayed when in RPM Display Mode is:

$$\frac{\text{Current Operating Speed} \times \text{P.028}}{\text{P.004 (Max Speed)}}$$

RPM Display Mode Example:

Example: You need the display to be scaled to show the maximum speed as 800 gallons/minute.

Parameter P.003 is set equal to = 150

Parameter P.004 is set equal to = 1722

1. Set parameter P.028 = 800.
2. Enter the RPM Display Mode.
3. Start the drive. (Press the START key).
4. When run up to rated speed, the RPM display mode shows that maximum speed is 800 gallons/minute.

P.029 Elapsed Time Meter Readout

Adjustment Range:

0 - 9999 days

Initial Setting:

N/A

Description:

This parameter displays the number of days (24 hour period) since the drive has been under power or the elapsed time since the Elapsed Time Meter Reset parameter was last reset. (See P.030.)

P.030**Elapsed Time Meter Reset (tunable)****Parameter Selection:**

OFF = No action

ON = Reset the elapsed time meter to zero (0). (Parameter P.029 will be reset = 0.)

Initial Setting:

OFF

Description:

Resets parameter P.029 to a zero value. This parameter is set to OFF after the reset operation is carried out.

P.031 - P.038**Multi-Speed Preset #1 through Multi-Speed Preset #8****Adjustment Range:**

Minimum Speed (P.003) - Maximum Speed (P.004)

Initial Setting:

150

Description:

Parameters P.031 through P.038 allow setting of up to eight different preset speed profiles. The multi-speed presets are configured using parameters P.007 and P.008 which define the digital inputs 6, 7, and 8 assignments. P.008 must be set to values of either 2, 3, or 4 for multi-speed presets. Refer to the Digital Assignment Matrix in table 6.4 and in figure 6.7.

Table 6.4 - Multi-Speed Preset Digital Input Matrix

Digital Inputs (Terminals) 8 (17) 7 (18) 6 (19)			Multi-Speed Preset Parameters
0	0	0	P.031
0	0	1	P.032
0	1	0	P.033
0	1	1	P.034
1	0	0	P.035
1	0	1	P.036
1	1	0	P.037
1	1	1	P.038

0 = Digital Input Open 1 = Digital Input Closed




Figure 6.7 - Typical Multi-Speed Preset Operation

P.039

Reserved for Later Use

P.040**Electronic Motor Thermal Overload**

CAUTION: This parameter should always be set equal to on. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

Parameter Selection:

OFF = Electronic Motor Thermal Overload is Disabled

ON = Electronic Motor Thermal Overload is Enabled

Initial Setting:

ON

Description:

When this parameter is "ON", the drive will trip if the thermal overload time is exceeded (60 seconds at 150% of motor rated current). The overcurrent amount is automatically calculated by the drive software based on the motor rated amps (U.004) and the drive panel rated amps (factory set).

P.041 - P.046**Reserved for Later Use****P.047****Carrier Frequency Selection****Parameter Selection:**

2 = 2 kHz Carrier Frequency

4 = 4 kHz Carrier Frequency

8 = 8 kHz Carrier Frequency

Initial Setting:

8

Description:

The carrier frequency can compensate for acoustic noise by adjusting the switching frequency of the transistors in the inverter section. The carrier frequency controls the width of the pulse and keeps the current smooth to the motor.

Keeping the carrier frequency at 8 kHz will ordinarily provide the quietest motor operation.

P.048 Drive Type Selection

Parameter Selection:

UEC = Vector Control

Initial Setting:

UEC

Description:

N/A

P.049 Default Type Selection

Parameter Selection:

USA = USA Default Settings

EUr = European Default Settings

JPn = Japan Default Settings

Initial Setting:

USA

Description:

Sets the factory initial default settings for each drive type. Refer to tables 8.1 through 8.3 for default settings.

P.050 Restore Default Settings

Parameter Selection:

OFF = No Action

ON = Reset Parameters to Default Settings

Initial Setting:

OFF

Description:

This parameter, when set equal to "ON", will reset all parameters to the default settings as selected in P.049. After the parameter values have been restored, P.050 will be set to equal "OFF" by the drive.

P.051**Program Lockout****Adjustment Range:**

0 - 32767

Initial Setting:

0

Password:

1044

Description:

This parameter requires the correct password to be entered in order to prevent parameter modification from the keypad front panel. To disable parameter programming:

1. Access P.051 on the display.
2. Press the ENTER key. Display shows "0".
3. Increment the value to 1044.
4. Press the ENTER key. Display shows "P.051".
5. The front panel "PASSWORD" LED will be lit to indicate that you cannot modify any parameters.

To return to enable programming, re-enter the password by repeating the steps above. Whatever state this parameter is in when power is removed will remain the state when power is returned.

P.052**Software Version****Description:**

Displays the software version number. This parameter is not adjustable by the user.

P.060 Drop Number Assignment**Adjustment Range:**

1 to 55 (Basic Drive Connection; see P.061)

1 to 53 (Full Drive Connection; see P.061)

Initial Setting:

1

Description:

This parameter specifies the base drop number to which the network board will respond on the AutoMax® network. Assigning a value to this parameter is equivalent to setting the thumbwheel switches on the faceplate of the AutoMax Network Communications module (M/N 57C404B).

This parameter cannot be written to the drive by the network master. The drop number cannot be changed over the network. This parameter must be set at the drive via its front panel/keypad or via a PC-HOST serial interface.

P.061 Network Connection Type**Parameter Selection:**

0 = Basic Drive Connection

1 = Full Drive Connection

Initial Setting

0

Description

This parameter is used to select one of two connection types:

Basic Drive Connection (0) provides basic drive control over the AutoMax network. You can control functions such as start/stop, reset, reference, and basic tunable parameters such as accel, decel, min. speed, max. speed, etc. See instruction manual D2-3308 for a complete listing of the parameters that can be controlled.

This configuration will occupy a single drop image area on the AutoMax network. This single drop area contains 32 read registers and 32 write registers. Up to 55 GV3000 drives can be connected to single AutoMax Network Communications module using the Basic Drive Connection option.

Full Drive Connection (1) provides a complete drive interface over the AutoMax network. In addition to the information available with the Basic connection, all other drive parameters and diagnostic data are provided. See instruction manual D2-3308 for a complete listing of the parameters that can be controlled.

This configuration will occupy three drop areas on the AutoMax network, with each drop area providing 32 read registers and 32 write registers. Up to 18 GV3000 drives can be connected to a single AutoMax Network Communications module using the Full Drive Connection option.

P.062**Comm Loss Selection****Parameter Selection:**

- 0 = IET Fault
- 1 = Hold Last Reference
- 2 = Use Terminal Block Reference

Initial Setting

0

Description

This parameter specifies how the drive will respond to a network communication failure while the option port (Network Option board) has been selected as the drive control source (P.000 = 'OP' (2)). If the option port is not in control of the drive, but is only monitoring drive operation, then loss of network communications will have no effect on drive operation. In all cases, the Network Option board, upon loss of communication with the network master, will attempt to re-establish the communication link. Three choices are provided:

IET Fault (0) - The drive will consider a loss of network communication a drive fault resulting in an IET type stop sequence. This is the default value for this parameter.

To eliminate extraneous fault conditions at power-up of a drive configured for network operation, the drive will delay for approximately 10 seconds after power-up before annunciating a fault condition. A fault condition will be annunciated if network communications is not established before the 10 second power-up timer expires, or if network communications was established and then lost.

Response to Network Communication Loss:

- The drive will latch a fault condition and perform a coast stop sequence.
- A fault code will be logged in the drive's error log and displayed on the front-panel display ("nCL" = network Comm Loss).
- The front-panel REMOTE LED will blink indicating that the network is inactive.
- Once network communications has been re-established, a drive fault reset will be required to re-start the drive. (Note: A fault reset does not clear the error log).

Hold Last Reference (1) - The drive will continue to operate using the last reference received from the network master.

Response to Network Communication Loss:

- A fault will not occur.
- An entry will be made into the drive's error log for each active to inactive transition of the network communication status.
- The front-panel REMOTE LED will blink indicating that the network is inactive.
- Once network communications has been re-established the drive will once again follow the reference and sequencing control inputs supplied by the network master.

It is important to note that, in this configuration, it may not always be possible to stop the drive over the network. Some form of hardwired stop must be used (e.g., function loss input configured for IET when asserted).

WARNING

THE GV3000 DRIVE IS NOT EQUIPPED WITH A COAST-STOP PUSHBUTTON. THE USER MUST INSTALL A HARDWIRED, OPERATOR-ACCESSIBLE PUSHBUTTON THAT PROVIDES A POSITIVE INTERRUPT AND SHUTS DOWN THE DRIVE. (USE TERMINALS 16 AND 20. SEE FIGURE 3.2 AND 3.4). FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.

Use Terminal Block Reference (2) - The drive will obtain its speed/torque reference from the terminal block analog input and its STOP input from the terminal block STOP input. All other inputs are held at the last values received from the network master.

This will allow the network master to continue controlling the drive reference with a direct-wired analog output to input, and to STOP the drive with a direct-wired digital output to input. Note that once the drive is stopped while in this mode, it cannot be re-started until network communication is re-established or the operation control source (P.000) is changed.

Response to Network Communication Loss:

- A fault will not occur.
- An entry will be made into the drive's error log for each active to inactive transition of the network communication status.
- The front-panel REMOTE LED will blink indicating that the network is inactive.
- Once network communications has been re-established the drive will once again follow the reference and sequencing control inputs supplied by the network master.

It is important to note that, in this configuration, it may not always be possible to stop the drive over the network. Some form of hardwired stop must be used (e.g., function loss input configured for IET when asserted).

WARNING

THE GV3000 DRIVE IS NOT EQUIPPED WITH A COAST-STOP PUSHBUTTON. THE USER MUST INSTALL A HARDWIRED, OPERATOR-ACCESSIBLE PUSHBUTTON THAT PROVIDES A POSITIVE INTERRUPT AND SHUTS DOWN THE DRIVE. (USE TERMINALS 16 AND 20. SEE FIGURE 3.2 AND 3.4). FAILURE TO OBSERVE THESE PRECAUTIONS COULD RESULT IN BODILY INJURY.

P.063**Network Reference Source Select****Adjustment Range:**

- 0 = Direct Reference
- 1 - 8 = Broadcast

Initial Setting

0

Description

This parameter specifies where the drive will get its reference when the control source has been configured as the option port (P.000 = OP (2)). There are 9 choices:

Direct Reference (0) - Reference is obtained from register 33 of the first drop image.

Broadcast (1 - 8) - Reference is obtained from network broadcast register 1 - 8, respectively. (For a description of network broadcast registers, refer to the Network Communications Module instruction manual, J2-3001.)

Note: Speed or torque control is configured by parameter U.000 to select the torque reference source. One of its selections is the option port.

P.064**Reserved for Later Use**

P.065**Option Port Type + Version Number****Description**

This parameter is read-only. The display consists of the network option type (always 2000) plus the software version number. For example, for software version 1.23, the value displayed will be 2123; for version 1.01, the value will be 2101.

6.6 Vector Operation Parameters

U.000 Torque Reference Source Selection

Parameter Selection:

- 0 = Use Speed Loop Output
NOTE: *If U.000 is 1, then P.025 must be = 0 (coast stop).*
- 1 = Terminal Block Analog Input (See Note 1)
- 2 = Option Port – If AutoMax Network option used, see P.063

NOTE 1: *The analog input is conditioned with offset and gain parameters (P.009 and P.010) and the signal can be inverted using the analog input invert (P.011) parameter.*

Initial Setting:

0

Description:

This parameter specifies the source for the torque reference. The source of the torque reference can be the output of the speed loop (default), the analog input (the drive regulates only torque with selection 1 or 2 and the current limit parameter - P.005 - is not applied), or the Option Port torque reference value.

If U.000 is set to 1 or 2, then the value of P.025 (STOP Type) is not relevant. In these cases, STOP Type will always be coast stop.

U.001**Pulse Tachometer Selection****WARNING**

THE SETTING OF PARAMETERS U.001 (PULSE TACHOMETER SELECTION), U.002 (MOTOR POLES), U.003 (MOTOR BASE FREQUENCY), AND U.005 (MOTOR RATED SPEED) DETERMINE THE MOTOR MAXIMUM SPEED. THESE PARAMETERS MUST BE SET BY A QUALIFIED PERSON WHO UNDERSTANDS THE SIGNIFICANCE OF SETTING THEM ACCURATELY. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

WARNING

DO NOT USE A 4096 PPR TACHOMETER WITH A 2-POLE MOTOR. OVERSPEED AND MOTOR DAMAGE CAN RESULT. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

NOTE: If torque control self-tuning is performed, then the value of this parameter is automatically set when self-tuning is successful.

Parameter Selection:

512 = 512 PPR

1024 = 1024 PPR

2048 = 2048 PPR

4096 = 4096 PPR

Initial Setting:

1024

Description:

Parameter U.001 selects the number of pulses per revolution (PPR) of the tachometer being used. The PPR must be selected based on a 125 kHz maximum input frequency limitation. The pulse tachometer PPR selection affects the minimum and the maximum operational speed in RPM and also affects the speed range.

The maximum input frequency can be calculated by the formula:

$$F_{\max} = \frac{U.005 \times U.001}{60}$$

where, F_{\max} is the maximum frequency in Hz.

U.002**Motor Poles Number****WARNING**

THE SETTING OF PARAMETERS U.001 (PULSE TACHOMETER SELECTION), U.002 (MOTOR POLES), U.003 (MOTOR BASE FREQUENCY), AND U.005 (MOTOR RATED SPEED) DETERMINE THE MOTOR MAXIMUM SPEED. THESE PARAMETERS MUST BE SET BY A QUALIFIED PERSON WHO UNDERSTANDS THE SIGNIFICANCE OF SETTING THEM ACCURATELY. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

WARNING

DO NOT USE A 4096 PPR TACHOMETER WITH A 2-POLE MOTOR. OVERSPEED AND MOTOR DAMAGE CAN RESULT. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

NOTE: *This parameter must be entered before parameter U.005 (Rated RPM). Parameter U.005 is limited by the number of motor poles entered into parameter U.002.*

Parameter Selection:

- 0 = 2 Poles
- 1 = 4 Poles
- 2 = 6 Poles
- 3 = 8 Poles

Initial Setting:

1

Description:

This parameter identifies the number of poles in the motor. If it is unknown, the number of poles can be obtained from data from the motor nameplate as follows:

1. Obtain the motor rated RPM as listed on the motor nameplate.
2. Obtain the motor rated frequency as listed on the motor nameplate.
3. Calculate the RPM value at 60 Hz as follows:

$$RPM @ 60 Hz = \frac{60}{\text{Motor Base Frequency (Hz)}} \times \text{Rated RPM (U.005)}$$

(U.003)

4. Determine the number of motor poles needed by looking up the value computed for *RPM @ 60 Hz*:

<u>Range of RPM @ 60 Hz:</u>	<u>Number of Poles:</u>
3600 - 3240	2
1800 - 1620	4
1200 - 1080	6
900 - 810	8

U.003**Motor Base Frequency****WARNING**

THE SETTING OF PARAMETERS U.001 (PULSE TACHOMETER SELECTION), U.002 (MOTOR POLES), U.003 (MOTOR BASE FREQUENCY), AND U.005 (MOTOR RATED SPEED) DETERMINE THE MOTOR MAXIMUM SPEED. THESE PARAMETERS MUST BE SET BY A QUALIFIED PERSON WHO UNDERSTANDS THE SIGNIFICANCE OF SETTING THEM ACCURATELY. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

NOTE: *This parameter must be entered before parameter U.005 (Rated RPM). Parameter U.005 is limited by the motor base frequency.*

Adjustment Range:

30.0 - 120.0 Hz

Initial Setting:

60.0

Description:

Enter the motor base frequency in Hz directly from the motor nameplate.

U.004**Motor Rated Amps**

CAUTION: This parameter must be equal to the rated amps found on the motor nameplate. Overcurrent or excess heating of the motor could result. Failure to observe this precaution could result in damage to, or destruction of the equipment.

Adjustment Range:

1/4- 1HP: U.004 = 0.7 amps - 3.1 amps
2HP: U.004 = 1.1 amps to 4.7 amps
3HP: U.004 = 1.5 amps to 6.4 amps
5HP: U.004 = 2.1 amps to 9.3 amps
7.5HP: U.004 = 3.1 amps to 14.0 amps
10HP: U.004 = 3.6 amps tp 16.7 amps

Initial Setting:

7.1

Description:

Enter the motor rated amps directly from the motor nameplate.

U.005**Motor Rated Speed (RPM)****WARNING**

THE SETTING OF PARAMETERS U.001 (PULSE TACHOMETER SELECTION), U.002 (MOTOR POLES), U.003 (MOTOR BASE FREQUENCY), AND U.005 (MOTOR RATED SPEED) DETERMINE THE MOTOR MAXIMUM SPEED. THESE PARAMETERS MUST BE SET BY A QUALIFIED PERSON WHO UNDERSTANDS THE SIGNIFICANCE OF SETTING THEM ACCURATELY. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN BODILY INJURY.

NOTE: *This parameter must be set prior to activating the torque control self-tuning (U.008).*

Adjustment Range:

1 - 4000 RPM : The actual adjustment range changes based on the values for U.002 and U.003. See the table below:

Pole Number (U.002)	Base Frequency 60 Hz (U.003)	Base Frequency 50 Hz (U.003)
2	3240 - 3596	2700 - 2997
4	1620 - 1798	1350 - 1498
6	1080 - 1198	900 - 999
8	810 - 899	675 - 749

In general, the value range for U.005 will be from:

$$\frac{U.003 \times 120}{U.002} \times .900 \quad \text{to} \quad \frac{U.003 \times 120}{U.002} \times .999$$

Initial Setting:

1722

Description:

Enter the motor rated RPM directly from the motor nameplate.

If the value is too close to the synchronous RPM, the drive may exhibit instability.

This value directly affects the torque linearity and the maximum attainable horsepower.

U.006**Motor Percent Magnetizing Amps**

CAUTION: If this parameter is set incorrectly overcurrent or excess heating of the motor could result. Failure to observe this precaution could result in damage to, or destruction of the equipment.

NOTE: *This parameter is automatically generated when self-tuning is performed. (See parameter U.008.)*

Adjustment Range:

10.0 - 80.0

Initial Setting:

54.5

Description:

U.006 is the percent of magnetizing current with respect to motor rated amps.

If the motor nameplate shows the no load current data or the magnetizing current, then this parameter value can be figured using the following formula. If this data does not appear on the motor nameplate, it is recommended that self-tuning (see parameter U.008) be performed to automatically calculate the result.

$$\text{Motor Percent Magnetizing Amps} = \frac{\text{Magnetizing Amps}}{\text{Motor Rated Amps}} \times 100$$

U.007**Reserved for Later Use**

U.008**Torque Control Self-Tuning**

CAUTION: Motor must **not** be loaded during the self-tuning operation, or incorrect parameter values will result. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

Refer to section 5.2.4. This parameter will be reset to “OFF” when self-tuning is completed or aborted. This parameter will only enable self-tuning, not start the procedure.

Parameter Selection:

ON = Enable Self-tuning

OFF = Disable Self-tuning

Initial Setting:

OFF

Description:

Self-tuning is a procedure performed by the drive that “tunes” or determines the pulse tachometer PPR selection for parameter U.001, and also determines the magnetizing current percent ratio for parameter U.006.

Determining the pulse tachometer PPR may be necessary since the PPR is not always listed on the motor or tachometer nameplate. Determining the magnetizing current ratio is necessary in vector operation so that the proper no load current, or magnetizing current, is set. The proper magnetizing current is required so that rated motor torque, speed, and horsepower can be developed in the vector mode.

Refer to section 5.2.4 for more information on the operation of self-tuning and the steps required to begin the procedure.

U.009**Results of Torque Control Self-Tuning****Parameter Output:**

- 0 = *Self-Tuning operation was successful.*
- 1 = *User initiated a normal stop. Self-Tuning operation aborted.*
- 2 = *Emergency stop or fault stop occurred during Self-Tuning. Self-Tuning operation aborted.*
- 3 = *Motor or pulse tach direction in reverse. Motor must rotate in clockwise direction facing motor/tach end. The pulse tachometer leads might also be reversed if the motor direction is correct.*
- 4 = *Pulse tachometer PPR out of range. The result of the determination of the pulse tachometer PPR was not one of the 4 selections of U.001. The pulse tachometer leads might also be reversed.*
- 5 = *Magnetizing current percent out of range. The measured no load current was not within 10% to 80% of rated current.*
- 6 = *Bus voltage error. Bus voltage out of range.*
- 7 = *Current limit exceeded. Self-Tuning should be run with the motor unloaded, and without being connected to any inertia load.*

NOTE: *Display will show "SF", with a fault entry into error log showing the cause(s) of the fault(s) for any values of 1 through 7. Refer to section 7, for a result other than zero.*

Initial Setting:

N/A

Description:

This parameter shows the results of the self-tuning operation. Normally, self-tuning should be successful and U.009 value will be 0.

U.010**Reserved for Later Use**

U.011**Reserved for Later Use**

U.012 Speed Regulator Proportional Gain Setting (tunable)

Adjustment Range:

0.01 - 99.9

Initial Setting:

2.0

Description:

With the default value, the drive should perform satisfactorily. However, with increased inertia loads, this gain parameter may need to be adjusted.

This parameter affects the dynamic performance of the speed regulation of the motor. It is the proportional gain of the PI amplifier in the speed loop.

U.013 Speed Regulator Integral Gain Setting (tunable)

Adjustment Range:

0.02 - 327.67 radians/second

Initial Setting:

2.0 radians/second

Description:

NOTE: It is recommended that this parameter not be adjusted under most applications.

With the default value, the drive should perform satisfactorily. However, with increased inertia loads, this gain parameter may need to be adjusted.

This parameter affects the dynamic performance of the speed regulation of the motor. It is the lead frequency of the PI amplifier in the speed loop.

7.0 TROUBLESHOOTING AND FAULT CODES

DANGER

ONLY QUALIFIED ELECTRICAL PERSONNEL FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THIS EQUIPMENT AND THE HAZARDS INVOLVED SHOULD INSTALL, ADJUST, OPERATE, AND/OR SERVICE THIS EQUIPMENT. READ AND UNDERSTAND THIS MANUAL IN ITS ENTIRETY BEFORE PROCEEDING. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

7.1 Drive Operation

The GV3000 is a digital A-C drive using closed loop vector control (refer to figure 7.1). Vector control offers the same dynamic performance to an A-C motor as that achieved with a D-C motor. Torque is constant across the motor's base speed range in both forward and reverse direction. The drive, under microprocessor system control, uses two control loops, speed and torque, to obtain vector performance.

Under the speed control loop, the speed reference (requested speed) can be an internal or an external source. The speed loop's feedback is provided by a pulse tach attached to the motor's shaft. The actual speed of the motor being calculated as the rate of change of position from the tach. An error signal derived from the difference between the requested and actual motor speed is implemented digitally (speed drive) to generate the torque command signal for the drive's torque control loop. The torque, in this case, will vary to maintain the motor at the requested speed.

Under torque control, the torque reference (requested torque) accepts a torque signal from the speed loop or from a selected torque reference. The torque control requires calculations and execution of motor equations based on given motor parameters to develop slip. The motor parameters required are magnetizing current (no load phase currents), motor nameplate data, and relative position of the rotor with time. Motor magnetizing currents are measured internally by the GV3000 drive while the rotor relative position is performed using a pulse tach. The torque control then provides information for the microprocessor system to generate the switching of the IGBT which, in turn, generates the motor phase voltages (PWM).

When the drive is configured for torque, it should be added that since only torque, not speed, is being regulated, an overspeed condition can result given certain motor/load conditions. A value of thirty percent (30%) over maximum speed will cause an instantaneous electronic trip in the drive.

7.1.1 Power Circuit Operation

As shown in figure 7.2, A-C power is supplied to the drive's base board at power terminals R, S, and T where three MOV suppressors limit voltage transients to within the maximum voltage range of a diode power module. This suppressed three-phased A-C voltage passes through the diode power module which full-wave rectifies the A-C into a D-C voltage. The D-C voltage is then sent to power terminals + and - (as D-C Bus Volts) and to the capacitor board. On the capacitor board, the D-C voltage is fed into a bank of capacitors for power and noise filtering. Upon returning to the base board, the filtered D-C voltage is then applied to sensors (D-C bus voltage and current), sent to an internal power supply and an IGBT (insulated-gate bipolar transistor) inverter bridge.




Figure 7.1 - Block Diagram of the GV3000 Vector Control

The filtered D-C bus voltage and current feedback signals are sent through the daughter board for control usage by the drive's regulator board.

The internal power supply uses the filtered D-C voltage to develop the isolated voltages and currents necessary for drive operation. These voltages also include the supply voltage for the Dynamic Braking kit. Dynamic braking control voltage is made available for the kit at the base board's + (10 VDC) and - (COM) power terminals. An isolated sawtooth voltage signal, developed by the internal supply, is sent to the drive's daughter board. The daughter board uses the isolated signal to create a isolated +15 VDC voltage for the regulator board's external speed reference.

The IGBT inverter is switched by gating signals to transform the filtered D-C voltage into a three-phase PWM (pulse-width modulated) voltage signal. The gating signals are sent through the daughter board and are delivered to the IGBT inverter via isolated drivers on the base board. The IGBT's PWM output voltage corresponds to the variable voltage and variable frequency source selected for the motor. Two of the three PWM voltage output lines (Phase U and V) are sent through the daughter board for phase current sensing. The phase current feedback signals from the daughter board are applied to the regulator board of control usage. Upon returning to the base board, the two PWM voltage output lines along with the third output line (Phase W) are sent to drive's power terminals U, V and W.

In summary, a constant D-C voltage is developed by rectifying and filtering the incoming A-C power line voltage. A PWM three-phase voltage is then produced from this constant voltage using an IGBT inverter corresponding to the variable voltage and frequency selected for the motor.

7.1.2 Drive Regulator Operation

Drive regulator operation is directed by a microprocessor system resident on the regulator board. The operation is divided into two sections, the membrane switch/bracket assembly (keypad) and the regulator board. All drive operation directed by the system is based on selected or adjustable parameters programmed into the microprocessor system by the user through the keypad. Keypad (switch) data, via a ribbon cable, enters the drive's regulator board through connector J9 where it enters a latching shift register for multiplexing into the microprocessor system. After isolating receivers, the control wiring data (via the control terminal strip) is also multiplexed to the microprocessor system through the latching shift register.

Power circuit feedback signals, a jumper selected external speed reference, and an internal heat sensor are all scaled and delivered to the regulator's microprocessing system through A/D conversion. The bus voltage and current and phase current feedback signals are used to provide trip-free (fault) characteristics, over/under voltage detection, and overcurrent detection during drive operation. The external (analog) speed reference parameter selected can be either \pm 0-10 VDC signal from an 5K ohm potentiometer or 0-20 mA process control signal by properly jumpering J4.

A heat sensor is provided for overtemperature detection and indicates when the inside ambient temperature of the drive is over specified limits.

The regulator's microprocessing system also receives information from a pulse tach attached to the motor. The pulse tach information is required by the microprocessor system for vector control. The pulse tach provides two signals and their complements to the regulator board for better noise reduction.

Under control from the microprocessing system, the regulator system delivers:

- PWM gating signals to the IGBT
- Provides form A and B contacts for IET/Drive running indications
- Display data for a four-character display and fourteen indicator LEDs
- An analog output
- A dynamic braking signal

The regulator board's microprocessor system sends PWM gating signals through the daughter board to isolated driver's on the base board. On the base board, the gating signals are delivered to isolated driver's and sent to switch the IGBT. The switching of the IGBT (directed by the gating signals) produces the PWM signal that corresponds to the selected frequency and voltage requested for the motor. The IGBT can be switched at either 2, 4 or 8kHz carrier frequency. A low carrier frequency will minimize drive heating but also increase acoustic noise, while a higher carrier frequency maximizes drive heating, but decreases acoustic noise.

The form A and B contacts are directed under parameter control. A form A or B transition can indicate a fault has occurred or that the drive is operating. The contacts are rated for 5 amps resistive load at 250 VAC/30 VDC and are made available through the control terminal strip.

The four-character display is used to indicate the drive's display modes, parameters, parameter values, and fault codes. The fourteen LED's give the user an "at a glance" indication of drive operational status and mode of control. Physical placement of the display and LED indicators on the regulator board permits viewing through the membrane switch and bracket assembly.

The analog output is a scaled voltage (0-10 VDC) or current (4-20 mA) signal proportional to either actual motor speed (RPM) or motor torque/current (%TORQUE). The current selection (via jumper J17) requires a user-supplied external power supply for operation. The analog output signal is available through the control terminal strip.

The regulator board's microprocessor system provides an interfacing signal for use by an optional dynamic braking kit. The signal goes through an isolating driver, made available through the control terminal block.




Figure 7.2 - Typical System Block Diagram

7.2 Fault Codes

The GV3000 drive displays fault codes to assist in troubleshooting should a fault occur during self-tuning or during drive operation. If a fault condition occurs while the drive is self-tuning or running, the drive will coast-to-stop and the fault type will flash on the drive display as a 2 or 3-digit alphabetical code.

The fault is then entered into the error log. The error log is accessible through the keypad and is displayed as "ERR" on the display. If a fault occurs when performing self-tuning, an SF (self-tuning fault) will be entered into the error log and the type of fault will be indicated in the parameter value of U.009 (Results of Torque Control Self-Tuning).

7.2.1 How to Access and Read the Error Log and Time Stamp

Faults codes are entered into the error log in sequential order if more than 1 fault should occur. The front panel will only display the first fault to occur. The other faults will be logged into the error log. (The error log must be accessed to see any additional faults.) After ten faults have occurred, no more subsequent faults will be entered in the error log. There is NO visual indicator to the user that the error log is completely filled and has stopped logging errors.

The faults entered into the error log are numbered sequentially. If first an overcurrent (steady state) were to occur, it would be displayed in the error log as [0. OC]. If next a thermal overload fault were to occur (and the first error was not yet cleared), it would be displayed in the error log as [1. OH], and so on.

The last fault to occur will appear first when accessing the error log. For example, if the last fault was a low bus fault, and the error log contains 9 entries, then the error log would display [8. LU] when the error log is first accessed.

Each fault code contained in the error log has an associated time stamp. The time stamp contains the day (based on a 0 to 248 day counter) and the time (based on a 24 hour clock providing both hours and minutes). Refer to "*To Access the Error Log Time Stamp*".

A single error entry in the log cannot be cleared. Only the entire error log and time stamp of each fault can be cleared.

Faults are retentive (stored) to the error log if a power loss occurs.

Table 7.1 lists fault codes, descriptions, causes, and possible actions.

Displays and keyboard actions for viewing the drive's error log is shown in figure 7.3.

7.2.1.1 Accessing the Error Logs

NOTE: This procedure assumes that you have already entered the password for the second menu list (P.006).

Action	Display/Notes
1. Press the PROGRAM key.	Display shows [P.---] - General parameters. The PROGRAM LED goes ON .
2. Press the DOWN ARROW key.	Display shows [U.---] - Vector parameters.
3. Press the DOWN ARROW key.	Display shows [Err] - Error log entries.
4. Press the ENTER key.	Display shows the error log entry - "last fault to occur", not necessarily, the flashing error displayed when the detected fault stopped the drive. For example, the flashing display code is [HU], while the last fault shown in the error log is [6. OC]. All errors in the log, from the last fault displayed [example 6. OC], to the flashing fault code on the display, occurred to cause the drive to stop.
NOTE: If interested in the approximate time that a fault occurred, refer to "To Access the Error Log Time Stamp".	
5. Press the PROGRAM key.	Display shows [P.---] - General parameters.
6. Press the UP ARROW key.	Display returns to the flashing fault code display or, if the RESET key was pressed, a [0] display.
7. Press the PROGRAM key.	

7.2.1.2 Accessing the Error Log Time Stamp

NOTE: The following procedure assumes that access has been obtained to the error log.

Action	Display/Notes
1. Pressing the UP ARROW key or DOWN ARROW key.	Display will step through error log entries.
2. Press the ENTER key.	Example: Display shows [117] - Day Time Stamp. NOTE: The day entry of the time stamp can be 0-248 days.
3. Press the DOWN ARROW key.	Example: Display shows [22.17] - Time Stamp. NOTE: Time is recorded on a 24-hour clock basis. The first two digits represent hours while the last two digits represent minutes.
4. Press the PROGRAM key. (Returning to error log.)	Display shows the error log entry prior to/associated with the last viewed time stamp.
5. Repeating steps 1 through 4 on any error log entry.	This will let you view the time stamp associated with each error log fault code entry.

7.2.2 How to Access and Read the Results from Torque Self-Tuning

A result code is entered into vector parameter U.009 with each performance of self-tuning. When a fault occurs during self-tuning, the display may or may not show a blinking self-tuning fault code. If more than 1 fault should occur during self-tuning, the front panel will only display the first fault code. All other faults will be logged into the error log in sequential order including the self-tuning fault code. Therefore, the error log must be accessed to see any additional faults. There is NO visual indicator to the user that the error log contains any additional fault codes which occurred during self-tuning.

7.2.2.1 Accessing the Self-Tuning Result Code (displayed in Parameter U.009)

NOTE: *This procedure assumes that you have already entered the password for the second menu list (P.006).*

Action	Display/Notes
1. Press the PROGRAM key.	Display shows [P.---] - General parameters. The PROGRAM LED goes ON .
2. Press the DOWN ARROW key.	Display shows [U.---] - Vector parameters.
3. Press the ENTER key.	Display shows [U.000] - the first Vector parameter.
4. Pressing the UP ARROW key or DOWN ARROW key.	Display will step through the vector parameter list.
NOTE: <i>Step through the vector parameter list until the display shows [U.009] - (results of torque control self-tuning).</i>	
5. Press the ENTER key.	Display shows [example: 5] - the result of self-tuning. (Refer to table 7.1 for more information on self-tuning result codes.)
6. Press the PROGRAM key.	Display shows [U.009] - Returns to vector parameter list.
7. Press the PROGRAM key.	Display shows [U.---].
8. Press the DOWN ARROW key.	Display shows [Err] - Error Log.
NOTE: <i>After checking vector parameter U.009 for the self-tuning result code, always check the error log for additional fault entries.</i>	

Table 7.1 - Troubleshooting IET Fault Codes

FL - Function Loss	
Cause	Action
<ul style="list-style-type: none"> ● Function loss input on control terminal is opened 	<p>Check that motor interlocks are connected. (Refer to section 3.12.)</p> <p>Motor thermal switch has opened.</p> <p>Drive heatsink thermostat has opened.</p> <p>Check that there is a connection between terminals 16 and 20 or jumper terminal on the control terminal strip. (Refer to section 3.7.2.)</p>
HU - High D-C Bus Voltage	
Cause	Action
<ul style="list-style-type: none"> ● Input voltage too high 	<p>Check input line voltage and, if necessary, add a transformer (See section 3.)</p>
<ul style="list-style-type: none"> ● Deceleration time too short 	<p>Parameter P.002 (deceleration time) is set too fast (small) given the maximum speed (P.004) setting, and motor inertia load. Increase the deceleration time. If problems still exist, consider adding a dynamic braking kit to the drive.</p>
LU - Low D-C Bus Voltage	
Cause	Action
<ul style="list-style-type: none"> ● Input voltage too low 	<p>Check input line voltage. If necessary, add a transformer (See section 3.)</p> <p>Input voltage line dip exceeded the 500 ms limit.</p> <p>NOTE: <i>If the drive was running when the fault occurred and the line dip does not exceed the 500 ms limit, the drive will automatically restart.</i></p>
OC - Overcurrent (steady state) OCA - Overcurrent (Accelerating) OCd - Overcurrent (decelerating)	
Cause	Action
<ul style="list-style-type: none"> ● Bad Motor 	<p>Check the motor for correct operation.</p>
<ul style="list-style-type: none"> ● Ground Fault 	<p>Check input and output wiring. (Refer to section 3, Installation and Wiring)</p>
<ul style="list-style-type: none"> ● Phase to Phase short 	
<ul style="list-style-type: none"> ● Parameter settings <p style="text-align: center;">(OCA - specific) (OCd - specific)</p>	<p>Check that parameters U.001 (pulse tach select), U.002 (motor pole number), U.003 (motor base frequency), U.004 (motor rated amps) and U.006 (Percent motor magnetizing amps) are set correctly.</p> <p>NOTE: <i>If magnetizing amps is not provided on the motor nameplate, perform self-tuning.</i></p> <p>Parameter U.012 (speed regulator proportional gain) may be incorrect.</p> <p>Parameter U.013 (speed regulator integral gain) may be incorrect. If a fault does not occur, the gain may still be set incorrectly. The motor speed may be unstable and/or the motor may exhibit a washing machine effect (i.e. forward rotation then reverse rotation)</p> <p>Parameter P.001 (acceleration time) may be incorrect given the maximum speed (P.004) setting and motor inertia load.</p> <p>Parameter P.002 (deceleration time) may be incorrect given the maximum speed (P.004) setting and motor inertia load.</p>
<ul style="list-style-type: none"> ● Pulse tach wired incorrectly wrong tach PPR 	<p>Check that pulse tach is wired correctly. (Refer to section 3 for pulse tach wiring information.)</p>

Table 7.1 - Troubleshooting IET Fault Codes (Continued)

OF - Overfrequency	
Cause	Action
<ul style="list-style-type: none"> • Drive has exceeded maximum allowable output frequency. Maximum frequency is 132 Hz. 	<p>Check that parameters U.001 (Pulse Tach select), U.002 (Motor Pole number), and U.003 (Motor base frequency) are set correctly.</p>
OH - Overtemperature	
Cause	Action
<ul style="list-style-type: none"> • Drive internal temperature has exceeded specified limit. 	<p>Check that outside ambient temperature is within drive specification. Check that internal and external fans are operational.</p>
OL - Electronic Thermal Overload	
Cause	Action
<ul style="list-style-type: none"> • Excess motor current 	<p>Check that parameter U.004 (motor rated amps) is set correctly. Check that drive is sized correctly for the motor. (Motor Horsepower (HP) should not exceed the drive HP rating. (See section 2 for more information.))</p>
<ul style="list-style-type: none"> • Loss of phase connection 	<p>Check the drive output lines to the motor.</p>
OSP - Overspeed	
Cause	Action
<ul style="list-style-type: none"> • The drive is equipped for a 130% maximum speed protection. 	<p>Check that parameters U.001 (Pulse Tach select), U.002 (Motor Pole number), U.003 (Motor base frequency), and U.005 (motor rated speed) are set correctly. Parameters U.012 (speed regulator proportional gain) and U.013 (speed regulator integral gain) may be set too high. Adjust both to remove condition.</p>
PH - Motor Phase Loss	
Cause	Action
<ul style="list-style-type: none"> • Loss of a motor phase (line) from the drive to the motor 	<p>Check the U, V, and W phase connections to the motor. Replace any damaged line(s).</p>

Table 7.1 - Troubleshooting IET Fault Codes (Continued)

SF - Self-Tuning	
Cause	Action
NOTE: The following causes represent the numbers displayed as the self-tuning result in Parameter U.009.	
<ul style="list-style-type: none"> ● 1 - user stop ● 2 - Emergency stop fault during self-tuning 	A user stop has been pressed, or a fault occurs during self-tuning. (Once the motor stops, clear the faults (both parameter and hardware) and again perform self-tuning.)
<ul style="list-style-type: none"> ● 3 - Motor or pulse tach direction reverse 	The motor is rotating in wrong direction. (Motor rotation should be in a clockwise direction from the tach end of the motor). If the motor rotation is correct, check that the pulse tach is wired correctly. (Refer to section 3.7.2.) Change drive U and V phases with one another, if tach wiring is correct.
<ul style="list-style-type: none"> ● 4 - Pulse tach PPR 	Check that the pulse tach's PPR is one of the four tach PPR's allowed for use with the drive. If not one of the four, replace the tach. Check that the pulse tach is wired correctly. (Refer to section 3.7.2).
<ul style="list-style-type: none"> ● 5 - Motor magnetizing amps ratio out of range 	Check that parameters U.002 (Motor Pole number), U.003 (Motor base frequency), U.004 (Motor rated Amps), and U.005 (motor rated speed) are set correctly.
<ul style="list-style-type: none"> ● 6 - D-C Bus voltage out of range 	If the line voltage is within limits, contact Reliance Electric.
<ul style="list-style-type: none"> ● 7 - Current limit detected 	Check that parameters U.002 (Motor Pole number), U.003 (Motor base frequency), U.004 (Motor rated Amps), and U.005 (motor rated speed) are set correctly.
nCL - Network Communications Loss	
Cause	Action
<ul style="list-style-type: none"> ● Communications with the AutoMax network master has been lost 	Check that all network cabling, from network master to drive's Network Board terminal strip, are properly connected. Check that AutoMax network master is functioning properly.
CHS - Checksum Error	
Cause	Action
<ul style="list-style-type: none"> ● Regulator Failure 	Replace regulator.
F xx – Fatal Fault	
Cause	Action
<ul style="list-style-type: none"> ● Microprocessor failure 	Return unit to Reliance Electric. These faults cannot be reset. Cycling power may clear this condition temporarily.

7.3 Verifying D-C Bus Voltage

DANGER

AFTER DISCONNECTING INPUT POWER WAIT FIVE MINUTES AND CHECK WITH A VOLTMETER TO INSURE THAT D-C BUS VOLTAGE CAPACITORS ARE DISCHARGED. THE VOLTMETER SHOULD READ ZERO VDC. FAILURE TO OBSERVE THIS PRECAUTION COULD RESULT IN SEVERE BODILY INJURY OR LOSS OF LIFE.

Before servicing the drive:

1. Turn OFF, and lock out and tag power to the drive.
2. Verify that there is no voltage entering the drive at A-C input power terminals R(L1), S(L2), and T(L3).
3. Verify at D-C Bus terminals (+) and (-) on the power terminal strip that the D-C Bus voltage has fallen to zero VDC. This will take a few minutes. See figure 7.4 for location of the D-C Bus terminals.






Figure 7.4 - D-C Bus Identification

4. Table 7.2 contains a list of GV3000 replacement parts. Refer to figures 7.5 and 7.6 or replacement parts location and additional information.

Table 7.2 - Replacement Parts List For GV3000 Drive

Description	Part Number	Quantity per Horsepower							
		1	2	3	5	7.5	10	15	20
Fan Assembly	615161-S			1	1	2	2	2	2
NEMA 1 Cover	805531-1R 805538-1R 805547-1R	1	1	1	1	1	1	1	1
NEMA 4X Cover/ gasket	805532-1R 805539-1R	1	1	1	1	1	1		
NEMA 12 Cover	805547-2R							1	1
Membrane Switch (keypad)/ bracket	709576-1R 709577-1R 805548-1R	1	1	1	1	1	1	1	1
Regulator PCB	0-56921-220	1	1	1	1	1	1	1	1
Capacitor PCB	0-56928-30 0-56928-50 0-56934-100 0-56948-015 0-56948-020	1	1	1	1	1	1	1	1
Daughter PCB	0-56926-20 0-56926-50 0-56935-100	1	1	1	1	1	1		
Power Board	0-56949-020							1	1
Signal Board	0-56950-015 0-56950-020							1	1
Gate Driver Board	0-56947-020							1	1
Fan Assembly Internal	615159-1R 615159-1S	1	1	1	1	1	1	1	1

REPLACEMENT PARTS




NOTES:


- <1. NEMA 1 COVER IS VENTED AND CONTAINS COMMUNICATIONS ACCESS DOOR.
- <2. NEMA 4X COVER IS NOT VENTED AND SUPPLIED WITH BASE AND KEYPAD GASKETS.
- <3. REMOVE THE INTERNAL FAN ASSEMBLY BRACKET BEFORE DISCARDING OLD MEMBRANE SWITCH/BRACKET. THE FAN BRACKET IS NOT SUPPLIED AND MUST BE REUSED WITH THE REPLACEMENT MEMBRANE SWITCH/BRACKET.

Figure 7.5 - GV3000 Replacement Parts Locations (460 VAC 1,2,3, and 5 HP)

REPLACEMENT PARTS




NEMA 1 <1




NEMA 4 <2

COVERS



CAPACITOR BOARD




DAUGHTER BOARD




FAN ASSEMBLY




FAN ASSEMBLY (INTERNAL)



<3



MEMBRANE SWITCH (KEYPAD)/BRACKET




REGULATOR BOARD

NOTES:


- <1. NEMA 1 COVER IS VENTED AND CONTAINS COMMUNICATIONS ACCESS DOOR.
- <2. NEMA 4X COVER IS NOT VENTED AND SUPPLIED WITH BASE AND KEYPAD GASKETS.
- <3. REPLACEMENT OF THE CAPACITOR AND DAUGHTER BOARDS REQUIRES THE REMOVAL OF THE MEMBRANE SWITCH/BRACKET AND BASE BRACKET.

Figure 7.6 - GV3000 Replacement Parts Locations (460 VAC 7.5 and 10 HP)

REPLACEMENT PARTS




1> NEMA 1



2> NEMA 12

COVERS



NOTES:

- 1> NEMA 1 COVER IS VENTED AND CONTAINS COMMUNICATIONS ACCESS DOOR.
- 2> NEMA 4X COVER IS NOT VENTED AND IS SUPPLIED WITH BASE AND KEYPAD GASKETS.
- 3> REPLACEMENT OF THE CAPACITOR, SIGNAL, & POWER BOARDS REQUIRES THE REMOVAL OF THE MEMBRANE SWITCH/TOP BRACKET AND SIGNAL BOARD/GATE DRIVER/BOTTOM BRACKET.

Figure 7.7 - GV3000 Replacement Parts Locations (460 VAC 15 and 20 HP)

8.0 PARAMETER QUICK REFERENCE GUIDE

Table 8.1 - First Menu Parameters (P---) - Short List

Parameter Number		Parameter Description	Parameter Selection/ Adjustment Range	Initial Factory Setting	User Data	
					Date	Setting
First Menu - General Parameters	P.000	Operation Control	LOCL = LOCAL front panel keypad rE = REMOTE (Terminal Block Inputs) OP = Option Port PC = Host PC	LOCL		
	P.001	Acceleration Time (seconds)	0.1 - 999.9 seconds	20.0		
	P.002	Deceleration Time (seconds)	0.1 - 999.9 seconds	20.0		
	P.003	Minimum Speed (RPM)	0 - Maximum Speed (P.004)	150		
	P.004	Maximum Speed (RPM)	10- Motor Rated Speed (U.005)	1722		
	P.005	Current Limit	U.006-150%	150		
	P.006	Second Menu and Password Enable NOTE: After entering password number, P.006 will change back to zero.	607 = Second Menu Enable/Disable	0		

Table 8.2 - Second Menu Parameters (P---)

Parameter Number		Parameter Description	Parameter Selection/ Adjustment Range	Initial Factory Setting	User Data	
					Date	Setting
Second Menu - General Parameters	P.007	Terminal Block Digital Input Configure NOTE: <i>The REM/LOC digital input allows you to temporarily switch from a REMOTE running condition to LOCAL operation without breaking the 2-wire control RUN signal.</i> NOTE: <i>For second RAMP times see P.017 (accel) and P.018 (decel).</i> NOTE: <i>You first must assign the digital inputs (setting P.007 to some value other than 0) before P.008 will allow being changed to something other than 0.</i>	0 = Digital Input 6 = FWD/REV Digital Input 7 = RAMP1/2 Digital Input 8 = REM/LOC 1 = Digital 7 = FWD/REV Digital 8 = RAMP1/2 2 = Digital 7 = FWD/REV Digital 8 = REM/LOC 3 = Digital 7 = RAMP1/2 Digital 8 = REM/LOC 4 = Digital 8 = FWD/REV 5 = Digital 8 = RAMP1/2 6 = Digital 8 = REM/LOC 7 = Digital Inputs 6- 8 are defined by P.008, or not used.	0		
	P.008	Terminal Block Speed Reference Selection (See P.007 to configure digital inputs 6, 7, and 8.)	0 = Analog Reference 1 = MOP (Uses terminal block digital inputs 6=Increment, 7=decrement) 2 = 2 Multi-speed Presets (uses terminal block digital input 6) 3 = 4 Multi-speed Presets (uses terminal block digital inputs 6 and 7) 4 = 8 Multi-speed Presets (uses terminal block digital inputs 6-8).	0 = Analog Reference		
	P.009	Terminal Block Analog Input Speed Reference Offset	-250 to 250 (NOTE: <i>Units = 1023 counts = +10V. Approx. 102 = 1V offset.</i>)	0		
	P.010	Terminal Block Analog Speed Reference Gain	0.750 - 1.250	1.000		

Table 8.2 - Second Menu Parameters (Cont'd.)

Parameter Number	Parameter Description	Parameter Selection/ Adjustment Range	Initial Factory Setting	User Data		
				Date	Setting	
Second Menu - General Parameters (Cont'd.)	P011	Terminal Block Analog Speed Reference Invert Selection (Input becomes inverted when enabled.) NOTE: <i>If the terminal block analog input is selected as the torque reference (U.000=1), then substitute +/- 150% torque limit for +/- motor rated RPM (U.005).</i>	OFF = <ul style="list-style-type: none"> ● 0-20mA: 0mA=0, 20mA=+ motor rated RPM ● 0-10VDC: 0VDC=0, +10VDC= + motor rated RPM ● -10 VDC to 10VDC: -10VDC= - motor rated RPM, +10VDC= + motor rated RPM ON = <ul style="list-style-type: none"> ● 0-20mA: 0mA=0, 20mA= - motor rated RPM ● 0-10VDC: 0VDC=0, +10VDC=- motor rated RPM ● -10VDC to 10VDC: -10VDC= + motor rated RPM, +10VDC= - motor rated RPM 	OFF		
	P012	Terminal Block Analog Output Source Selection	0 = Speed Loop Feedback 1 = Torque/Current Feedback	0		
	P013	Output Relay Configuration (See terminal block terminals 28-31)	0 = relay energized is state of active fault (IET) 1 = relay energized is state of drive running with 0.5 sec delay 2 = relay energized is state of drive running <u>without</u> 0.5 sec delay 3 = relay energized indicates that Network communications is active	0		
	P014	Trim Reference Source Selection	0 = No Trim Reference 1 = Terminal Block Analog Input 2 = N/A 3 = Maximum Speed (P004) 4 = Torque Current Feedback	0		
	P015	Trim Gain Percentage	- 99.9% to +99.9%	0.0		
	P016	Draw Gain Percentage	- 99.9% to +99.9%	0.0		
	P017	Second Ramp Acceleration Time (Seconds)	0.1 - 999.9 seconds	20.0		
	P018	Second Ramp Deceleration Time (Seconds)	0.1 - 999.9 seconds	20.0		
	P019	S-Curve Selection (NOTE: <i>This selection does not apply to the Jog Accel or Decel Parameters.</i>)	OFF = Use Linear Accel/Decel Function ON = Use S-Curve Function	OFF		

Table 8.2 - Second Menu Parameters (Cont'd.)

Parameter Number	Parameter Description	Parameter Selection/ Adjustment Range	Initial Factory Setting	User Data		
				Date	Setting	
Second Menu - General Parameters (Cont'd.)	P.020	Jog Speed Reference (RPM)	Min Speed (P.003) - Maximum Speed (P.004)	150		
	P.021	Jog Ramp Acceleration Time (Seconds)	0.1 - 999.9 seconds	20.0		
	P.022	Jog Ramp Deceleration Time (Seconds)	0.1 - 999.9 seconds	20.0		
	P.023	MOP Reference Rate (Seconds)	0.1 - 999.9 seconds	20.0		
	P.024	MOP Reset	0 = Reset MOP setpoint after IET 1 = Reset MOP setpoint during each stop 2 = Do not reset MOP setpoint	0		
	P.025	STOP Type Selection	0 = Coast to rest stop 1 = Ramp to rest stop	0		
	P.026	Function Loss Selection	0 = Fault trip at Function Loss <i>NOTE: You must press the STOP/RESET key to restart the drive. This selection causes the output relay to be asserted.</i> 1 = Coast to test stop without output at Function Loss. The output relay is not asserted.	0		
	P.027	Reverse Disable	Off = Drive will run in reverse direction On = Drive will not run in reverse direction. (The REVERSE LED will not light.)	OFF		
	P.028	RPM Display Mode Scaling (Used to scale the RPM display mode value to any Engineering Unit.)	10 - 9999 Example: <u>Current Speed x P.028</u> P.004 (Maximum Speed) = Value displayed when RPM mode is selected	1722		
P.029	Elapsed Time Meter Readout	0 - 9999 days	N/A			

Table 8.2 - Second Menu Parameters (Cont'd.)

Parameter Number	Parameter Description	Parameter Selection/ Adjustment Range	Initial Factory Setting	User Data		
				Date	Setting	
Second Menu - General Parameters (Cont'd.)	P030	Elapsed Time Meter Reset (Resets the meter to zero.)	OFF = No action. ON = Reset elapsed time meter to zero (0). (P029 will be reset = 0.)	OFF		
	P031	Multi-speed Preset #1	P003 (Min Speed) - P004 (Max Speed)	150		
	P032	Multi-speed Preset #2	P003 (Min Speed) - P004 (Max Speed)	150		
	P033	Multi-speed Preset #3	P003 (Min Speed) - P004 (Max Speed)	150		
	P034	Multi-speed Preset #4	P003 (Min Speed) - P004 (Max Speed)	150		
	P035	Multi-speed Preset #5	P003 (Min Speed) - P004 (Max Speed)	150		
	P036	Multi-speed Preset #6	P003 (Min Speed) - P004 (Max Speed)	150		
	P037	Multi-speed Preset #7	P003 (Min Speed) - P004 (Max Speed)	150		
	P038	Multi-speed Preset #8	P003 (Min Speed) - P004 (Max Speed)	150		
	P039	Reserved for later use				
	P040	Electronic Motor Thermal Overload	OFF = Electronic Motor Thermal Overload is disabled ON = Electronic Motor Thermal Overload is enabled	ON		
	P041 - P046	Reserved for later use				
	P047	Carrier Frequency Selection (If values are entered from the options port, they will be 0, 1, and 2 instead of 2, 4, and 8.)	2 = 2 kHz Carrier Frequency 4 = 4 kHz Carrier Frequency 8 = 8 kHz Carrier Frequency	8		
	P048	Drive Type Selection	UEC = Vector Control	UEC		
	P049	Default Type Selection	USA = USA defaults EUr = Europe defaults JPn = Japan defaults	USA		
	P050	Restore Default Settings	OFF = No action. ON = Reset Parameters to default settings.	OFF		
	P051	Program Lockout	1044 = Disable/Enable programming	0		
	P052	Software Version	N/A	N/A		
	P053 - P059	Reserved for later use				
	P060	Drop Number Assignment	1 to 55 (Basic Connection) 1 to 53 (Full Connection)	1		

Table 8.2 - Second Menu Parameters (Cont'd.)

Parameter Number		Parameter Description	Parameter Selection/ Adjustment Range	Initial Factory Setting	User Data	
					Date	Setting
Vector Control Parameters	P.061	Network Connection Type	0 = Basic Connection 1 = Full Connection	0		
	P.062	Comm Loss Selection	0 = IET Fault 1 = Hold Last Reference 2 = Use Terminal Block Reference	0		
	P.063	Network Reference Source Select	0 = Direct Reference 1 - 8 = Broadcast	0		
	P.064	Reserved for later use				
	P.065	Option Port Type + Version Number	read only	N/A		

Table 8.3 - Vector Control Parameters (U.---)

Parameter Number	Parameter Description	Parameter Selection/ Adjustment Range	Initial Factory Setting	User Data	
				Date	Setting
U.000	Torque Reference Source Selection	0 = Use Speed Loop Output 1 = Terminal Block Analog Input 2 = Option Port	0		
U.001	Pulse Tachometer Selection NOTE: This parameter is automatically calculated during Self-tuning (P.008).	512 = 512 PPR 1024 = 1024 PPR 2048 = 2048 PPR 4096 = 4096 PPR	1024		
U.002	Motor Pole Number	2 = 2 poles 4 = 4 poles 6 = 6 poles 8 = 8 poles	4		
U.003	Motor Base Frequency (Hz)	Enter from motor nameplate. 30.0 - 120.0 Hz	60		
U.004	Motor Rated Amps (A)	Enter from motor nameplate.	7.1		
U.005	Motor Rated Speed (RPM)	Enter from motor nameplate.	1722		
U.006	Motor Percent Magnetizing Amps (Percent of magnetizing current with respect to rated current.) NOTE: <i>This parameter is automatically calculated during Self-tuning (U.008).</i>	10.0% - 80.0%	54.5		
U.007	Reserved for later use				
U.008	Torque Self-Tune Selection Self tuning will calculate values for Parameters U.001 and U.006.	OFF = Disable self-tuning. ON = Begin self-tuning after START command. NOTE: <i>Motor MUST NOT BE LOADED during Self-Tuning!</i>	OFF		

Table 8.3 - Vector Control Parameters (Cont'd.)

Parameter Number		Parameter Description	Parameter Selection/ Adjustment Range	Initial Factory Setting	User Data	
					Date	Setting
Vector Control Parameters (Cont'd.)	U.009	Torque Self-tune Result	0 = Torque self-tuning was successful 1 = User initiated a normal ramp stop sequence 2 = Emergency coast stop or fault stop 3 = Motor or pulse tach direction reverse 4 = Pulse tach PPR out of range 5 = Motor magnetizing current percent ratio out of range 6 = Bus voltage out of range 7 = Current limit exceeded	Output dependent on result.		
	U.010	Reserved for later use				
	U.011	Reserved for later use				
	U.012	Speed Regulator PGain Setting	0.01 - 99.99	2.0		
	U.013	Speed Regulator IGain Setting	0.02 - 327.67	2.0		

A-C DRIVES TRAINING AND AUDIO/VISUAL PRODUCTS

Reliance Electric offers a wide variety of Industrial Training courses for electricians, electronic technicians and engineers who are responsible for the installation, repair and maintenance of production equipment and systems.

Professional quality A/V Programs are also available. These programs have been designed to provide years of efficient in-house training. Available for playback at the user's convenience, these videotape programs allow individual or groups to learn or review subjects at any time.

Printed reference materials come with all diagnostic and troubleshooting programs.

Training Courses

No.	Title
A-C DRIVE COURSES	
2-1	Maintenance and Troubleshooting of VVI Style Variable-Speed A-C Drives
2-5	Maintenance and Troubleshooting of PWM Style Variable-Speed A-C Drives
2-4	VVI/PWM A-C Drives Hands-On Troubleshooting Lab
2-7	Maintenance and Troubleshooting VCI A-C Inverters
2-8	Maintenance and Troubleshooting VGI A-C Inverters

Audio/Visual Products

Order No.	Title	Format	Price
A-C DRIVES PROGRAMS			
TM2241	Introduction to the VVI	Videotape	\$725
TM2242	Troubleshooting the VVI Regulator	Videotape	995
TM2367	Troubleshooting the 6-Transistor Power Module	Videotape	725
VIDEO TRAINING PROGRAMS			
VMBA001	Fundamentals of A-C Motors	Videotape	\$495
VMBV001	Concepts of Digital Controls	Videotape	495
VWVS001	GP2000 Video Training	Videotape	495
VWVS002	HR2000 Video Training	Videotape	495
VWVS005	Basics of A-C Drives	Videotape	495

For details and prices on these courses, audio/visual products and FREE Training Schedule Brochure, HD-405, contact:

Industrial Training Department
Reliance Electric
35000 Curtis Boulevard
Eastlake, Ohio 44095

Call Toll Free:

**800-RELIANCE
(800-735-4262)**

Reach us now at www.rockwellautomation.com


Wherever you need us, Rockwell Automation brings together leading brands in industrial automation including Allen-Bradley controls, Reliance Electric power transmission products, Dodge mechanical power transmission components, and Rockwell Software. Rockwell Automation's unique, flexible approach to helping customers achieve a competitive advantage is supported by thousands of authorized partners, distributors and system integrators around the world.

Americas Headquarters, 1201 South Second Street, Milwaukee, WI 53204, USA, Tel: (1) 414 382 2000, Fax: (1) 414 382 4444

European Headquarters SA/NV, Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific Headquarters, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Reliance Electric Standard Drives Business, 24800 Tungsten Road, Cleveland, Ohio 44117, USA, Tel: (1) 888 374 8370, Fax: (216) 266 7095



**Rockwell
Automation**