Fardware Reference, Installation, and Troubleshooting Manual D2-3417-2



GV3000/SE AC Drive 30 - 100 HP, 230V AC

Version 8.04





D Allen-Bradley - Rockwell Software

Important User Information

Solid-state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (publication <u>SGI-1.1</u> available from your local Rockwell Automation soles office or online at <u>http://www.rockwellautomation.com/literature/</u>) describes some important differences between solid-state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid-state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation. Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safery considerations.



A let Angle; Rockett Mohenn, Exclusion and a construction of a supercenter of some fragment for

A teacher realize any new Backed card ratio the prepared and require score price.

Document Update

Electronic Motor Overload Protection This product does not offer speed-sensitive overload protection, thermal memory retention or provisions to act upon motor over-temperature sensing in motors. If such protection is needed in the end-use product, it needs to be provided by additional means.

Notes:

The information below summarizes the charges made to this manual since its last release (August 1999).

Description of Changes	Page
Adade Document Update.	After manual Trant cover
Defeted the following statement: 'The Mater Overbace Finable parameter (RC40) can be used in place of the electronic thermal overlead relays in single motor applications'	6-1

Notes:

CONTENTS

Chapter 1	Becc	oming Familiar with the Manual
355 S.S.A.G. 256 D.S.	1.1	Finding Information
	1.2	Assumptions About the Audience
	1.3	Understanding Terms Used in this Manual
	1.4	If You Want to Know More
	1.5	Getting Assistance from Reliance Electric
Chapter 2	Abo	ut the Drive
	2.1	Identify the Drive by Model Number
	2.2	Enclosures
	2.3	30-100 HP GV3000/SE Drive Components and Locations
	2.4	Regulator Board Descriptor
		2.4.1 Jumper Locations and Settings
		2.4.1.1 Analog Input Speed Reference Jumper
		2.4.1.2 Analog Output Jumper
		2.4.2 Wring the Terminal Strip
		2.4.3 RS 232 Communication Port
		2.4.4 Option Board Connector
		2.4.5 Operator Interlace Module Connector
		2.4.6 Keypad/Display
	2.5	Jumpers on Base Board (PISC-40)
	2.6	Drive Kt Optons
Chapter 3	Plan	ning Before Installing
	\$.1	Requirements for the Installation Site
		3.1.1 Making Sure Environmental Conditions are Met
		3.1.2 Determining Total Area Required Based on Drive
		Dimensions
		3.1.3 Verifying the Site Provides for Recommended Air Flow
		Closrances
		2.1.4 Musiking Brown Musiking AC Januar, Bulling Mulak
		5.1.4 Veniying Power Module AC input Ratings Match
		Supplied Power
	3.2	wiring Requirements for the Drive
		3.2.1 Meeting Terminal Strip Input and Output Specifications
		3.2.2 Determining Wire Size Requirements
		S.2.2.1 Recommended Power Wire Sizes
		3.2.2.2 Recommended Control and Signal Wire Sizes
		8.2.2.3 Recommended Notor Lead Lengths
		3.2.2.4 Recommended Serial Communication Cable Lengths
		3.2.3 Selecting AC Input Line Branch Circuit Fuses. Circuit
		Breakers, and AC Reactors
		3.2.4 Meeting Encoder Specifical ons (FVC Regulation Only)
		3.2.4.1 Encoder Winng Guidelines

		3.2.5 Verifying Power Module Output Current Rating is Greater				
		Than Motor Full Load Amps	3-9			
Chapter 4	Mou	inting the Drive, Grounding, and Finding Wire Routing Locations				
	4.1	Mounting the Drive	4-1			
		4.1.1 Verify no the Drive's Watts Loss Rating	4-1			
	4.2	Routing Input, Motor Output, Ground, and Control Winno				
		for the Drive	4-1			
	1.3	Grounding the Drive	1-2			
Chapter 5	Inst	alling Input Power Wiring				
	5.1	Installing Transformers and Reactors (Optional)	5-1			
	5.2	Installing Fuses for Branch Circuit Protection	5-2			
	5.3	Installing a Required External/Separate Input Disconnect	5-2			
	5.4	Installing Power Wiring from the AC Input Line to the Drive's				
		Power Terminals	5-5			
	5.5	Installing Power Wiring from an External DC Bus to the				
		Drive's Internal DC Bus Terminals	5-5			
Chapter 6	Installing Output Power Wiring					
	6.1	Installing Output Contactors (Optional)	C-1			
	6.2	Installing Mechanical Motor Overload Protection (Optional)	6-1			
	6.3	Installing Oulput Wining from the Drive Oulput Terminal to the Motor	6-1			
Chapter 7	Wiri	ng the Regulator Board Terminal Strip				
	7.1	Stopping the Drive	7-6			
	7.2	Wiring the Encoder Feedback Device (FVC Regulation Only)	7-6			
	7.3	Wiring the Signal and Control I/O	7-9			
Chapter 8	Con	npleting the Installation				
	8.1	Checking the Installation	8-1			
	8.2	Powering Up After Installation is Complete	8-2			
Chapter 9	Tro	ubleshooting the Drive				
	9.1	Test Equ prisent Needed to Troubleshoot	9-1			
	9.2	Drive Alarms and Faults	9-1			
	9.3	Verifying That DC Bus Capacitors are Discharged	9-1			
	9.4	Checking Out the Power Module with Input Power OT	9-2			
	9.5	Replacement Parts	8-4			
Appendix /	A Tecl	hnical Specifications	A-1			
Appendix I	30-1	00 HP GV3000/SE System Wiring Diagram	B-1			

List of Figures

Figure 2.1 – Identifying the Drive Model Number	2-1
Figure 2.2 - 30 to 50 HP Drive Components and Locations	2-3
Figure 2.3 - 60 to 100 HP Drive Components and Locations	2-4
Figure 2.4 - Regulator Board Components and Locations	2-6
Figure 2.5 - Jumper J4 Settings for Analog Input Speed Reference	2-В
Figure 2.6 – Jumper J17 Settings for Analog Outputs	2-9
Figure 2.7 - Typical Terminal Strip Connections	2-10
Figure 2.8 – Keypad/Display	2-11
Figure 2.9 - Base Board Jumper Locations	2-12
Figure 3.1 – Drive Dimensions	3-3
Figure 3.2 - Recommended Air Flow Clearances	3-1
Figure 3.3 - How to Measure Motor Lead Lengths	3-7
Figure 4.1 - Terminal Locations	4-3
Figure 5.1 – Typical AC Input Electrical Connections	5-3
Figure 5.2 - Typical DC Input Electrical Connections	5-4
Figure 7.1 - Two-Wire Start/Stop Sample Control Wiring	7-4
Figure 7.2 - Three-Wire Start/Stop Sample Control Wiring	7-5
Figure 7.3 – Encoder Wiring Connections	7-8
Figure 9.1 – DC Bus Voltage Terminals	9-2

List of Tables

Table 2.1 -	Power Ratings	2-2
Table 2.2 –	Settings of Jumpers on Base Board	2-11
Table 2.3 -	Available Kits and Options	2-13
Table 3.1 -	Ambient Cond Lons	3-2
Table 3.2 –	Drive Dimensions and Weights	3-2
Table 3.3 –	Recommended Power Wire Sizes for 30 to 50 HP Drives	3-5
Table 3.4 -	Recommended Power Wire Sizes for 60 to 100 HP Drives	3-6
Table 3.5 –	Recommended Terminal Strip Wire Sizes	3-C
Table 3.6 -	Motor Lead Lengths	3-7
Table 3.7 –	Reactors	3-7
Table 3.8 –	AC Input Line Fuse Selection Values	3-8
Table 3.9 -	Circuit Breaker Salaction Values	3-9
Table 3.10 -	AC Reactor Selection Values	3-9
Table 5.1 –	AC Line Reactors	5-2
Table 7.1 -	RS-232 Connections (Terminals 1-3)	7-1
Table 7.2 -	Encoder Connections (Terminals 4-9)	7-1
Table 7.3 -	Analog Output Connections (Terminals 10 and 11)	72
Table 7.4 -	Analog Speed/Torque Reference Connections	
	(Terminals 12-15)	7-2
Table 7.5 -	Digital Input Connections (Terminals 16-25)	72
Table 7.6 -	Snubber Resistor Braking Connections (Terminals 26 and 27)	7-3
Table 7.7 –	Status Relay Connections (Terminals 28-31)	7-3
Table 7.8	Wiring Signal and Control I/O to the Terminal Strip	79
Table 9.1 –	Resistance Checks	9-3
Table 9.2 -	Replacement Parts for the GV3000/SE Drives	9-1
Table A.1 -	Service Conditions	A 1
Table A.2 -	Environmental Condition	A-2
Table A.3 -	Terminal Strip Input Specifications	A-2
Table A.4	Terminal Strip Output Specifications	A 2
Table A.5 -	Terminal Strip RS-232 Specifications	A-3
Table A.6 -	Encoder Feedback Device Specifications	
	(FVC Regulation Only)	AЭ
Table A.7 -	Input Signal Response Times (Maximum)	A-

CHAPTER 1

Becoming Familiar with the Manual

This chapter provides help in finding information in the manual and describes the intended audience. Also included are references to other related publications and instructions on receiving assistance from Reliance Electric.

1.1 Finding Information

This instruction manual describes the GV3000/SE drive's Power Module and regulator hardware. It does not cover the GV3000/SE software. For additional software information, refer to the GV3000/SE 230 VAC General Purpose (V/Hz) and Vector Duty Drive Software Start-Up and Reference Manual (D2-3416-1).

As an aid in finding information in this manual, each chapter is briefly described below:

	Chapter 1	 Becoming Familiar with the Manual
		Provides information on how the manual is organized and where to find additional information.
•	Chapter 2	- About the Drive
		Identifies drive components and shows their locations.
•	Chapter 3	- Planning Before Installing
		Presents information that must be considered when planning a drive installation.
•	Chapter 4	 Mounting the Drive. Grounding, and Finding Wire Routing Locations
		Describes now to mount the drive and properly ground it.
	Chapter 5	- Installing Input Power Wiring
		Describes incoming AC and DC line components and how to properly connect them.
	Chapter 6	- Installing Output Power Wining
		Describes output AC line components and how to properly connect them to the motor.
	Chapter 7	- Wiring the Regulator Board Terminal Strip
		Provides information on the I/O wiring that connects the terminal strip on the Regulator board.
•	Chapter 8	 Completing the Installation
		Provides instructions on how to perform a final check of the instal ation before power is applied.
20	Chanter O	Test block active the Drive

Describes the equipment that is needed to troubleshoot the drive and how to measure DC bus voltage. A replacement part list is also provided.

- Append x A Technical Specifications Lists drive specifications in table form.
- Append x B 30-100 HP GV9000/SE System Wiring D agram Provides additional wiring information for the 30-100 HP drives.

1.2 Assumptions About the Audience

This manual is intended for qualified electrical personnel. It is task-oriented and is organized according to a logical progression of steps to be followed to install and troubleshoot the drive.

1.3 Understanding Terms Used in this Manual

The following terms are defined according to the way they are used in this manual:

- GV3000/SE drives will typically be referenced by horsepower. If additional clarity is required, drive model numbers will also be included.
- Parameters will be referenced either as parameter (P.030) or Elapsed Time Meter Reset (P.030).

1.4 If You Want to Know More

Refer to the following related publications as necessary for more information:

- GV3000/SE 230 VAC General Purpose (Volts/Hertz) and Vector Duty Drive Software Start-up and Reference manual (D2-3416-1).
- Instruction manuals I sted in Table 2.8.

1.5 Getting Assistance from Reliance Electric

If you have any questions or problems with the products described in this instruction manual, contact your local Reliance Electric sales office. For technical assistance, call 1-800-726-8112.

CHAPTER 2

About the Drive

This chapter describes how to identify the drive using the model number matrix. Major components of each drive are also shown.

The GV3000/SE AC drive is a PWM (Pulse-Width-Modulation) drive that provides vector and general purpose regulation for a wide range of applications.

Using vector regulation, the drive can provide high dynamic response, maintain full rated motor torque to zero speed, and precisely control motor speed in both directions. The drive can provide this functionality either with encoder feedback (flux vector control or FVC) or without (sensoriess vector control or SVC).

Using general purpose (volts/hertz or V/Hz) regulation, the drive is suited for a broad range of applications requiring adjustable speed control of motors.

2.1 Identify the Drive by Model Number

Each GV3000/SE AC Drive can be identified by its model number. See figure 2.1. This number appears on the shipping label and on the drive's nameplate. The drive's model number includes the Power Module and the regulator. Drive power ratings are provided in table 2.1.

	NNN	V	2	Q N
Horseonwe: Balinus	3504-2		1.1	(a) 33
30 30 HP				1 1
40 - 40 HP				
50 = 50 HP				
60 – 60 HP				
75 - 75 HP				
100 = 100 HP				
GV3000SE -				
V = WH7 or Vector				
Voltage				
2 = 900 - 990 VAC				
2 - 200 - 230 190				
Enciesule				-
0 - Chassis				
Reculator Version				33
PC - Vector and V/Hz Begulator				
co - rector and trinz negulator				

Figure 2.1 - Identifying the Drive Model Number.

Model Number	Input Volts (AC)	input KVA	Input Amps (Maximum)	Output Amps (Maximum) (1937)	Power Loss Watts (Full Load)
30V2060	200-230 VAC +/ 10%	41.8	105 A	105 A	EEO
40V2060	200-230 VAG +/− 10%	53.8	135 A	135 A	900
50V2060	200-230 VAC +/ 10%	59.8	150 A	150 A	- 1CC
60V2060	200-230 VAC +/ 10%	$\overline{n}.\overline{r}$	195 A	195 A	-360
75V2060	200-230 VAC 1/ 10%	97.6	245 A	245 A	- 650
100V2060	200-230 VAC +\ 10%	109.E	275 A	275 A	2250

Lable 2.1 Power Patings

With vector regulation, 150% output or rent capability for one minute.
 These values are for operation with 4 kHz carrier frequency. For operation with 8 kHz carrier frequency, derating by 20% is recurred.

2.2 Enclosures

This manual describes GV3000/SE chassis style drives. These drives should be installed in cabinets.

2.3 30-100 HP GV3000/SE Drive Components and Locations

The 30-100 HP GV3000/SE drives have the following main components. The identification numbers provided correspond to the number used in figures 2.2 and 2.3. Replacement parts are listed in chapter 9.

- 1. Fan Assembly
- 2. Membrarie Switch (Keypad/Bracke.)
- 3. Regulator Printed Circuit Board
- 4. Base Board (PISC Board)
- 5. Bus Capacilor
- C. Internal Fan Assembly.
- 7. Cover





Figure 2.3 - 60 to 100 HP Drive Components and Locations

2.4 Regulator Board Description

GV3000/SE drive regulation is performed by a microprocessor on the Regulator board. See figure 2.4. Drive operation is adjusted by the parameters entered through the keypad. The Regulator board accepts power circuit feedback signals and an external speed reference signal, as well as data from an encoder that is attached to the motor when set up for FVC regulation. The Regulator board provides:

PWM gating signals to the IGBT power devices.

Based on the output of the control loop, the regulator sends PWM gating signals through the Current Feedback board to isolated drivers on the Gate Driver board. These drivers switch the Insulated Gate Bi-polar Transistors (IGBTs), producing a pulse-width-modulated (PWM) waveform that corresponds to the speed (FVC regulation) or frequency (volts/hertz regulation) reference. The IGBTs can be switched at either a 2, 4 or 8 kHz carrier frequency.

Form A and B contacts for drive status indicators

The Form A and B contacts are under control of the user via programmable parameters. A Form A or B transition can indicate drive status. The contacts are rated for 5 amps resistive load at 250 VAC/ 30 VDC and are made available through the terminal strip.

Display data for a four-characterid splay and fourteen indicator LEDs.

The four-character display is used to indicate drive parameters, parameter values, and fault codes. The fourteen single LEDs indicate drive status and mode, as well as identifying drive outputs whose values are displayed on the four-character display.

An analog output

The analog output is a scaled voltage (0-10 VDC) or current (4-20 mA) signal proportional to either motor speed (RPM) or motor torque or current (%TORQUE). The current signal selection (via jumper J17) requires a power supply for operation. The power can be sourced from the encoder terminals (4 and 9) or from an external 15V power supply. See table 7.8, terminals 10 and 11, for more information. The analog output signal is available through the terminal strip.

A snubber resistor braking signal

The Regulator board provides a signal for use by an optional snubber resistor braking kit. The signal is available through the terminal strip.



Figure 2.4 Regulator Board Components and Locations

2.4.1 Jumper Locations and Settings

Jumpers J4 and J17 on the Regulator board are factory-set for voltage in and voltage out signals. Refer to figure 2.4 for the rilocations on the Regulator board. If you need to change the jumpers' settings, use the following procedures.



ATTENTION: Do not alter the setting of any jumper not described in this instruction manual. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

2.4.1.1 Analog Input Speed Reference Jumper (J4)

Jumper J4 is the analog speed/.orque (U.080) reference jumper. This jumper selects either +/+ 10 VDC or 0-20 mA input. Parameters P.069, P.010, and P.011 are used in conjunction with the jumper. Note that if the position of jumper J4 is changed after the parameters are programmed, the software will not recognize that the input reference or polarity has been changed. Be sure to verify that parameters P.069, P.010, and P.011 are correct before starting the drive. Refer to the GV3000/SE Software Start-Up and Reference manual for more information.

Use the following procedure to set jumper J4:



ATTENTION: DC bus capacitors retain hazardous vo tages after input power has been disconnected. After disconnecting input power, wait five (5) minutes for the DC bus capacitors to discharge and then check the voltage with a voltmeter to ensure the DC bus capacitors are discharged before touch ng any internal components. Failure to observe this precaution could result in severe bodily injury or loss of life.

- Step 1. Turn off input power to the drive and wait five minutes.
- Step 2. Remove the cover from the drive by unscrewing the two attaching screws.
- Step 3. Verily that the DC bus voltage is zero by following the procedure in section 9.3.
- Step 4. Locate jumper J4 on the Regulator board. Refer to figure 2.4.
- Step 5. Locate pin 1 on jumper J4. Move the jumper to the desired setting as shown in figure 2.5.
- Step 6. Re-attach the cover.
- Step 7. Re-app y input power.
- Step 8. Verify that the Terminal Strip Analog Input Offset (P.009), Terminal Strip Analog Input Gain (P.010), and Terminal Strip Analog Input Configure (P.011) are correctly set. Note that the jumper settings must match the software settings otherwise the reference value may differ from what is expected. Refer to the GV3000/SE Software Start-Up and Reference manual for more information.



Figure 2.5 - Jumper of Settings for Analog Input Speed Reference

2.4.1.2 Analog Output Jumper (J17)

Jumper J17 is the analog output jumper. This jumper selects either a 0-10 VDC or 4-20 mA scaled signal output that is programmable for either speed or torque, parameter P.012. The jumper only selects a 0-10 VDC source voltage or 4-20 mA sink current to represent speed or torque. Note that the 4-20 mA current selection requires a power supply for operation as shown in table 7.8, term hals 10 and 11.

Use the following procedure to set jumper J17:



- Step 1. Turn off input power to the drive and wait five minutes.
- Step 2. Remove the cover from the drive by unscrewing the two attaching screws.
- Step 3. Verify that the DC bus voltage is zero by to lowing the procedure in section 9.3.
- Step 4. Locate jumper J17 on the Regulator board. Refer to figure 2.4.
- Step 5. Locate pin 1 on jumper J17. Move the jumper to the desired setting as shown in figure 2.6.
- Step 6. Re attach the cover.
- Step 7. Re apply input power.
- Step 8. Verify that parameter P.012 is set correctly for either speed or torque.



Figure 2.6 - Jumper J 17 Settings for Analog Outputa

2.4.2 Wiring the Terminal Strip

The terminal strip on the Regulator board provides terminals for connecting customer I/O devices. See figures 2.4 and 2.7. The following terminals are provided:

- Terminals 1.3 : RS 232 connections
- Terminals 4.9 : encoder connections
- Terminals 10 11: analog output connections
- Terminals 12 15: analog speed/torque reference connections
- Terminals 16 25: 24 VDC digital input connections.
- Terminals 26 27: shubber resistor braking control connections for older Snubber Resistor Braking Kits (for example, the M/N 2DB2010 series)
- · Terminals 28-31: status relay connections



Figure 2.7 - Typical Terminal St/tp Connections

2.4.3 RS-232 Communication Port

The Regulator board contains a 9-pin D-shell RS-282 communication port (J8). This port provides RS-282 communication between the GV3000/SE drive and a personal computer running the Control and Configuration (CS3000) software. See figure 2.4. Refer to instruction manual D2-9348, for more information about the CS3000 software.

2.4.4 Option Board Connector

The flat-ribbon cable connector (J3) on the left side of the Regulator board is a parallel bus connection port that provides a means of attaching optional boards such as the DeviceNet Option board, the RMI board, or the AutoMax Network Option board, or similar boards to the GV3000/SE drive. See figure 2.4. The option board is mounted below the Regulator board inside the drive. Refer to the appropriate board instruction for more information. Refer to section 2.5 of this manual for more information on optional drive kits.

2.4.5 Operator Interface Module Connector

The flat-ribbon connector J7 provides a means of attaching the optional Operator Interface Module (OIM). The OIM is available for use as a remote keypad for the GV3000/SE drive.

2.4.6 Keypad/Display

The front panel keypad/display is used to program and operate the GV3000/SE drive. See figure 2.8. Refer to the GV3000/SE Software Start-Up and Reference manual for more information.



Figure 2.8 - Keypad/Diapley

2.5 Jumpers on Base Board (PISC-40)

Jumpers JP1 through JP4 on the Base board (PISC-40) are used for selection of ourrent feedback gain as shown in table 2.2. On the Base board, there is another jumper, JP6, to be used for selection of ON/OFF level of precharge relay. Table 2.2 also shows the factory settings of these jumpers. For the locations of these jumpers, see figure 2.9.

Jumpers	Description	Factory Setting
JP1 (for U-phase) JP2 (for V-phase) JP3 (for ous current) JP4 (for ous current)	These jumpers are used for selection of current teedback gain as follows: A: for 30 to 50 HP units B: for 60 to 100 HP units	For 30 to 50 HP units: : A For 60 to 100 HP units: R
JPS	This jumper is used for selection of ON/OFF level of precharge relay as follows; A: ON at 175 V, OFF at 155 V 5: ON at 220 V, OFF at 200 V	Set In A position

Table 2.2 - Settings of Jumpers on Base Board



Figure 2.8 - Base Board Jumper Locations

2.6 Drive Kit Options

Table 2.3 provides a listing of the available GV3000/SE kit options.

Kit Description	Option Kit Model Number	Instruction Manual
Snubber Resistor Braking 🤋	2SR20450	
Motor Encoder Caole	2TC3025 * 2TC3075 * 21C4025 * 2TC4075 * 2TC4100 * 2TC4300 *	U2-3305
ControlNet Network Option Board	2CN3000	D2-3390
Interbus S Network Option Beard	2N63000	49'1333
AutoMax Network Option Board with 782 mm (30') of Cable	2AX3000	D2 3308
AutoMax RS-232 Adapter Cable	2CA300*	D2-3348
Super Remote Meter Interface (RMI)	2513000	D2-3341
DeviceNet Network Option Board	2UV3000	HE-HGV3DN
Operator Interface Module (OIM)	2BK3000	D2 3342
CS3000 Control and Contiguration Software	2CS3000	D2-3348
CS3000 RS-232 Computer Cable	2CA3000	D2-3348
115 VDC Interface Option Board	2L63000	D2 3376
PHOHBUS' * Interface Board	2PB3000	49.1355

Table 2.3 - Available Kits and Optional

O Consult the tectory for options dosired when not shown. Option kits are subject to change to feature or performance enhancements.

¹⁵¹ Up to two anubber kits can be connected to a drive in parallel.

24 These cobles are for use with Boliance NEMA Vector Inverter Duty Mators (encoder connector and exposed wire pairs).

39 These cables are for use with Bollence NEMA Vector Inverter Duty Mators (erassed wire pairs on both ends).

CHAPTER 3

Planning Before Installing

This chapter provides information that must be considered when planning a GV3000/SE drive installation. Installation site requirements, drive requirements, and wiring requirements are presented.



ATTENTION: Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should instail, adjust, operate, or service this equipment. Read and understand this manual and other applicable manuals in their entirety before proceeding. Failure to observe this precaution could result in severe bod ly injury or loss of life.

ATTENTION: When the level-sense start leature is enabled (P.654 = ON), the user must ensure that automatic start up of the driven equipment will not cause injury to operating personnel or damage to the driven equipment. In addition, the user is responsible for providing suitable audible or visual alarms or other devices to indicate that this function is enabled and the drive may start at any moment. Refer to the GV3000/SE Software Start-Up and Reference manual for additional information. Failure to observe this precaution could result in severe bodily injury or loss of life.

ATTENTION: Use of power correction capacitors on the output of the drive can result in erratic operation of the motor, nu sance tripping, and/or permanent damage to the drive. Remove power correction capacitors before proceeding. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

ATTENTION: The user is responsible for conforming with all applicable ocal, national, and international codes. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

3.1 Requirements for the Installation Site

It is important to properly plan before installing a GV3000/SE drive to ensure that the drive's environment and operating conditions are satisfactory. Note that no devices are to be mounted behind the drive. This area must be kept clear of all control and power wiring. Read the following recommendations before continuing with drive installation.

3.1.1 Making Sure Environmental Conditions are Met

Before deciding on an installation site, consider the following guidelines:

- · Verily that drives can be kept clean, cool, and dry.
- The area chosen should allow the space required for proper air flow as defined in section 3.1.3.

- Be sure that drives are away from bil, coolants, or other airborne contaminants.
- Do not install the drive above 1000 meters (3300 feet) without derating output power. For every 91.4 meters (300 feet) above 1000 meters (3300 feet), derate the output current 1%.
- Verify that the drive location will meet the environmental conditions specified in table 3.1.

Condition	Specification
Operating Temperature (Ambient)	0° to 55°C (32° to 131°F)
Storage Temperature (Ambient)	-40° to +85°C (-40° to +149°F)
Humidity	5 to 95% (non-condensing)

Table 3.1	- Ambient Conditions	
100-0.1	. IT biene donaldo le	

3.1.2 Determining Total Area Required Based on Drive Dimensions

Drive dimensions and weights are listed in table 3.2. Overall drive dimensions are illustrated in figure 3.1 as an aid in calculating the total area required by the GV3000/SE drives.

GV3000/SE Drive 30V2060 50V2060	Dim. H1 544 mm 21.4"	Dim. H2 564 mm 22.2 '	Dim. H3 504 cim 19.81	Dim. H4 606 mm 23.91	Dim. W 235 mm 9.0*	Dim. D 954 mm 13.81	Weight 34 kg 75 lbs
60V2080	714 mm	734 mm	874 mm	776 mm	245 mm	366 mm	44 kg
100V2060	25.1°	28.9 '	26.51	30.6 '	8.6"	14.4 '	87 Ibs

Table 3.2 - Drive Dimensions and Weights

GV3000/SE Drive	Dim. A1	Dim. A2	Dim. A3	Dim. A4	Dim. B1	Dim. 82	Dim. C1	Dim. C2	Dim. C3	Dia. d
30V2060	10 mm	30 mir	10 mm	30 mm	51 mm	5" mm	* 00 mir	100 mm	9 mm	9 mm
50V2060	0.41	1.2'	0.4'	1.21	2.0'	2.0'	3.9*	3.9*	0.351	0.351
60V2080	10 mm	30 mm	10 mm	30 mm	51 mm	5° mm	200 mm	200 mm	9 mm	9 mm
100V2060	0.41	1.2'	0.1'	1.2'	2.0'	2.0'	7.9*	7.9*	0.35 '	0.351



Figure 3.1 - Drive Dimensions

3.1.3 Verifying the Site Provides for Recommended Air Flow Clearances

Be sure there is adequate clearance for air ventilation around the drive. For best air movement, do not mount GV3000/SE drives directly above each other. Note that no devices are to be mounted behind the drive. This area must be kept clear of all control and power wiring. Refer to figure 3.2 for recommended air flow clearances.



Figure 3.2 - Recommended Air Flow Clearences

When installing a GV3000/SE drive, prepare an opening for its ventilating duct at the top of the cabinet and, if necessary, provide an extension of the duct to connect between the opening and the duct.

3.1.4 Verifying Power Module AC Input Ratings Match Supplied Power

It is important to verify that plant power will meet the input power requirements of the GV3000/SE drive's Power Module circuitry. Refer to table 2.1 for input power rating specifications. Be sure input power to the drive corresponds to the drive namep ate voltage and frequency.

3.2 Wiring Requirements for the Drive

Certain drive requirements should be checked before continuing with the drive installation. Wire sizes, branch circuit protection, speed feedback (for FVC regulation), and E stop wiring (see chapter 7), are all areas that need to be evaluated.

3.2.1 Meeting Terminal Strip Input and Output Specifications

The terminal strip on the Regulator board provides terminals for 24 VDC power for the eight remote control inputs. Refer to tables A.3 and A.4 for control input and output specifications.

3.2.2 Determining Wire Size Requirements

Wire size should be determined based on applicable local, national, and international codes (e.g., NEC/CEC regulations).



ATTENTION: The user is responsible for conforming with all applicable local, national, and international codes. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

3.2.2.1 Recommended Power Wire Sizes

Input power wiring should be sized according to applicable codes to handle the drive's continuous rated input current. Output wiring should be sized according to applicable codes to handle the drive's continuous rated output current. See tables 3.3 and 3.4 for recommended power wire sizes.

Important: Use only copper (Cu) wire with a temperature rating of 60/75°C.

Type of Wiring	Terminals	Size of Wire (Maximum)	
AC Input Power	HAL1, SAL2, 1/L3		
Output Power	U/T1, V/T2, W/T3	3/0 AWC (or 85 mm²)	
DG Input Power	P. N		

Table 3.3 - Recommended Power Wire Sizes for 30 to 50 HP Drives

Type of Wiring	Terminals	Size of Wire (Maximum)
AC Input Power	R/L1, S/L2, T/L3	
Output Power	U/T1, V/T2, W/T3	500 Kamil (or 250 mm²)
DC Input Power	P.N	

Table S.4. - Recommended Power Wire Sizes for 60 to 100 HP HP Drives

3.2.2.2 Recommended Control and Signal Wire Sizes

The recommended wire size to connect I/O signals to the terminal strip on the Regulator board are shown in table 3.5. Recommended terminal tightening torque is 0.5 Newton-meters (4.5 in-b). Operator controls can be up to 303 meters (1000 feet) from the GV3000/SE drive.

Table 2.5 -	Recommended	Term nsl	St ip Wire	Sizea
-------------	-------------	----------	------------	-------

Terminals	Wire Size
1 to 31	20 to 14 AWG, 0.5 to 2 (mm ²)

3.2.2.3 Recommended Motor Lead Lengths

The following motor lead lengths are recommended to reduce line disturbances and noise. See I gure 3.3.

- For applications using one motor, motor lead length should not exceed 76 meters (250 feet). Note that drives using vector regulation can only be connected to one motor at a time.
- For applications with multiple motors, total motor lead length should not exceed 76 meters (250 feet).

When total lead length exceeds 76 meters (250 feet), nuisance trips can occur, caused by capacitive current flow to ground. Note that these capacitively-coupled currents should be taken into consideration when working in areas where drives are running. If the motor lead length must exceed these limits, the addition of output line reactors or other steps must be taken to correct the problem. See tables 3.6 and 3.7. Note that the motor lead lengths shown in table 3.6 are only guidelines. Your application may be restricted to shorter lead length due to:

- the type of wire.
- The placement of wire (for example, in conduit or a cable tray).
- the type of time reactor.
- the type of motor.



Figure 3.3 - How to Measure Motor Lead Lengths

âvsoovse		Maximum Leed Length in Feet with 230 VAC Motor Carrier Frequency			
HP Rating	Filter Type	2 kHZ	4 kHZ	8 kHZ	
30		600	500	500	
40		800	500	500	
50	Nona	800	500	500	
60	020000	600	500	500	
75		800	500	500	
- 00		800	500-	500	
30		1000	1000	1000	
40	A AW MITE	1000	1000	1000	
50	reactor/filter	1000	1000	1000	
60	at the drive.	1000	1000	1000	
75	and the second se	1000	1000	1000	
- 00		1000	1000	1000	

Lable S.6 – Motor Lead Latigths

Note that the load, engine listed are valid with Beliance Electric inverter duty motors.

GV3000/SE HP Rating	240 Volt 5% MTE Reactor	GV3000/SE HP Rating	240 Volt 5% Reactor
30	RL-08002	60	RL-16002
40	RL-10002	75	RI -20002
- 60	RL-13002	100	RL-25002

able 3.7 - Peectors

These part numbers are for a reactor with a cacitor filter.

MTE standard reactors can be used on GVX000/SE drives with carrier frequency settings up to 8 kHZ. All reactors are UL-recognized (UL-506 File (/E53091) and CSA certified (CSA File //LF29752).

3.2.2.4 Recommended Serial Communication Cable Lengths

Connector J8 on the Regulator boards is an RS-232 serial communication port. This connector allows the GV3000/SE drive to communicate with external devices such as a personal computer using RS-232 protocol. See table A.5. Two RS-232 cables are available from Reliance: a 3 meter (10 feet) D-shell 9-pin to 9-pin cable (M/N 2CA3000) and a 0.5 meter (1 foot) D-shell 9-pin to 25-pin adapter cable (M/N 2CA3001). User-constructed cables can be up to 15 meters (50 feet) in length. Note that for communication between a GV3000/SE drive and a personal computer, the Control and Configuration software must allobe used. Refer to instruction manual D2-9348 for more information.

The Regulator boards have one set of RS-232 transmit/receive lines. These lines can be accessed by only <u>one</u> device at a time: connector J8, the RS-232 terminals (1-3) on the terminal strip, or an Operator Interface Module (OIM).

3.2.3 Selecting AC Input Line Branch Circuit Fuses, Circuit Breakers, and AC Reactors



ATTENTION: Most codes require that upstream branch circuit protection be provided to protect input power wiring. Install the fuses recommended in table 3.8. Do not exceed the fuse ratings. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

Input line branch circuit protection fuses must be used to protect the input power lines. See figures 5.1 and 5.2. Recommended fuse values are shown in table 3.8. The input fuse ratings listed in table 3.8 are applicable for one drive per branch circuit. No other load may be applied to that fused circuit.

Model Number	Horsepower Rating	Input AC Fuse Rating ¹ 2
3DV206C	30 H P	200 A
40V206C	401 P	250 A
50V2060	50 HP	300 A
\$0V2060	EC HP	350 A
75V2060	76 HP	450 A
100V2060	100 HP	500 A

Table 3.8 AC Input Line Euse Selection Values.

3 Recommended luse type UL Classic, 600V. The overlap or equivalent.
AC reactor must be installed in the AC input line. Tables 3.9 and 3.19 show select on values for the circuit breakers and AC reactors respectively.

Model Number	Horsepower Rating	Circuit Breaker Rating
3CV2050	30 HP	150 A
40V2090	40 HP	200 A
50V2080	50 HP	250 A
6CV2080	60 HP	300 A
75V2080	75 HP	350 A
100V2050	100 HP	400 A

Table 3.9 - Circuit Breaker Selection Values

Table 3.10 - AC Resolar Selection Values

Model Number	Horsepower Rating	AC Reactor
3075080	30 HP	LS3-125/3-1 (125 A/84 mH)
40V2060	40 HP	LS3-160/3-1 (160 A/66 mH)
50V2090	50 HP	LS3-160/3-1 (160 A/66 mH)
60V2060	80 HP	LS3-200/3-1 (200 A/54 mH)
75V2060	75 HP	LS3-250/3-1 (250 A/42 mH)
100V2080	100 HP	I \$3-300/3-1 (300 A/36 mH)

3.2.4 Meeting Encoder Specifications (FVC Regulation Only)

GV3000/SE drives set up for FVC regulation require an encoder for closed loop operation. Encoder specifications are provided in table A.6. Drives set up for V/Hz or SVC regulation do not require an encoder for leedback because they operate in open loop mode.

3.2.4.1 Encoder Wiring Guidelines

Encoder connections are considered signal level wiring and, therefore, must be run separate from control and power wiring. Reliance Electric recommends 18 AWG unshielded twisted pair wires with 2 3 twists per inch for applications to a maximum distance of 303 meters (1000 feet). The recommended Reliance Electric part number is 417900 207CG. 18 AWG, 6 conductor (3 twisted pairs).

3.2.5 Verifying Power Module Output Current Rating is Greater Than Motor Full Load Amps

Verily that the GV3000/SE output current rating is greater than the motor's full load current (amps). Table 2.1 lists the output current values.

Mounting the Drive, Grounding, and Finding Wire Routing Locations

This chapter shows how to mount the drive and properly ground it.

4.1 Mounting the Drive

Attach the drive to the vertical surface selected using the four (4) mounting holes provided. In order to maintain a flat mounting surface and to ensure that bolt tightness is maintained, use washers under the bolt heads. Refer to figure 3.1 and table 3.2 for drive mounting dimensions. Use the following user-supplied mounting bolts and washers:

- 30 to 50 HP drives: M8 (5/18*)
- 60 to 100 HP drives: M8 (5/16⁴).

4.1.1 Verifying the Drive's Watts Loss Rating

When mounting the drive inside of another enclosure, you should determ no the watts loss rating of the drive shown in table 2.1. This table lists the typical full load power loss watts value under all operating carrier frequencies. Ensure adecuate ventilation is provided based on the drive's watts loss rating.

4.2 Routing Input, Motor Output, Ground, and Control Wiring for the Drive

All wiring should be installed in conformance with the applicable loca, national, and international codes (e.g., NEC/CEC). Signal wiring, control wiring, and power wiring must be routed in separate conduits to prevent interference with drive operation. Note that no wires are to be routed help nd the drive. Figure 4.1 shows the locations of the power terminals and the grounding terminals of the GV3000/SE drives.



ATTENTION: Do not route signal and control wiring with power wiring in the same conduit. This can cause interference with drive operation. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

Do not route more than three sets of motor leads through a single conduit. This will minimize cross-talk that could reduce the effectiveness of noise reduction methods. If more than three drive/motor connections per conduit are required, shielded cable must be used. If possible, each conduit should contain only one set of motor leads.



ATTENTION: Unused wires in conduit must be grounded at both ends to avoid a possible shock hazard caused by induced voltages. Also, if a drive sharing a conduit is being serviced or installed, all drives using this conduit should be disabled to eliminate the possible shock hazard from cross-coupled motor leads. Failure to observe these precautions could result in bodily injury.

4.3 Grounding the Drive



ATTENTION: The user is responsible for conforming with all applicable local, national, and international codes. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

Use the following steps to ground the drive:

- Step 1. Remove the drive's cover.
- Step 2. Run a suitable equipment grounding conductor unbroken from the drive's ground terminal to the motor's ground terminal and then to earth ground. See Egures 4.1, 5.1 and 5.2.
- Step 3. Connect a suitable grounding conductor to the motor frame, the remote control station (if used), and the transformer. Run each conductor unbroken to earth ground.

When adding more than one grounding conductor wire to a single chassis ground, twist the conductors together.

Step 4. Real.ach the drive's cover.



Figure 4.1 - Terminal Locations

Installing Input Power Wiring

This chapter describes incoming line components and how to install them.

5.1 Installing Transformers and Reactors (Optional)

Input iso ation transformers might be needed to help eliminate the following:

- · Damaging I ne voltage transients from reaching the drive.
- Line no se from the drive back to the incoming power source.
- Damaging currents that could develop if a point inside the drive becomes grounded.

Observe the following guidelines when installing an isolation transformer:

- A power disconnecting device must be installed between the power line and the primary of the transformer.
- If the power disconnecting device is a circuit breaker, the circuit breaker trip rating must be coordinated with the inrush current (10 to 12 times full load current) of the transformer.
- An additional impedance is required between the drive and the transformer. An appropriate three-phase AC line reactor should be used as shown in table 5.1.



ATTENTION: Distribution system capacity above the maximum recommended system KVA (500 KVA for 230 VAC) requires the use of an isolation transformer, a line reactor, or other means of adding similar impedance to the drive power input. Failure to observe these precautions could result in damage to, or destruction of, the equipment.

ATTENTION: When the AC line is shared directly with other SCRrectified drives, an optional shubber resistor braking kit might be recuired to alleviate excess DC bus voltage. Failure to observe these precautions could result in damage to or destruction of the equipment.

The GV3000/SE AC line distribution system capacity is 500 KVA, three-phase with 30,000 amps symmetrical fault current capacity with a line impedance of less than 5%. The symmetrical fault current may be increased to 85,000 amps if the appropriate three-phase AC line reactor is used as shown in table 5.1.

GV3000/SE Drive	Line Reactor Inductance (+/-10%)
301 P	64 µH
40 H P	66 µ⊢
30 HP	66 µ⊢
60 H P	54 µH
751 P	42 µH
100 H P	

Table 5.1 - AG line Reactors

5.2 Installing Fuses for Branch Circuit Protection

Install the required, user-supplied branch circuit protection fuses according to the applicable local, national, and international codes (e.g., NEC/CEC). The fuses must be installed in the line before the drive input terminals. See figures 5.1 and 5.2. Fuse value selections are provided in table 3.6.



ATTENTION: Most codes require that upstream branch protection be provided to protect input power wiring. Failure to observe this precaution could result in severe bodily injury or loss of life.

5.3 Installing a Required External/Separate Input Disconnect

An input disconnect must be installed in the line before the drive input terminals in accordance with local, national, and international ondes (e.g., NEC/CEC). The disconnect should be sized according to the in-rush current as well as any additional loads the disconnect might supply. The trip rating for the inrush current (10-12 times full load current) should be coordinated with that of the input isolation transformer, if used. Refer to section 5.1 for additional information.



Figure 5.1 - Typical AC Input Electrical Connections



Figure 5.2 - Typical DC Bus Electrical Connections

5.4 Installing Power Wiring from the AC Input Line to the Drive's Power Terminals

Use the following steps to connect AC input power to the drive:

Step 1. Wire the AC input power leads. Tables 3.3 and 3.4 contain the recommended power wiring sizes.



ATTENTION: Do not route signal and control wiring in the same conduit with power wiring. This can cause interference with drive operation. Failure to observe this precaution could result in damage to, or destruct on of, the equipment.

- Step 2. Connect the three-phase AC input power leads (three-wire 200-230 VAC) to terminals R/L1, S/L2, T/L3. Refer to figure 4.1 for the locations of the terminal.
- Step 3. Tighten the AC input power terminels to 9.8-11.7 Newton-meters (87-104 lb-in) for 30-100 HP drives.

5.5 Installing Power Wiring from an External DC Bus to the Drive's Internal DC Bus Terminals

Use the following steps to connect DC input power to the drive:

Step 1. Wire the DC input power leads. Tables 3.3 and 3.4 contain the recommended power wiring sizes.



ATTENTION: Do not route signal and control wiring in the same conduit with power wiring. This can cause interference with drive operation. Failure to observe this precaution could result in damage to, or destruct on of, the equipment.

ATTENTION: If the GV3000/SE drive is connected to an external DC bus, the user is responsible for DC bus short-circuit protection. Failure to observe this precaution could result in damage to, or destruction of, the ecuipment.

Step 2. Connect the DC input power leads (two-wire 310 VDC nominal) to terminals + and -. See figure 4.1 for the locations of the terminals.

> Note that the maximum discharge rate of the DC bus supply should be 200. V/second.

Step 3. Tighten the DC input power terminals to 9.8-11.7 Newton-metars (87-104 lb-in) for 30-100 HP drives.

Installing Output Power Wiring

This chapter provides instructions on wiring output contactors, motor overload protection, and output wiring to the motor.

6.1 Installing Output Contactors (Optional)

Output contactors provide a positive means of disconnecting the motor from the drive. If the application requires the use of output contactors, contact Reliance Electric for assistance.

6.2 Installing Mechanical Motor Overload Protection (Optional)

To provide the motor with overload protection, local, hat onal, and international codes (e.g., NEC/CEC) require one of the following:

- A motor thermostat be installed internal to the motor.
- An electronic thermal motor overload relay, sized to protect the motor, he installed between the motor and the drive's output terminals.

Note, however, that temperature measuring devices integral to the motor are the best way to thermally protect AC motors under all conditions. Parameter R040 must be enabled to provide overload protection. Refer to the GV3000/SE Software Start-Up and Reference manual for more information.

In multiple-motor applications (V/Hz regulation only), each motor must have its own user-supplied overload protection.

6.3 Installing Output Wiring from the Drive Output Terminals to the Motor

Use the following steps to connect the AC output power wiring from the drive to the motor:

Step 1. Wire the three-phase AC output power motor leads. Tables 3.3 and 3.4 contain the recommended power wiring sizes.

Do not route more than three sets of motor leads through a single conduit. This will minimize cross-talk that could reduce the effectiveness of noise reduction methods. If more than three drive/motor connections per conduit are required, shielded cable must be used. If possible, each conduit should contain only one set of motor leads.



ATTENTION: Do not route signal and control wiring with power wiring in the same conduit. This can cause interference with drive operation. Failure to observe this precaution could result in damage to, or destruction of, the equipment.

ATTENTION: Unused wires in conduit must be grounded at both ends to avoid a possible shock hazard caused by induced voltages. Also, if a drive sharing a conduit is being serviced or installed, all drives using this conduit should be disabled to e iminate the possible shock hazard from cross-coupled motor leads. Failure to observe these precautions could result in bodily injury.

- Step 2. Connect the three-phase AC output power motor leads to terminals U/T1, V/T2, W/T3. See Figure 4.1 for the locations of the terminals.
- Step 3. Tighten the three-phase AC output power terminals to 9.8-11.9 Newton-meters (87-104 lb-in) for 30-100 HP drives.

Wiring the Regulator Board Terminal Strip

This chapter describes how to wire the Regulator board term nal strip for stop, encoder feedback, and remote control signals.

The signals available through the terminal strip are shown in tables 7.1 to 7.7 and figures 7.1 and 7.2. Table 7.8 provides additional information.

Note that when the Control Source parameter (P.000) is set to remote (rE), the drive will be controlled by the signals connected to the terminal strip. Refer to the GV3000/SE Software Start-Up and Reference manual for more information on how parameter P.000 is used to specify where the drive is controlled from.

Terminal #	Signal	
1	Transmit (Tx)	
2	Receive (Fx)	
Э	Regulator Common	
Notes: The (J8) or an C the same th	RS-202 terminals should only be used when the RS-202 communication per perstor interface Module (OLM) are not being used, as all three devices use anamit/receive lines.	

Table 7.	1 - 85-232	Connections	(Terminals	1-51
----------	------------	-------------	------------	------

Table 7.2 - E	incoder:	Connectiona	(Terminals 1-9)
---------------	----------	-------------	-----------------

Şignal
+15 VDC
Phase A
Phase A Not
Phase B
Phase B Net
Regulator Common

Table 7.3 - Analog Cutput Connections (Terminals 10 and 11)

Terminal #	Signal
-0	Analog Meter Output
-1	Regulator Common
Notes: The setting of ju programme torque.	e outout of this terminal is either 0-10 VDC or 4-20 mA as determined by the imper J17 on the Regulator board. The analog output must also be divia parameter P.012 for an indication of speed and direction or percent of

Table 7.4 - Analog Speed/Torque Reference Connections (Terminals 12-15)

Signal	
laciated Reference Voltage	
VDC Speed/Torque Reference	
mA Speed/Torque Reference	
Iselated Reference Cemmer	

-/-20 mA, as determined by the setting of jumper J4 on the Regulator board. The analog reference can be adjusted using parameters P.009, P.010, and P.011.

Table 7.5 - Digital Input Connections (Terminals 18-25)

Terminal #	Signal
16	24 VDC (Current Limited) (For remote control digital inputs only)
17	Digital Input 8 (Nemote/Local) - Programmable
15	Digital Input 7 (Ramp 1/Ramp 2) - Programmable
19	Digital Input 6 (Forward/Roverse) - Programmable
20	Function Loss
21	Rur/Jog
22	Heset
23	Stop
24	Start
25	-24 VDC Common

Notes: When a user installed function less input, a ceast to stop pushbutton, or another external interlock is installed, the factory-installed jumper connecting terminals 16 and 20 must be removed so that a contact, when open, will stop the drive.

Terminals 17, 18, and 19 (remote control inputs 8, 7, and 6) are programmed using parameters P.007, P.009, and P.031 through P.038. Factory default settings are shown here in parentheses. Refer to the GV3000/SE Software Start-Up and Peterence manual for more information.

Terminal #	Signal
26	Snubber Resistor Braking Signal
27	-24 VDC Common
Notes: Thes gate turn on	e terminals are used with older Snubber Resistor Braking kits that require a signal from the drive (for example, the M/N 2DB2010 series).

Table 7.7 Status Belay Connections (Terminals 28-31)

Terminal #	Signal	
28	N.C. Relay Contact	
28	N.C. Rolay Common	
30	N.O. Relay Contact	
31	N.O. Relay Common	

Notes: Relay contact closure is programmable thready parameter P.013. Refer to the GV3000/SE Software Start-Up and Reference manual for more information.



Hgum 7.1 - Two With Start/Stop Sample Control Withs





7.1 Stopping the Drive

ATTENTION: The user must provide an external, hardwired emergency stop circuit outside of the drive circuitry. This circuit must disable the system in case of improper operation. Uncontrolled machine operation may result if this procedure is not followed. Failure to observe this precaution could result in bodily injury.
 ATTENTION: When P.055 is set to ON, the STOP/RESET key is functional only from the selected control source. As a safety precaution, Reliance Electric recommends that an emergency stop push button be located near the drive in an easily accessible location. As a further safety precaution, you should post a warning on the drive to alert personnel that the STOP/RESET key is not functional. Failure to observe this precaution could result in severe bodily injury or loss of life.

Depending upon the requirements of the application, the GV2000/SE drive can be programmed to provide either a coast-to-rest or a ramp-to-rest operational stop without physical separation of the power source from the motor. A coast-to-rest stop turns of the transistor power device drivers. A ramp-to-rest stop fires the transistor power device drivers until the motor comes to a stop, and then turns off the power devices. The user can also program zero speed with power maintained to the motor, but in this condition, the drive is not actually stopped. See the description of terminal 23 and 24 or Stop Type (P.025) for more information on how to program the operational stop.

In addition to the operational stop, the user must provide a hardwired emergency stop external to the drive. The emergency stop circuit must contain only hardwired electromechanical components. Operation of the emergency stop must not depend on electronic logic (hardware or software) or on the communication of commands over an electronic network or link.

Parameter P.055 (STOP/RESET Key D sable) can be used to change the operation of the STOP/RESET key. See the parameter P.055 description in the software manual for more information.

Note that the user-installed hardwired emergency stop may be used at any time to stop the drive.

7.2 Wiring the Encoder Feedback Device (FVC Regulation Only)

If the GV3000/SE drive is programmed to provide FVC regulation, an encoder must be installed. Drives using V/Hz or SVC regulation do not require the use of an encoder feedback device. The encoder connects to terminals 4 to 9 of the regulator's terminal strip:

- Terminal 4: Encoder Supply +15 VDC (250 mA capacity)
- Terminal 5: Encoder Phase A Differential Input.
- Terminal 6: Encoder Phase A Not Differential Input.

- Terminal 7: Encoder Phase B Differential Input
- Terminal 8: Encoder Phase B Not Differential Input
- Terminal 9: Encoder/Regulator Common

Use the following procedure to connect an encoder to the regulator's terminal strip:

- Step 1. Connect the encoder's wires to terminals 4 through 9 of the terminal strip. See figure 7.9. See table A.6 for additional encoder specifications. Refer to section 9.2.4.1 for encoder wiring guidelines.
- Step 2. Set the following parameters to establish the maximum motor speed:
 - P.004: Maximum Speed
 - U.CO1: Encoder PPR
 - U.CO2: Motor Poles
 - U.003: Motor Nameplate Base Frequency
 - U.005: Motor Nameplate BPM
 - U.017: Motor Top Speed

Refer to the GV3000/SE Software Start-Up and Reference manual for more information.



Figure 7.2 - Encoder Willing Connections

7.3 Wiring the Signal and Control I/O

Wire the drive's signal and control I/O to the terminal strip as shown in table 7.8.

Terminal Number	Description	Parameters/Wiring Connections
	٧	Viring RS-232 Signals
1	RS 232 Transmit	Note that RS-232 communication between the GV30000/SE drive and a personal computer requires the use of the Control and
2	HS-232 Receive	Configuration software. Refer to instruction manual D2-3348 for more information.
э	RS-232 Signal/Regulator Common	These ferminals should only be used when the RS-232 pert (J5) or an Operator Interface Module (OIM) are not being used, as all three devices use the same transmit/receive lines.
		TERMINAL STRIF PER SOCIAL CONFIDIENT 1 CSTIN D-STILL VALUE -0 I- STIN D-STILL, PLUG 1 I 1 C 1 C 0 C
		TRUE LENGTH TISO FEET [K4X]
Wiring Encoder Inputs		
4-9	Encoder Wiring	See section 7.2.

lable 7.8 - W the	Signal and	Control I/O to the	leminal Strp
	Access to the second	Contraction 14 (20 10 10 10 10 10 10 10 10 10 10 10 10 10	the state of the property of t

Terminal Number	Description	Parameters/Wiring Connections
		Wiring Analog Outputs
10	0-10 VDC or 4-20 mA Analog Output Reference	The setting of parameter P.012 selects the terminal strip analog output source (either speed or torque). Jumper J17 must also b set. See figure 2.6.
11 Regulator Common	The 4-20 mA current selection requires a power supply for operation. The power can be sourced from the encoder supply, terminal 4 (15 VBC), or from an external 15 V power supply. Note that the maximum supply current from terminal 4 is 250 mA (encoder and current source) at 15 V. Terminals 9 and 11 are internally connected.	
		Terriral S.1p
		Ø 1
		(Motor or Analog Input)
		· 📃 Ø 5
		Ø ₀-
		Connection to the negative side of the power supply is only recuired when an external 15 V power supply is used

Table 7.8 - Wiring Signal and Centrel (-C to the Terminel Strip (Corribued)

Terminal Number	Description	Perameters/Wiring Connections
	Wiring	Analog Speed Reference Inputs
12	Isolated Reference Vollage (-19 VDC)	Helated parameters:
13	Analog Speed/Torque Reference Input Voltage (-/- 10 VDC)	P.000: Control Strip Analog Input Offset P.010: Terminal Strip Analog Input Gain P.011: Terminal Strip Analog Input Configure
14	Analog Speed/Torque Reference Input Current (0.20 mA)	Refer to the GV3000/SE Software Start-Up and Reference manual for additional parameter information. Jumper J4 must also be set. See tigure 2.6.
15	Isolated Speed/Forque Reference Common (Voltage/Current)	+10 V 0 V

Table 7.8 - W fing Signal and Control PO to the Terminal Strip (Continued)

Terminal Number	Description	Parameters/Wiring Connections
		Wiring a Remote/Local Input
16	+24 VDC Power Supply	Current I mited for remote input logic use only.
17	Digital Input 8 (Default - Remoto/Lecal)	Digital input 9 is control function programmable through parameter P.007.
⚠	ATTENTION: If a maintained remote from the terminal strip plosed. Stay plear of rotating observe this precaution could	start contact is used when the control source — rF, switching from local to will cause power to be soplied to the motor if the remote start contact is machinery in this case. Failure to result in bod y injury.
		 The following parameters must be set: P.000: Control Source (Only active when P.000 = rE) P.006: Second Vienu Password P.007: Terminal Strip Digital Inputs Configure (Sclocks and assigned a control function to digital Inputs 6 to 8). P.008: Terminal Strip Speed Reference Source (Analog, Motor Operated Potentiometer (MOP), or Preset Speeds) Note that based on the settings of parameters P.000, P.007, P.008 and r.050 if an RMI board is used, the following parameters can alfect digital input 8. P.023: MOP Acce/Dece Time P.024: MOP Reset Configuration P.031 to P.038: Preset Speeds 1-8 Refer to the GV3000/SE Software Start Up and Reference manual for additional information.
		LOCAL Terminal 17 On = Local Control

Table 7.8 - Wiring Signal and Control VC to the Terminal Strip (Continued:

Terminal Number	Description	Parameters/Wiring Connections
	Wir	ing an Additional Ramp Input
18	Wir Digital Input 7 (Default - Ramo 1/Pamp 2)	ing an Additional Ramp Input Dig tal input 7 is control function programmable through parameter P.007. The following parameters must be set: P.000: Control Source P.001: Accel Lime 1 (Hamp 1) P.002: Decel Time 1 (Ramp 1) P.002: Second Menu Paseword P.007: Terminal Strip Dig tal Inputs Configure (Selects and assigns a control function in digital inputs 6 to 8). P.008: Terminal Strip Speed Reference Source (Analog, Motor Operated Potentiometer (MOP), or Preset Sobeds) P.017: Accel Time 2 (Ramp 2) P.018: Docel Time 2 (Ramp 2) P.018: Docel Time 2 (Ramp 2) P.018: Docel Time 2 (Ramp 2) Note that based on the settings of parameters P.000, P.007, P.008, and r.020 if an RMI board is used, the following parameters can affect digital input 7. P.023: MOP Acce/Dece Time P.031 to P.038: Preset Speeds 1-3 Refer to the GV30000/SE Software Start-Up and Reference manual tor additional Information.
		eminal 18 Or = Pamp 2 Diagram shows factory setting.

Table 7.8 - Widney Signal and Control I/O to the Terminal Strip (Continued)

Table 7.8 - Winng Signal and Control VC to the Terminal Stri	trip (Continued)
--	------------------

Description	Parameters/Wiring Connections
Wir	ing a Forward/Reverse input
Wir Ig tal Input 6 Dolault Forward/Reverse)	 Ing a Forward/Reverse Input Dig fall input 6 is control function programmable through parameters must be set: P.000: Control Source: P.000: Second Menu Password P.007: Terminal Strip Dig fall inputs Configure (Selects and assigns a control function to digital inputs 6 to 8). P.008: Terminal Strip Dig tall inputs Configure (Selects and assigns a control function to digital inputs 6 to 8). P.008: Terminal Strip Dig tall inputs Configure (Selects and assigns a control function to digital inputs 6 to 8). P.008: Terminal Strip Dig tall inputs Configure (Selects and assigns a control function to digital inputs 6 to 8). P.008: Terminal Strip Dig tall inputs Configure (MOP), or Presel Speeds) P.027: Forward/Reverse Configuration Note that based on the settings of parameters P.000, P.007, P.008, and t.030 if an PMI heard is used, the following parameters can affect digital mout 8. P.023: MOP Accel/Decel Time P.031 to P.032: Preset Specifies 1-5 Refer to the GV3000/SE Software Start-Up and Reference manual for additional information. If FR:27 = 1 / REV IFF:27 = 1
	Description Win lig tal Input 6 Default Forward/Reverse)

Digita Input 5	Wiring a Function Loss Input
Digita Input S	ENVERTIES AND
(Function Loss)	The following parameters must be set: P.026: Function Loss Hesponse A signal must be present at terminal 20 for the drive to be able to start. See Figures 7.1 and 7.2. The drive is shipped from the factory with a jumper between terminals 16 and 20 which provides the signal. The functor loss input should be in series with the drive's external interlocks. In this case, the jumper must be removed before the connector's are made. See Figure 2.7. TERMINAL STRIP 16 17 18 19 20 21 16 17 18 19 20 21 17 18 19 20 21 18 17 18 19 20 18 18 17 18 19 18 18 17 18 18 20 21 18 17 18 18 18 18 18 18 18 18 18 18 18 18
	Wiring a Run/Jog Input
Digita Input 4 (Run/Jug)	The following parameters must be set: P.000: Centrol Source P.020: Jog Speed Peterence P.021: Jog Ramp Accel Time P.022: Jog Ramp Decel Time 18
	Digita Inout 4 (Run/Jug)

Table 7.8 - Willing Signal and Control I/O to the Terminal Strip (Continued)

Terminal Number	Description	Parameters/Wiring Connections		
Wiring the Reset Input				
22	Digital Input 3 (Reset)	The following parameter must be set: P.000: Control Source		
	Wiri	ng the Stop/Start Inputs		
23 24 25	Digital Input 2 (Step) Digital Input 1 (Start) 24 VDC Isolated Common	The following parameters must be set: P.000: Centrol Source P.025: Stop Type		
Wiring the Snubber Resistor				
26 27	Snubber Hesistor Braking Control Signal +24 VDC Isolated Common	Used with older Snubber Pealstor Braking Kits that require a gate turn-on signal from the drive (for example, the M/N 2DB2010 series).		
		Note that terminals 26 and 27 are not to be used with Snubber Resistor Braking Kits M/N 2SR20400, 2SR20400, 2SR21200, 2SR21800, 2SR20300, and 2SR20450.		

Table 7.8 – Wiring Signal and Control $\ensuremath{\backslash} G$ to the Terminal Strip (Continued)

Terminal Number	Description	Parameters/Wiring Connections
	0.9	ining the output status helays
25	Normally-Closed Contact (Form B)	Both Form A and Form B contacts are rated for 250 VAC/30 VDC at 5 amps resistive or 2 amps inductive load.
29	Normally-Closed Contact Common (Form B)	he following parameter must be set:
		P.013: Output Relay Configuration
30	No mally Open Contact	
	(I cm A)	Note that depending on the solting of parameter P.013, the
31 	Normally-Open Contact Common (Form A)	relay coll will energize (the hormally-open contact will close and the normally-closed contact will open). Refer to the CV3000/SE Software Start-Up and Reference manual for more information.
		PARAVETER POIS SELECTS OUTPUT

Table 7.8 – Withig Signal and Control (O to the Torminal Stdp (Cardinued)

Completing the Installation

This chapter provides instructions on how to perform a final check of the installation before power is applied to the drive.



ATTENTION: Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should start and adjust it. Read and understand this manual in its entirety before proceeding. Failure to observe this precaution could result in severe bodily injury or loss of life.

8.1 Checking the Installation

Use the following procedure to verify the condition of the installation:



ATTENTION: DC bus capacitors retain hazardous voltages after input power has been disconnected. After disconnecting input power, wait five (5) minutes for the DC bus capacitors to discharge and then check the voltage with a voltmeter to ensure the DC bus capacitors are discharged before touching any internal components. Failure to observe this precaution could result in severe bodily injury or loss of life.

Step 1. Turn off, lock out, and tag the input power to the drive. Wait five minutes.

- Step 2. Verify that the DC bus voltage is zero. Refer to section 9.3.
- Step 3. If a function loss coast-stop push-button has been installed, verify that it has been wired correctly. Be sure the factory-installed jumper at terminals 16 and 20 has been removed so that the coast-stop push-button will work.



ATTENTION: The user must provide an external, hardwired emergency stop circuit outside of the drive circuitry. This circuit must disable the system in case of improper operation. Uncontrolled operation may result if this procedure is not followed. Failure to observe this precaution could result in bodily injury.

- Step 4. Remove any debris, such as metal shavings, from around the drive.
- Step 5. Check that there is adequate clearance around the drive.
- Step 6. Verify that the wiring to the terminal strip and the power terminals is correct.
- Step 7. Check that the wire size is within terminal specification and that the wires are tightened properly.

- Step 8. Check that user-supplied branch circuit protection is installed and correctly rated.
- Step 9. Check that the incoming power is rated correctly.
- Step 10. Check the motor installation and length of motor leads.
- Step 11. Disconnect any power correction capacitors connected between the drive and the motor.
- Step 12. Check that the rating of the transformer (if used) matches the drive requirements and is connected properly.
- Step 13. Verify that a property-sized ground wire is installed and a suitable earth ground is used. Check for and eliminate any grounds between the motor frame and the motor power leads. Verify that all ground leads are unbroken.
- Step 14. Uncouple the motor from any driven machinery to initially start the drive.

8.2 Powering Up After Installation is Complete

Use the following procedure to verify that the drive is installed correctly and is receiving the proper line voltage:

- Step 1. Turn the drive's input power disconnect to the On position.
- Step 2. Apply power to the drive.
- Step 3. Follow the start-up procedure in the GV3000/SE Software Start-Up and Reference manual.

Troubleshooting the Drive

This chapter describes now to troubleshoot the drive and the edu priment that is needed to do so. Also provided are replacement part lists and information on clearing faults.

9.1 Test Equipment Needed to Troubleshoot

An isolated multimeter will be needed to measure DC bus voltage and to make resistance checks. Note that dedicated troubleshooting test points are not provided.

9.2 Drive Alarms and Faults

The drive will display alarm and fault codes to assist in troubleshooting when a problem develops during self-tuning or drive operation.

If an alarm condition occurs, the drive will continue to run and a 2- or 3-digit alarm code will f ash on the display.

If a fault occurs, the drive will coast-to-rest stop and a 2- or 3-digit fault orde will flash on the display.

Refer to the GV3000/SE Software Start-up and Reference manual for more information on drive alarms and faults.

9.3 Verifying That DC Bus Capacitors are Discharged



ATTENTION: DC bus capacitors retain hazardous voltages after input power has been disconnected. After disconnecting input power, wait five (5) minutes for the DC bus capacitors to discharge and then check the voltage with a voltmeter to ensure the DC bus capacitors are discharged before touching any internal components. Failure to observe this precaution could result in severe bodily injury or loss of life.

The GV3000/SE drive's DC bus capacitors retain hazardous voltage after input power has been disconnected. Perform the following steps before touching any internal components:

- Step 1. Turn off and look out AC input power. Wai: five minutes.
- Step 2. Remove the drive's cover.
- Step 3. Verify that there is no voltage at the drive's input power term rais.
- Step 4. Measure the DC bus potential with a voltmeter at the DC bus power terminals. See figure 9.1.
- Step 5. Once the drive has been serviced, realtach the drive's cover.
- Step 6. Reapply AC input power.



Figure 9.1 - DC Bus Voltage Terminals

9.4 Checking Out the Power Module with Input Power Off

Use the following procedure to check the drive's Power Module circuitry with power of:

ATTENTION: DC hus capacitors retain hazardous voltages after input power has been disconnected. After disconnecting input power, wait five (5) minutes for the DC bus capacitors to discharge and then check the voltage with a voltmeter to ensure the DC bus capacitors are discharged before touching any internal components. Failure to observe this precaution could result in severe bodily injury or loss of life.

- Step 1. Turn off and look out input power. Wait five minutes.
- Step 2. Remove the drive's cover.
- Step 3. Verify that there is no voltage at the drive's input terminals.
- Step 4. Check the DC bus potential with a voltmeter as described in section 9.3 to ensure that the DC bus capacitors are discharged.
- Step 5. Disconnect the mator from the drive.
- Step 6. Check all AC line and DC bus fuses.
- Step 7. If a fuse is open, use a multimeter to check the input diodes and output IGBTs. See table 9.1.

Note that the drives do not have replaceable transistor modules: the entire drive must be replaced if a transistor malfunctions.

- Step 8. Reconnect the motor to the drive.
- Step 9. Reattach the drive's cover.
- Step 10. Reapply nput power.

Input Diode No.	Meter Connection (-) (-)	Component is OK if resistance (R) is:	Component is detective if:
1	4 P/L1	50 eW < P < 10 MW	Continuity (short circuit) or
2	* S/L2		open when the meter is connected with reversed
3	* T/L3		polarity
1	R/L1 *		33)
5	S/1.2 **		
6	T/L3 **		1

IGBT No.	Meter Connection (+) (-)	Component is OK if resistance (R) is:	Component is defective it:
1	* W/T3	50~kW < H < 10~MW	Continuity (shed circuit) or
2	* V/T2		open when the meter is connected with reversed
3	2 U/T1		polarity
4	W/T3 **		
5	V/T2 **		
6	L/T° •*		
6 • (+) D(• (-) D(L/T ² ** C Bus Volts power C Bus Volts power	terminal terminal	

Table 9.1 - Realstance Checka

9.5 Replacement Parts

Table 9.2 lists the replacement parts that are available from Rel ance Electric. See figures 2.2 and 2.3 for the location of the parts.

		Power Module					
Description	Part Number	30V2060	40V2060	50V2060	60V2060	75V2060	100V2060
Regulator Board	0-58921-XXX	1	1		10 I	t S	1.
Base Board PISC-40	827711	1	ta	1	10	1÷	1 0
Membrane Switch Keypad/Bracket Assembly	907021	E.	E.	1	1	ţ.	1
Inforcal Fan Assembly	907017	1	6 K	6 É	1	1	o 1
Diode Module Fan Assembly	907018 907019	2	2 -	2	-	Ē	ī
IGBT Module Fan Assembly	907020	2	2	2	2	2	2
IGBT Module	536664 536174 536175	3 - -	3 - -	3 -	- 3 3	0 3	- 3 3
Diode Bridge	5° 2902 5° 4706	1	<u>1</u>	1	- 6	- 6	- 8
DC Bus Fuse	286301 268325	1	1	1	ī	1	_ 1
DC Bus Capacitor	453136B	5	3	5	9	y	9

Lable 9.2 - Replacement Parts for the GV 3000/SE Drives

APPENDIX A

Technical Specifications

AC Line Distribution System Capacity (maximum) for 230 VAC Units	Three-phase with 85,000 amps symmetrical fault current capacity with AC line reactor with a line impedance of less than 5%.	
Control Method	All digital vector, sinusuidal pulse width modulated (PWM)	
Displacement Power Factor	0.98	
Line Frequency	50 ± 5 Hz or 60 ± 5 Hz	
Line Voltage Variation	-10% to -10%	
Line Dip Ride Through	Maximum 500 milliseconds - FVG Adjustable up to 999.9 seconds (Sec P.042) - V/Hz, SVC	
Motor Lead Lengths	76 meters (250 feet) total	
Remote Operator Control Wire Length	Up to 303 meters (1000 feet) from the drive	
Analog Speed Reference Recolution	1/1024 (10 bits) 0.1%	
Acceleration Adjustment Range	0.1 to 999.9 seconds (within the ability of current)	
Carrier Frequency	2 kHz, 4 kHz, or 8 kHz, software so octable	
Current Limit Adjustment	U.006 to 150% (based on motor nameplate rating) - vector 50 to 100% (based on motor nameplate rating) - V/Hz ³⁰	
Service Factor	1.0	
Seeed Adjustable Range	From 0 RPM to maximum speed (vector)	
Speed Regulation	Vector = 0.01% FVC, 0.5% SVC (sleady state) V/Hz - metor silp-dependent	
Speed Setpoint Resolution	1 HPM with local keypad4095 to +4095 counts with a network or serial reference	
Turque Control Response	180 to 220 Hz	
Torque Linear ly	+3% with optimal parameter selling (typical) (see parameter 0.005)	

Table A.L. - Service Conditions

11 For WHz regulation, the eventeed current is limited to 100% of the drive nonneplate rating. (For vector regulation, the overload current is limited to 150% of the drive nameplate rating.)

chic A.2	Environmental Good to	n
to setting years	The state of the s	

Condition	Specification	
Operating Temperature (Amblent)	0° to 40°C (32° to 104°I)	
Storage Temperature (Amblent)	-40° to 65°C (-40° to 149°F)	
Humidity	5 to 95% non-condensing	

able A.8 • Terminal amplineur appendence	Table A.8 -	Term ta	Strip Input	Specifications
--	-------------	---------	-------------	----------------

Signal Type	Terminal(s)	Specification
Speed Reference Input	12-15	5 KW potentiometer (0 to +/+ 10 VDC © 50 KW input impedance) or 0-20 mA (@250 W input impedance) with 10 bit resolution. (Jumper-selectable by jumper J4; refer to section 2.4.1.)
		Note that the drive provides +15 VDC buffcred through a 1.875 KW resistor.
Digital inputs (1 - 8)	16	+24 VDC Isolated Suboly
	17	Remote/Loca (Default)
	18	Ramp1/Pamp2 (Detault)
	19	Forward/Reverse (Default)
	20	Function Loss
	21	Ruiking
	22	Reset
	23	Stop
	24	Start

Table A.4 - Terminal Strip Culput Specifications

Signal Type	Terminal(s)	Specification
Analog Oulput	10 - 11 scaled signa	0-10 VDC or 4-20 mA
Snubber Hesistor	26-27	Used with older Snubber Resister Braking Kits such as M/N 2DB2010 series that requires a gate turn-on signal from the drive.

Table A.5 - Terminal St4p RS-232 Spectications

Signal Type	Terminal(s)	Specification
RS 232 Communications	1	XVII
	2	BECV
	3	COMMON

Table A 6 Encoder Feedback Device Specifications (FVC Regularion Only)

Specification	Rating
Motor Poles	2.4,6, or 9 po as
Overcurrent IET	200% load (based on drive namoolate rating)
Overload Current Rating	150% for 1 minute (based on drive nameplate rating)
Soeed Control Range	1:600 with 1024 PPR
Speed Control Response	15 Hz (typical)
Encodo: Feedback	15 V differential quadrature, encoder noremental (S12 PPR, 1024 PPR, 2048 PPR, 4096 PPR)
Service Factor	1.0

Signal Type and Source	Volts/Hertz Regulation**	Vector Regulation **	
Keypad START	150 milliseennds	130 millisaconds	
Terminal Strp:			
START	126 mil leeconds	105 milliseconda	
STOP, RESET. FL	75 milliseconda	75 milliseconds	
Preset Speeds	75 millisəconda	75 milliaeconds	
Analog Speed/Trim Reference	18 milliseconds	5 millisaconds	
Analog Torque Reference	N/A	0.5 milliseconds	
Network:			
START	46 milliseconds + network transport time	25 milliseconds + inetwork transport time	
S OP, HESEL FL	26 milliseconds + network transport time	25 milliseconds + instwork transport time	
Analog Speed/Trim Roterence	S milliseconds + notwork transport time	5 mill seconds + network transport timo	
Torque Reference	N/A	0.5 milliseconds – network transport time	

Table A.7 - Input Signal Peopense Times (Maximum)

 $^{\rm (0)}$. These are the maximum times from transitioning the input to the drive reacting to the input.

30-100 HP GV3000/SE System Wiring Diagram



APPENDIX B

- ta 20 HP and 20 HP ants, 21 pN250 X to 80 HP and 32 HS 50 A
- and six / 14708 clock bioges for 801121b 100, 02 units.
- one 10 Chms/S2C Wireskners for 60 HP to 100 HP units.
- and three 516 674 03 11 modules and three 516 05 03 11 modules.
- WEFP ontic end one S0/IP 9 code and 34 tax assemble is used. to 82 HP through 100 HP units. For 80 HP through 100 HP units.

U.S. Allen-Bradley Drives Technical Support (TSU1) 202 512:8176, Fex (1) 262.512.2222, Email: supports envise rairodswell.com/Online: www.ab.com/support/abenives

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas, Rockwell American, 1201 South Science Science, Milwaskee, WI 49224, 2006 USA, Tel. (1): 411,982,2000, Fasta (1): 414, 582, 444 Europe/Weally basy/Africa. Hitchwell American, Pagasias ack. Det Skethar. 124, 1831 (2004). Reference (1): 569,9800 (2005) (2005) Avertas the four descell American, Level Tel. Careet, Colorgina, 3, 1000 (2007) and 1100 (2007) (2015) (2007) (2007) (2007) (2007)