




MD60 / MD65 NEMA 1 / IP30 Kit Installation Instructions







Model Numbers 6MD-NM1A, 6MD-NM1B, and 6MD-NM1C
Instruction Manual D2-3503-1



ATTENTION: Wait three (3) minutes for capacitors to discharge to safe voltage levels. Failure to observe this precaution could result in severe bodily injury or loss of life.



The thick black bar shown on the outside margin of this page is used to signify new or revised text or figures.



www.rockwellautomation.com



Corporate Headquarters

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions

Americas: Rockwell Automation, 1731 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe: Rockwell Automation SA/NV, Vanstaen/Boulevard du Souverain 36-BP 34B, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, 27/F Chicago Centre, 18 Whitefield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Headquarters for Dodge and Reliance Electric Products

Americas: Rockwell Automation, 6340 Pondara Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.287 4900, Fax: (1) 864.281.2433

Europe: Rockwell Automation, B-Hilfsstraße 22, D-74834 Ebnat-Kalau, Germany, Tel: (49) 8261 9410, Fax: (49) 8261 1774

Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307687, Tel: (35) 351 6723, Fax: (65) 355 1733

Reliance Electric Standard Drives Business, P.O. Box 248019, Mayfield Heights, OH 44124-8019 USA, Tel: (1) 888.374.8370, Fax: 440.645.7317